

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [EGLO](#) /

› [EGLO Tirol 60-inch 3-Blade Ceiling Fan with Dimmable LED Light Kit and Remote Control User Manual](#)

EGLO 235224-6001A

EGLO Tirol 60-inch 3-Blade Ceiling Fan with Dimmable LED Light Kit and Remote Control User Manual

Model: 235224-6001A

1. INTRODUCTION

Thank you for purchasing the EGLO Tirol 60-inch 3-Blade Ceiling Fan with Dimmable LED Light Kit and Remote Control. This manual provides essential information for the safe installation, operation, and maintenance of your new ceiling fan. Please read these instructions thoroughly before beginning installation and retain them for future reference.



Image 1.1: The EGLO Tirol 60-inch 3-Blade Ceiling Fan in White. This image displays the complete fan assembly, including the motor housing, three white blades, and the integrated LED light kit, designed for modern interior spaces.

2. SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these instructions:

- Ensure the installation site is structurally sound and capable of supporting the fan's weight (approximately 22.9 lbs).
- All wiring must be in accordance with national and local electrical codes. Consult a qualified electrician if you are unsure.

- Disconnect power at the circuit breaker or fuse box before beginning installation or performing any maintenance.
- Do not operate the fan with damaged wiring or if any parts are missing.
- Keep hands, clothing, and other objects clear of the fan blades when the fan is operating.
- This fan is intended for indoor use only.
- Do not attempt to repair or replace parts unless specifically instructed in this manual.

Proposition 65 Warning: This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, visit www.P65Warnings.ca.gov.

3. PACKAGE CONTENTS

Verify that all components listed below are present and undamaged before proceeding with installation. If any parts are missing or damaged, contact EGLO customer support.

- Ceiling Fan Motor Assembly
- Fan Blades (3)
- Downrod (2 lengths provided)
- Mounting Bracket
- Canopy
- LED Light Kit
- Remote Control with Wall Mount
- Hardware Pack (screws, washers, wire nuts)
- Instruction Manual

4. SETUP AND INSTALLATION

Professional installation is recommended. Ensure power is disconnected at the circuit breaker before installation.

4.1 Mounting the Fan

1. Secure the mounting bracket to the ceiling junction box. The junction box must be listed for fan support.
2. Attach the chosen downrod to the fan motor assembly, ensuring all screws are tightened securely.
3. Carefully lift the fan assembly and hang it from the mounting bracket.



Image 4.1: Side view of the EGLO Tirol ceiling fan, illustrating the downrod and motor housing connection. This perspective helps visualize the fan's profile once installed.

4.2 Electrical Wiring

Connect the fan's electrical wires to the household wiring according to the provided wiring diagram in the separate wiring guide (if applicable) and local electrical codes. Typically, this involves connecting:

- Black wire (Live/Hot) to Black wire
- White wire (Neutral) to White wire
- Green/Bare Copper wire (Ground) to Green/Bare Copper wire

Ensure all wire connections are secure using the provided wire nuts.

4.3 Attaching Blades and Light Kit

1. Attach each fan blade to the motor housing using the provided screws. Ensure they are firmly secured.
2. Connect the LED light kit wiring to the fan motor assembly.
3. Secure the LED light kit to the fan motor housing.



Image 4.2: A detailed view of the EGLO Tirol fan's central motor housing and integrated LED light kit. This image highlights the sleek design of the light fixture and the connection point for the blades.



Image 4.3: Bottom view of the EGLO Tirol ceiling fan, showcasing the three white blades and the circular LED light diffuser. This angle provides a clear perspective of the fan's operational components from below.

5. OPERATING INSTRUCTIONS

Your EGLO Tirol ceiling fan is operated using the included remote control.

5.1 Remote Control Functions

- **Fan ON/OFF:** Press to turn the fan on or off.
- **Fan Speed:** Buttons typically labeled 1-3 or with fan icons to adjust fan speed (Low, Medium, High).
- **Light ON/OFF:** Press to turn the LED light on or off.
- **Light Dimming:** Press and hold the light button to cycle through brightness levels, or use dedicated dimming buttons if available.
- **Reverse Function:** (If applicable) A button to change the direction of blade rotation for summer (downward airflow) or winter (upward airflow) operation.

Ensure the remote control has fresh batteries installed for optimal performance.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Periodically clean the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure power is off before cleaning.
- **Blade Balance:** If the fan wobbles, check that all blade screws are tight. A balancing kit (often sold separately) can be used to correct persistent wobbling.
- **Light Source:** The integrated LED light kit is designed for long life. If replacement is ever needed, contact EGLO customer support for compatible parts.

7. TROUBLESHOOTING

Refer to the following table for common issues and their potential solutions.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low.	Check circuit breaker; Verify all wire connections are secure; Replace remote control batteries.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws; Use a blade balancing kit; Ensure mounting bracket is securely fastened.
Light does not work	Loose wire connection to light kit; Faulty LED light kit; Remote control battery low.	Check light kit wiring; Contact EGLO support for replacement; Replace remote control batteries.
Remote control not working	Dead batteries; Remote not paired with fan.	Replace batteries; Refer to remote pairing instructions (usually in a separate guide or quick start).

8. SPECIFICATIONS

Feature	Detail
Brand	EGLO
Model Name	Tirol
Model Number	235224-6001A
Fan Size	60 inches
Number of Blades	3
Blade Material	ABS
Color	White Blade
Light Kit	Integrated Dimmable LED
Control Type	Remote Control
Power Source	AC/DC
Voltage	120 Volts
Wattage	18.00 Watts

Feature	Detail
Product Dimensions	60"D x 12.2"W x 60"H
Item Weight	22.91 Pounds
Special Feature	Quiet Operation
Recommended Room Type	Bedroom, Dining Room, Home Office, Living Room




Image 8.1: A fan size guide chart, illustrating recommended fan sizes based on room dimensions in both inches/feet and centimeters. This helps users determine if the 60-inch fan is suitable for their space.

9. WARRANTY AND CUSTOMER SUPPORT






EGLO products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your product or visit the official EGLO website. If you encounter any issues or require technical assistance, please contact EGLO customer support.

EGLO USA Contact Information:

- Website: www.eglo.com/usa (Example link, actual link may vary)
- Refer to product packaging or official website for current contact details.



Image 9.1: The EGLO brand logo, featuring the text "EGLO my light | my style". This logo identifies the manufacturer of the ceiling fan.

	<p><u>EGLO 39685A LEMORIETA Pendant Light Installation Instructions</u></p> <p>Detailed installation guide for the EGLO 39685A LEMORIETA pendant light, including safety precautions, wiring, and height adjustment instructions.</p>
	<p><u>EGLO GIRON-TW LED Ceiling Light Installation and Remote Control Guide (Art.Nr. 75507, 31048)</u></p> <p>Comprehensive guide for installing the EGLO GIRON-TW LED ceiling light (Article Numbers 75507, 31048) and operating its ET3386 IR remote control for brightness and color temperature adjustments.</p>
	<p><u>EGLO 44001A MIDSUMER Pendant Light Installation Guide</u></p> <p>Official installation instructions for the EGLO 44001A MIDSUMER pendant light. Learn how to safely install your new EGLO lighting fixture with step-by-step guidance.</p>
	<p><u>EGLO 99591A NARICES Suspension Light - Installation Guide</u></p> <p>Comprehensive installation guide for the EGLO 99591A NARICES suspension light fixture. Includes essential safety precautions, detailed assembly steps, electrical connection guidance, and height adjustment instructions. Learn how to safely install your new EGLO lighting.</p>
	<p><u>EGLO 300467 LED Lamp: Dimmable and Color Temperature Adjustable</u></p> <p>Explore the EGLO 300467 LED lamp, a modern lighting solution offering adjustable brightness and color temperature (Warm White, Neutral White, Cool White). This guide details its touch controls for effortless operation and customization.</p>
	<p><u>EGLO GIANELLA LED Ceiling Lamp - Installation and Operation Guide</u></p> <p>Detailed instructions for installing and operating the EGLO GIANELLA LED ceiling lamp, including wiring diagrams, assembly steps, and dimming control features. Article number 900947.</p>