

[Manuals.plus](#) /

› [EGLO](#) /

› EGLO Surfline 52" 3-Blade Fan User Manual

EGLO 235111-5202A

EGLO Surfline 52" 3-Blade Fan User Manual

Model: 235111-5202A

Brand: EGLO

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your EGLO Surfline 52" 3-Blade Fan. Please read this manual thoroughly before installation and use, and retain it for future reference.

The EGLO Surfline fan is designed to provide efficient air circulation and ventilation in various indoor spaces. It features a modern aesthetic with a sophisticated black finish, a 52-inch blade span, and convenient remote control operation with 5 speed settings.

2. SAFETY INFORMATION

WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

Always ensure the power supply is disconnected before installation, cleaning, or maintenance. Do not operate the fan with damaged wiring or if it is not properly installed. Keep hands, hair, and clothing away from moving parts. This fan is intended for indoor use only.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation. The package should contain:

- Ceiling Fan Motor Housing
- 3 Fan Blades
- Downrod and Canopy
- Remote Control and Receiver
- Mounting Hardware Kit
- Instruction Manual (this document)



Image: The EGLO Surline 52-inch 3-blade ceiling fan in black, showcasing its sleek design.

4. SETUP AND INSTALLATION

For detailed installation instructions, please refer to the official Installation Manual provided with your product. A digital copy can also be accessed via the following link:

[Download Installation Manual \(PDF\)](#)

General Installation Steps:

1. Turn off power at the circuit breaker.
2. Mount the ceiling bracket securely to a junction box capable of supporting the fan's weight.
3. Assemble the fan blades to the motor housing.
4. Connect the electrical wiring according to the provided diagram in the installation manual.
5. Attach the fan assembly to the ceiling bracket and secure the canopy.
6. Install the remote control receiver.



Image: A full view of the EGLO Surline fan, showing its complete assembly and how it appears when installed.

5. OPERATING INSTRUCTIONS

Your EGLO Surline fan comes with a convenient remote control for easy operation. Ensure the remote control has working batteries installed.

Remote Control Functions:

- **Power On/Off:** Press the power button to turn the fan on or off.
- **Speed Control:** Use the speed buttons to cycle through 5 different fan speeds.
- **Direction Control:** (If applicable, check manual) Button to reverse blade direction for summer (downward airflow) or

winter (upward airflow) operation.



Image: The EGLO Surflin fan installed in a modern bedroom, demonstrating its integration into a living space.

6. MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your fan.

- **Cleaning:** Dust the fan blades and motor housing regularly with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Blade Inspection:** Periodically check that all blade screws are tight. Loose blades can cause wobbling and noise.
- **Motor Lubrication:** The fan motor is permanently lubricated and does not require additional oiling.

CAUTION: Always turn off the power to the fan at the circuit breaker before cleaning or performing any maintenance.

7. TROUBLESHOOTING

If you encounter issues with your EGLO Surflin fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not operate.	No power; loose wiring; remote control battery dead.	Check circuit breaker; verify wiring connections; replace remote control batteries.
Fan wobbles.	Loose blade screws; unbalanced blades; loose mounting bracket.	Tighten all blade screws; ensure blades are balanced (use balancing kit if provided); secure mounting bracket.
Noisy operation.	Loose screws; motor hum; fan not level.	Check and tighten all screws; ensure proper installation; verify fan is level.

8. SPECIFICATIONS

Brand	EGLO
Model Name	Surflin

Item Model Number	235111-5202A
Color	Black
Size	52"
Product Dimensions	52"D x 12.96"W x 52"H
Item Weight	16.73 Pounds
Electric Fan Design	Ceiling Fan
Power Source	AC/DC
Voltage	120 Volts
Special Feature	Quiet Operation
Recommended Uses	Air Circulation, Ventilating
Room Type	Bedroom, Dining Room, Home Office, Living Room




Image: A diagram illustrating recommended fan sizes based on room dimensions in both inches/feet and centimeters.

9. WARRANTY AND SUPPORT

For warranty information and customer support, please visit the official EGLO website or contact their customer service. You can also find additional resources and product information on the EGLO brand store on Amazon:

[Visit the EGLO Store on Amazon](#)

For technical assistance or replacement parts, please refer to the contact information provided in your installation manual or on the EGLO website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DQLXZJQB>

More documents and user manuals: **<https://manuals.plus/>**