

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Accutime](#) /
- › [Accutime Lord of The Rings Watch with Printed Band User Manual](#)

Accutime Lord of the Rings Watch

Accutime Lord of The Rings Watch with Printed Band User Manual

PRODUCT OVERVIEW

The Accutime Lord of The Rings Watch with Printed Band is an officially licensed timepiece featuring a quartz movement and an analog display. This watch is designed for daily wear with a unique printed band inspired by the Lord of the Rings saga.



Image: Front view of the Accutime Lord of The Rings Watch, highlighting its green dial with the Elvish symbol and the patterned green plastic band.

INITIAL SETUP

Setting the Time

1. Locate the crown (small knob) on the right side of the watch case.
2. Pull the crown gently outwards until you feel a click. This is the time-setting position.
3. Rotate the crown clockwise or counter-clockwise to move the hour and minute hands until the desired time is displayed.
4. Once the time is set, push the crown back into its original position. The watch will begin to run.

Adjusting the Band

The watch features a two-piece plastic strap with a buckle clasp. To adjust the fit, insert the buckle pin into one of the pre-punched holes on the strap that provides a comfortable and secure fit on your wrist.

OPERATION

Basic Timekeeping

This watch operates on a quartz movement, providing accurate analog time display with hour, minute, and second hands. No further user interaction is required for basic timekeeping once the time is set.

Water Resistance

This watch is rated as **Moisture Resistant**. This means it can withstand minor splashes, such as from hand washing or light rain. It is **not** suitable for showering, bathing, swimming, or any activities involving submersion in water.

CARE AND MAINTENANCE

Cleaning

- To clean the watch case and crystal, use a soft, damp cloth. Avoid harsh chemicals or abrasive materials.
- For the plastic band, a mild soap solution and a soft cloth can be used. Ensure the band is thoroughly dried afterward.

Battery Replacement

When the watch stops running or the second hand begins to skip, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and function.

Band Care

Avoid prolonged exposure of the plastic band to direct sunlight or extreme temperatures, as this may cause discoloration or material degradation over time. Keep the band clean and dry to prolong its lifespan.

TROUBLESHOOTING

Watch Not Running

- **Check the Crown:** Ensure the crown is fully pushed in. If it is pulled out, the watch will not run.
- **Battery:** The battery may be depleted. Refer to the 'Battery Replacement' section for guidance.

Incorrect Time Display

- **Reset Time:** Follow the 'Setting the Time' instructions to reset the watch to the correct time.
- **Environmental Factors:** Extreme temperatures or strong magnetic fields can sometimes affect quartz watch accuracy. Avoid such conditions.

PRODUCT SPECIFICATIONS

Model Name	Lord of the Rings Watch
Brand	Accutime
Watch Movement Type	Quartz

Display	Analog
Clasp Type	Buckle
Strap Type	Two Piece Strap
Band Material Type	Plastic
Case Material Type	Stainless Steel
Crystal	Mineral Glass
Water Resistance Level	Moisture Resistant
Shape	Round
Band Color	Green
Dial Color	Green
Manufacturer	Accutime Watch Corp.
Package Dimensions	11.42 x 7.87 x 1.18 inches
Item Weight	1 Grams
UPC	030506614937

WARRANTY AND SUPPORT

This product is manufactured by Accutime Watch Corp. For specific warranty information or technical support, please refer to the documentation included with your purchase or contact the manufacturer directly. Keep your proof of purchase for any warranty claims.