

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [HCDZ](#) /

› **HCDZ Replacement Remote Control for beFree Sound Speakers (Models BFS-7777X, BFS-6100, BFS-4500, BFS-9000, BFS-7900, BFS-5700, BFS-6550, BFS-4600) User Manual**

HCDZ B0DQNB94HT

HCDZ Replacement Remote Control User Manual

For beFree Sound BFS-7777X, BFS-6100, BFS-4500, BFS-9000, BFS-7900, BFS-5700, BFS-6550, BFS-4600 Subwoofer Portable Party PA Speakers

INTRODUCTION

This manual provides instructions for the HCDZ Replacement Remote Control. This remote is designed to be compatible with various beFree Sound Subwoofer Portable Party PA Speaker models, including BFS-7777X, BFS-6100, BFS-4500, BFS-9000, BFS-7900, BFS-5700, BFS-6550, and BFS-4600. It functions as a direct replacement and requires no programming.

The package includes one remote control. Batteries and additional instructions are not included in the package.

SETUP: BATTERY INSTALLATION

The remote control requires two AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open it.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: Back of the remote control with the battery compartment open, showing the correct orientation for inserting two AAA batteries.



Image: Back of the remote control with the battery compartment securely closed after installation.

Once new batteries are inserted, the remote control will be ready for use immediately. No programming is required.

OPERATION

This HCDZ replacement remote control operates using infrared (IR) technology. To control your beFree Sound speaker, point the remote control directly towards the IR sensor on the speaker.

The remote provides standard functions for controlling your speaker. Refer to your beFree Sound speaker's original manual for specific button functions if needed.

MAINTENANCE AND CARE

- **Storage:** Do not leave the remote control in extremely hot or humid environments.
- **Battery Usage:** Avoid mixing new batteries with old ones. Always replace all batteries with new ones simultaneously.
- **Direct Sunlight:** Do not expose the remote control's IR sensor to direct sunlight or strong lighting apparatuses, as this may cause a malfunction.
- **Long-Term Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent potential damage from battery leakage and corrosion.
- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.

TROUBLESHOOTING

If the remote control is not functioning as expected, consider the following troubleshooting steps:

- **Replace Batteries:** The most common cause of remote control malfunction is depleted batteries. Replace both AAA batteries with fresh ones.
- **Check Battery Terminals:** Ensure the battery terminals inside the compartment are clean and that the batteries are inserted with the correct polarity (+/-).
- **Proximity to Device:** The remote control operates within a certain range. Move closer to your beFree Sound speaker to ensure it is within effective operating distance.
- **Obstructions:** Remove any physical obstructions between the remote control and the IR sensor on your speaker. Ensure a clear line of sight.
- **Speaker Power:** Verify that your beFree Sound speaker is properly plugged in and powered on. The remote cannot control a device that is off or unplugged.

SPECIFICATIONS

Brand	HCDZ
Compatible Devices	beFree Sound Subwoofer Portable Party PA Speakers (BFS-7777X, BFS-6100, BFS-4500, BFS-9000, BFS-7900, BFS-5700, BFS-6550, BFS-4600)
Connectivity Technology	Infrared (IR)
Max Number of Supported Devices	1
Special Feature	No Programming Required
Batteries Required	2 AAA batteries (not included)
Package Dimensions	Approximately 5.91 x 3.94 x 1.18 inches
Manufacturer	HCDZ

WARRANTY AND SUPPORT

Specific warranty information for this HCDZ replacement remote control is not provided in the product details. For any support inquiries or further assistance, please refer to the seller or manufacturer directly. You can visit the [HCDZ Store on Amazon](#) for more information about the brand and its products.