

enya INSPIRE-BK

Enya Electric Guitar Inspire Instruction Manual

Model: INSPIRE-BK

INTRODUCTION

The Enya Electric Guitar Inspire is a cutting-edge 39-inch smart electric carbon fiber guitar designed for musicians seeking versatility and convenience. Featuring an integrated 15W wireless speaker, 20 distinct tones, and customizable onboard presets via the ENYA MUSIC App, this instrument offers a comprehensive playing experience without the need for external amplification. Its durable carbon fiber construction ensures reliability in various environments, making it ideal for practice, performance, and creative exploration.

KEY FEATURES

- **Smart System Integration:** Equipped with a powerful 15W speaker, 20 distinct tones, and deep customization options accessible through the ENYA MUSIC App. Includes 6.35mm output jack, 3.5mm headphone output jack, and a USB Type-C port for charging and OTG recording.
- **Integrated Onboard Speaker:** The 15-watt speaker allows for easy amplification of presets and effects for practice or small jam sessions. Wireless connectivity enables seamless audio playback from your phone.
- **SSH Pickup Configuration:** Features ceramic magnet SSH pickups suitable for various genres including rock, fusion, blues, and prog. A push-pull volume knob allows switching the bridge pickup between series and parallel coil configurations for enhanced tonal versatility.
- **Strat-Style Design:** A super Strat model with 24 frets for extended fretboard exploration. Combines SSH pickups, an ultra-ergonomic design, a 2-point tremolo bridge, onboard speaker, and built-in presets for a powerful musical tool.
- **Onboard Presets & Dual Output:** Comes with 4 factory presets (Clean, Overdrive, Crunch, Lead) easily switchable with a single button. These presets can be amplified through the onboard speaker or connected to an external amplifier or PA system for live performances.

SETUP GUIDE

1. **Unboxing:** Carefully remove the guitar and all accessories from the gig bag. Verify all components are present: guitar, charging cable, adjusting wrench.
2. **Initial Charge:** Connect the guitar to a power source using the provided USB Type-C cable. Ensure the battery is fully charged before first use for optimal performance.
3. **Tuning:** Use a digital tuner (built-in or external) to tune the guitar to standard EADGB_e tuning. The stable carbon fiber neck helps maintain tuning stability.
4. **App Connection:** Download the ENYA MUSIC App from your device's app store. Enable Bluetooth on your mobile device and pair it with your Enya Inspire guitar for full customization and control.
5. **Strap Attachment:** Attach a guitar strap to the strap buttons located on the body of the guitar for comfortable playing while standing.



The Enya Inspire Electric Guitar comes complete with essential accessories including a gig bag, charging cable, and adjusting wrenches.


OPERATING INSTRUCTIONS

Powering On/Off

To power on the smart system, press and hold the main control knob until the indicator light illuminates. To power off, press and hold the same knob until the light turns off.

Using Onboard Speaker & Presets

The Enya Inspire features a built-in 15W speaker for immediate sound output. Use the dedicated button to cycle through the 4 onboard presets: Clean, Overdrive, Crunch, and Lead. Each preset offers a distinct tonal character for various playing styles.




The Enya Inspire's onboard speaker offers convenient, cable-free playing, eliminating the need for external amplifiers during practice.

App Control & Customization

Connect your guitar to the ENYA MUSIC App via Bluetooth for advanced control. The app allows you to:

- Customize existing presets or create new ones.
- Access a wider range of virtual effects (amp models, EQ, modulation, delay, reverb, etc.).
- Adjust volume levels for guitar, Bluetooth audio, speaker, and line out.
- Enable OTG (On-The-Go) recording via the USB Type-C port.



Four Onboard Presets & DIY for More

Customize your sound with the ENYA MUSIC App, offering a wide array of tones and effects.

Output Options

- **6.35mm Output Jack:** Connect to external amplifiers, PA systems, or audio interfaces for larger sound or recording.
- **3.5mm Headphone Output Jack:** For silent practice sessions.
- **USB Type-C Port:** For charging and direct OTG recording to compatible devices.

Video Demonstrations

Your browser does not support the video tag.

Official Enya Inspire video showcasing various tones and playability for entertainment.

Your browser does not support the video tag.

Experience unlimited harmonic feedback with the Inspire Smart Guitar, demonstrating its unique capabilities.

Your browser does not support the video tag.

A demonstration of the Enya Inspire's sound capabilities with a guitar solo from 'Sweet Child O' Mine'.

Your browser does not support the video tag.

Highlighting the convenience of the Enya Inspire's onboard speaker
for direct sound output.

Your browser does not support the video tag.

Discover the Enya Inspire, a guitar that eliminates the need for
pedals or external amps.

Your browser does not support the video tag.

The Inspire guitar delivers a powerful sound, adding more 'bite' to
your music.

Your browser does not support the video tag.

A musician demonstrates playing the Enya Inspire smart electric
guitar, highlighting its advanced features.

Your browser does not support the video tag.

Testing famous guitar riffs on the Enya Inspire, showcasing its
versatility for various musical styles.

MAINTENANCE

- **Cleaning:** Wipe the guitar body and neck with a soft, dry cloth after each use to remove sweat and grime. For deeper cleaning, use a slightly damp cloth and dry thoroughly. Avoid harsh chemicals.
- **String Replacement:** Replace strings regularly (e.g., every 1-3 months depending on usage) to maintain optimal tone and playability. Refer to the specifications for recommended string material (Nickel High Carbon).
- **Battery Care:** Recharge the internal 12V battery as needed using the USB Type-C port. Avoid completely draining the battery frequently to prolong its lifespan. If storing for extended periods, charge to about 50% and store in a cool, dry place.
- **Storage:** Store the guitar in its provided gig bag to protect it from dust, scratches, and minor impacts. While carbon fiber is durable, proper storage helps maintain its pristine condition.
- **Bridge and Tremolo Maintenance:** Periodically check the 2-point tremolo bridge for proper function and lubrication. If tuning stability issues arise, ensure the tremolo springs are correctly tensioned (professional setup recommended if unsure).

TROUBLESHOOTING

- **No Sound from Speaker:** Ensure the guitar's smart system is powered on. Check the volume levels on the guitar and within the ENYA MUSIC App. Confirm the speaker volume is not muted.
- **No Sound from External Amp/Headphones:** Verify the cable connection to the 6.35mm or 3.5mm jack. Check the volume on the external device. Ensure the guitar's output volume is not muted in the app.
- **Bluetooth Connectivity Issues:** Make sure Bluetooth is enabled on your mobile device and the ENYA MUSIC App is open. Try restarting both the guitar and your device. Ensure the guitar is not already paired with another device.
- **Tuning Instability:** Check string condition and replace if old or worn. Ensure proper string winding on tuning pegs. If using the tremolo system heavily, verify spring tension and bridge setup.

- **App Not Responding:** Close and reopen the ENYA MUSIC App. Restart your mobile device and the guitar. Ensure the app is updated to the latest version.

SPECIFICATIONS

Feature	Specification
Model Number	INSPIRE-BK
Item Weight	11.62 pounds
Product Dimensions	43.11 x 5.81 x 25 inches
Body Material	Carbon Fiber
Neck Material Type	carbon
Fretboard Material	carbon
Number of Strings	6
Guitar Pickup Configuration	S-S-H
Speaker Count	1
Speaker Amplification Type	active
Supported Software	Enya Music
Battery Type	12V (included)
Hand Orientation	Right
Proficiency Level	All

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product packaging or visit the official Enya Musical website. Specific warranty terms and contact details may vary by region.

© 2025 Enya Musical. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question