

[Manuals.plus](#) /

> [Outsunny](#) /

> Outsunny Single Outdoor Privacy Screen (Model 84J-038V00BK) Instruction Manual

Outsunny 84J-038V00BK

Outsunny Single Outdoor Privacy Screen

Model: 84J-038V00BK

Brand: Outsunny

1. INTRODUCTION

Thank you for choosing the Outsunny Single Outdoor Privacy Screen. This versatile panel is designed to provide privacy, act as a sunshade, or function as a room divider for both indoor and outdoor environments. Constructed with a durable steel frame and water-repellent 160gsm polyester fabric offering UV30+ protection, it is built for stability and ease of use. Please read this manual thoroughly before assembly and operation to ensure proper use and longevity of your product.



Figure 1: Outsunny Single Outdoor Privacy Screen, Black.

2. SAFETY INFORMATION

- Do not use in high wind conditions.
- Ensure the divider is properly anchored to prevent tipping.
- Keep children and pets away from the product during assembly.
- Regularly inspect all components for wear and tear. Replace damaged parts immediately.

3. PRODUCT COMPONENTS

Before assembly, ensure all parts are present and undamaged. Refer to the included parts list in your packaging for detailed component identification. Key components include:

- Steel Frame Poles
- Polyester Fabric Panel
- Wide Support Feet

- Assembly Hardware (screws, washers, etc.)
- Assembly Tool (e.g., Allen wrench)



Figure 2: Key components of the privacy screen.

4. ASSEMBLY INSTRUCTIONS

A detailed installation manual with specific diagrams is included in your product packaging. The following steps provide a general overview:

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out. Compare them with the parts list provided in your product's specific manual to ensure nothing is missing.
2. **Assemble the Frame:** Connect the vertical and horizontal steel poles according to the diagrams in your manual. Ensure all connections are secure.
3. **Attach the Fabric Panel:** Slide the polyester fabric panel onto the assembled frame. The fabric is designed to fit snugly.
4. **Secure the Support Feet:** Attach the wide support feet to the bottom of the vertical poles using the provided hardware. Tighten all screws firmly to ensure stability.
5. **Final Check:** Verify that all parts are correctly assembled and tightened before placing the screen in its desired location.

STABLE AND PROTECTIVE



Powder Coated
Steel Frame

160gsm Polyester Fabric
Water Repellent
UV30+

Wide Feet

Figure 3: Stable and protective design with steel frame and wide feet.



ELEVATED BASE

Allows for better air circulation
and less wind stress

Figure 4: Elevated base for improved air circulation and wind resistance.

5. OPERATING INSTRUCTIONS

The Outsunny Single Outdoor Privacy Screen is designed for simple operation:

- **Positioning:** Due to its freestanding design with wide feet, the screen can be easily moved and positioned to create privacy, block sun, or divide spaces as needed.
- **Indoor Use:** Place the screen on a flat, stable surface to define areas in a room or create a private nook.
- **Outdoor Use:** Position the screen on a level patio, deck, or garden area. For added security, especially in areas prone to light breezes, consider placing heavy objects on the wide feet or using additional anchoring methods (not included) if suitable for your surface.



Figure 5: Privacy screen in an outdoor patio setting.



Figure 6: Privacy screen used in an indoor setting.

6. MAINTENANCE

- **Cleaning:** Wipe the steel frame with a damp cloth and mild soap. The polyester fabric can be spot cleaned with a soft brush, mild detergent, and water. Rinse thoroughly and allow to air dry completely before storage.
- **Storage:** When not in use for extended periods or during severe weather, disassemble the screen if possible and store it in a dry, protected area to prolong its lifespan.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight.

7. TROUBLESHOOTING

- **Instability in Wind:** The screen may not be stable enough in windy conditions. If using outdoors, ensure it is placed in a sheltered location or consider additional anchoring (e.g., sandbags on feet, ground stakes if applicable) to prevent tipping.
- **Loose Connections:** If the screen feels wobbly, check all screws and connections and tighten them as necessary.

8. SPECIFICATIONS

Feature	Detail
Overall Dimensions	70.9"L x 19.7"W x 70.9"H (180 x 50 x 180 cm)
Model Number	84J-038V00BK
Colour	Black
Material	Polyester, Steel
Fabric Weight	160gsm
UV Protection	UV30+
Item Weight	3.18 kg
Assembly Required	Yes

70.9" (180 cm)




Figure 7: Product Dimensions.

9. OFFICIAL PRODUCT VIDEOS

No official seller videos directly demonstrating the assembly or features of this specific Outsunny Single Outdoor Privacy Screen (Model 84J-038V00BK) were found in the provided data.

10. WARRANTY AND SUPPORT

Specific warranty information and detailed support contacts are not available in the provided product data. For warranty claims, technical support, or missing parts, please refer to the contact information provided in your product's packaging or visit the official Outsunny website.