

KB2004-1-PLTMX, KB2030-3-PLTMX-FB, KB2403-1-PLTMX, KB2403-3MP-PLTMX, KB2404-1-PLTMX

Generic Remote Control User Manual

For King Electric Garage Heater KB PlatinumX Series

1. INTRODUCTION

This document provides essential information and instructions for the Generic replacement remote control designed for use with King Electric Garage Heater KB PlatinumX Series models. This remote is an infrared (IR) replacement unit. It is crucial to verify that your original remote control matches the appearance of this replacement unit for proper functionality.

Compatible Models:

- KB2004-1-PLTMX
- KB2030-3-PLTMX-FB
- KB2403-1-PLTMX
- KB2403-3MP-PLTMX
- KB2404-1-PLTMX

If your specific heater model is not listed, please compare your original remote control carefully with the images provided in this manual. Functionality cannot be guaranteed for models not explicitly listed or if the remote's appearance differs from your original unit.



Image 1.1: Visual comparison of an original remote (left) and the replacement remote (right). Ensure your original remote matches the design of the replacement for compatibility.

2. PRODUCT OVERVIEW

The replacement remote control features a straightforward design for easy operation of your King Electric Garage Heater. It includes essential buttons for controlling the heater's functions.

We sell

compatible with following model:



Image 2.1: Front view of the remote control, showing the button layout.

Key Buttons:

- **START/STOP:** Powers the heater on or off.
- **MODE:** Cycles through available operating modes (e.g., heat, fan).
- **Up Arrow (▲):** Increases settings such as temperature or fan speed.
- **Down Arrow (▼):** Decreases settings such as temperature or fan speed.

3. SETUP

3.1 Battery Installation

The remote control requires two (2) AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to remove it.



Image 3.1: Back view of the remote control, showing the battery compartment cover.

3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.



Image 3.2: Battery compartment with the cover removed, showing the battery terminals.

4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: This replacement remote control does not require any programming or setup. Once batteries are installed, it is ready for use with compatible King Electric Garage Heaters.

4. OPERATION

To operate your King Electric Garage Heater using this remote control, point the remote directly at the heater's infrared receiver. Ensure there are no obstructions between the remote and the heater.

- **Power On/Off:** Press the **START/STOP** button once to turn the heater on. Press it again to turn the heater off.
- **Change Mode:** Press the **MODE** button to cycle through the available operating modes of your heater. Refer to your heater's original manual for specific mode descriptions.
- **Adjust Settings:** Use the **Up Arrow (▲)** to increase temperature, fan speed, or other adjustable settings. Use the **Down Arrow (▼)** to decrease these settings.

Important: While this remote is a functional replacement, it may not replicate every single function of your original remote if your original had advanced features not present on this simplified replacement. Basic power, mode, and temperature adjustments are supported.

5. MAINTENANCE

5.1 Battery Replacement

Replace batteries when the remote control's range decreases or if it stops responding. Always replace both

AAA batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries.

5.2 Cleaning

To clean the remote control, wipe it with a soft, dry cloth. Do not use liquid cleaners, aerosols, or harsh chemicals, as these can damage the remote's surface or internal components.

5.3 Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device.

6. TROUBLESHOOTING

- **Remote not responding:**

- Check if the batteries are installed correctly with the correct polarity (+/-).
- Replace the batteries with fresh AAA batteries.
- Ensure there are no obstructions between the remote and the heater's IR receiver.
- Verify that the remote is pointed directly at the heater.
- Confirm that your heater model is listed as compatible or visually matches the remote.

- **Limited range:**

- Replace the batteries.
- Ensure no strong light sources (like direct sunlight) are interfering with the IR signal.

7. SPECIFICATIONS

Product Type	Infrared (IR) Replacement Remote Control
Compatible Devices	King Electric Garage Heater KB PlatinumX Series (Models: KB2004-1-PLTMX, KB2030-3-PLTMX-FB, KB2403-1-PLTMX, KB2403-3MP-PLTMX, KB2404-1-PLTMX)
Batteries Required	2 x AAA (not included)
Color	Black
Max Supported Devices	1

8. WARRANTY AND SUPPORT

Information regarding specific warranty terms for this Generic replacement remote control is not provided. For any issues or questions, please refer to the seller or retailer from whom the product was purchased.

