

[Manuals.plus](#) /

› [WLIVE](#) /

› WLIVE Black 6-Drawer Dresser Instruction Manual

WLIVE ASNG111BL

WLIVE Black 6-Drawer Dresser Instruction Manual

Model: ASNG111BL | Brand: WLIVE

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your WLIVE Black 6-Drawer Dresser. Please read this manual thoroughly before beginning assembly to ensure proper setup and safe use of the product. Keep this manual for future reference.

PRODUCT OVERVIEW

The WLIVE Black 6-Drawer Dresser is a versatile storage solution designed for various rooms, including bedrooms, living rooms, hallways, and closets. It features a modern design with sturdy metal handles and offers ample storage capacity. This dresser can also function as a TV stand for televisions up to 55 inches.

- **Modern Design:** Classic and atmospheric wooden dresser with exquisite metal handles.
- **Large Storage Capacity:** Equipped with six spacious drawers for organizing clothes, toys, blankets, and other household items.
- **Multi-functional:** Can be used as a clothing organizer, entryway table, decorative storage unit, or a TV stand for up to 55-inch TVs.
- **Stable and Smooth Operation:** Features a middle support plate for enhanced stability and load capacity, along with smooth metal slides for easy drawer access.
- **Safe and Sturdy Construction:** Crafted from durable engineered wood, resistant to scratches. Each drawer supports up to 30 lbs, and the tabletop supports up to 130 lbs. Includes an anti-tipping device for safety.



Image: Front view of the WLIVE Black 6-Drawer Dresser, showcasing its modern design and six drawers.

PRODUCT SIZE



Image: Diagram illustrating the dimensions of the dresser (15.75"D x 47.24"W x 31.89"H) and the weight capacity of drawers (30 lbs each) and tabletop (130 lbs).



Image: The dresser shown with a television on top, indicating its suitability as a TV stand for up to 55-inch TVs.

PARTS LIST

Before assembly, ensure all parts and hardware are present and undamaged. Refer to the assembly instructions video for visual identification of each component.

Part ID	Description	Quantity
1	Bottom Panel	1
2	Left Side Panel	1
3	Middle Partition Panel	1
4	Right Side Panel	1
5	Back Support Bar (Bottom)	1

Part ID	Description	Quantity
6	Back Support Bar (Top/Middle)	2
7	Top Panel	1
8	Drawer Bottom Panel	6
9	Drawer Front Panel	6
10	Drawer Back Panel	6
11	Drawer Side Panel (Right)	6
12	Drawer Side Panel (Left)	6
13	Drawer Middle Support	6
14	Drawer Backboard	6

Hardware List:

ID	Description	Quantity
A	Cam Lock	36
B	Wood Dowel	16
C	Cam Bolt	36
D	Leg (Front)	2
E1	Anti-tip Bracket (Wall)	2
E2	Anti-tip Bracket (Dresser)	2
E3	Anti-tip Screw	8
F	Small Screw	37
G	Middle Leg	1
H	Leg (Back)	4
I	Leg Mounting Plate (Corner)	4
J	Leg Mounting Plate (Middle)	1
K	Drawer Slide Screw	48
L	Drawer Handle	6
M	Drawer Bottom Screw	12
N	Large Screw	46
O	Back Panel Nail	1
P	Allen Wrench	1

ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to have a second person assist with assembly.

Your browser does not support the video tag.

Video: Official WLIVE assembly instructions for the 6-drawer dresser. This video provides a visual guide for each step of the assembly process.

Step-by-Step Assembly:

1. **Prepare Side Panels:** Attach drawer slides to the Left Side Panel (2) and Right Side Panel (4) using screws (K) and cam locks (CR, CL).
2. **Attach Middle Partition:** Secure drawer slides to the Middle Partition Panel (3) using screws (K) and cam locks (CR, CL).
3. **Assemble Main Frame:** Connect the Left Side Panel (2), Middle Partition Panel (3), and Right Side Panel (4) to the Bottom Panel (1) using cam bolts (C) and cam locks (A). Attach the back support bars (5, 6) and the Top Panel (7) to complete the main frame. Use large screws (N) and wood dowels (B) as indicated.
4. **Install Legs:** Attach the leg mounting plates (I, J) to the bottom of the dresser. Secure the front legs (D), back legs (H), and middle leg (G) to the plates using small screws (F).
5. **Assemble Drawers:** For each of the six drawers:
 - Attach the drawer sides (11, 12) to the drawer front (9) and back (10) panels using cam bolts (C) and cam locks (A).
 - Slide the drawer bottom panel (8) into the grooves.
 - Secure the drawer bottom panel (8) with drawer bottom screws (M).
 - Attach the drawer middle support (13) and backboard (14) as shown.
 - Install the drawer handles (L) to the front panels (9) using small screws (F).
6. **Insert Drawers:** Carefully slide each assembled drawer into its corresponding slot in the dresser frame.
7. **Install Anti-Tipping Device:** Secure the anti-tip bracket (E2) to the back of the dresser using anti-tip screws (E3). Attach the wall bracket (E1) to a wall stud using appropriate hardware (not included, but typically E3 screws are used for this as well, or wall anchors). Connect the dresser to the wall bracket using the provided strap or cable. This step is crucial for safety to prevent tipping.

ANTI-TIP LOCK DETAILS






Image: Illustration demonstrating the correct installation of the anti-tipping device to secure the dresser to the wall.

OPERATING INSTRUCTIONS

Your WLIVE dresser is designed for ease of use and durability.

- **Opening/Closing Drawers:** Gently pull or push the metal handles to open and close the drawers. The smooth gliding system ensures effortless operation.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 30 lbs per drawer and 130 lbs for the tabletop. Overloading can damage the dresser and pose a safety risk.
- **TV Placement:** If using as a TV stand, ensure the television's base fits securely on the tabletop and its weight does not exceed 130 lbs.



Image: Close-up views highlighting the wide elegant metal handles, smooth gliding system for drawers, and stable base supports of the dresser.

MAINTENANCE

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Heat and Moisture:** Keep the dresser away from direct heat sources and areas of high humidity.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.

TROUBLESHOOTING

If you encounter any issues with your dresser, refer to the following common solutions:

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned drawer slides or loose screws.	Check that all screws on the drawer slides are securely tightened. Ensure the slides are properly aligned with the tracks on the dresser frame.
Dresser feels wobbly or unstable.	Loose assembly hardware or uneven floor.	Verify all cam locks and screws in the main frame are fully tightened. Ensure the dresser is placed on a level surface. Adjust leg levelers if present, or use shims if needed. Confirm the anti-tipping device is correctly installed and secured to a wall stud.
Parts do not fit together during assembly.	Incorrect orientation of parts or missing pre-drilled holes.	Double-check the part numbers and orientation against the assembly video and diagrams. If a pre-drilled hole is missing or misaligned, contact customer support. Do not force parts together.
Strong odor from new furniture.	Off-gassing from manufacturing materials.	Air out the room by opening windows and doors. Leave drawers open for a few days to allow ventilation. Wiping down surfaces with a damp cloth (e.g., with a mild vinegar solution) may help.

SPECIFICATIONS

Feature	Detail
Brand	WLIVE
Product Dimensions	15.75"D x 47.24"W x 31.89"H
Color	Black
Mounting Type	Floor Mount
Room Type	Bedroom, Closet, Home Office, Living Room, Study Room
Special Features	Safety Stop, Scratch Resistant, Space Saving
Assembly Required	Yes
Model Name	ASNG111 Wood dresser/BL
Item Weight	85.6 Pounds
Size	15.8"D x 47.2"W x 31.9"H (6 Drawers)
Manufacturer	WLIVE
ASIN	B0DQQ4V78R
Item Model Number	ASNG111BL
Date First Available	December 17, 2024

WARRANTY AND SUPPORT

WLIVE is committed to providing quality products and customer satisfaction.

- **Returns:** This product is eligible for 30-day easy returns. Please refer to the retailer's return policy for specific details.
- **Customer Support:** If you encounter any problems during assembly or use, or if you have questions regarding parts or functionality, please contact WLIVE customer support. Detailed contact information can typically be found on the product packaging or the retailer's website.
- **Missing or Damaged Parts:** If any parts are missing or damaged upon arrival, please contact customer support immediately for assistance. Parts and accessories are coded for easy identification.

© 2025 WLIVE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question