

- Manuals.plus /
- › [HP](#) /
 - › HP 15 Slim Laptop User Manual

HP Slim

HP 15 Slim Laptop User Manual

Model: Slim

INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your HP 15 Slim laptop. Designed for efficiency and portability, this laptop features an Intel Celeron N4120 processor, 16GB RAM, 1TB storage (512GB SSD + 512GB external hard drive), and runs on Windows 11 Pro. Please read this manual thoroughly to ensure optimal performance and longevity of your device.

SLEEK AND THIN DESIGN

experience a slim and elegant profile



Image: The HP 15 Slim Laptop showcasing its sleek and thin design, emphasizing its portable profile.

SETUP

1. Unboxing and Initial Inspection

Carefully remove all components from the packaging. Verify that the following items are included:

- HP 15 Slim Laptop
- Power Adapter
- 512GB External Hard Drive
- Microfiber Cloth
- Hotkey Sticker Sheet

2. Connecting the Power Adapter

Connect the power adapter to the laptop's AC smart pin port and then plug it into a power outlet. It is recommended

to fully charge the laptop before first use.

3. Initial Power On and Windows 11 Pro Setup

Press the power button to turn on the laptop. Follow the on-screen instructions to complete the Windows 11 Pro setup process. This includes selecting your region, language, connecting to a Wi-Fi network, and creating a user account.

4. Connecting Peripherals

Your HP 15 Slim laptop features various ports for connecting external devices:

- **USB Type-C (5Gbps signaling rate):** For data transfer only.
- **USB Type-A (5Gbps signaling rate):** For connecting USB devices like mice, keyboards, or external storage.
- **HDMI 1.4b:** For connecting to external displays.
- **Multi-format SD media card reader:** For reading SD cards.
- **Headphone/microphone combo:** For audio input/output.

OPTIMIZED FOR PROFESSIONALS

*Pre-installed with Windows 11 Pro
for enhanced security and professional capabilities*



Image: A detailed view of the HP 15 Slim Laptop's side ports, illustrating the locations of the headphone/microphone combo jack,

OPERATING

1. Power Management

- **Power On:** Press the power button located on the keyboard deck.
- **Sleep Mode:** Close the lid or select 'Sleep' from the Windows Start menu.
- **Shut Down:** Select 'Shut down' from the Windows Start menu.

2. Keyboard and Touchpad

The laptop features a full-size US English keyboard with a numeric keypad for efficient data entry. The integrated touchpad supports multi-touch gestures for navigation and interaction with the operating system.

3. Display

Your HP 15 Slim is equipped with a 15.6-inch Full HD (1920x1080) anti-glare display, providing clear visuals and reducing reflections for comfortable viewing.

FULL HD DISPLAY

Enjoy sharp and clear visuals with anti-glare



Image: The HP 15 Slim Laptop with its screen displaying a high-definition image, highlighting the clarity of its Full HD anti-glare display.

4. Audio and Webcam

The laptop includes dual stereo speakers for audio output and dual array microphones for clear voice input. The integrated 720p HD webcam is suitable for video calls and online meetings.

5. Windows 11 Pro and AI Features

Benefit from the advanced features of Windows 11 Pro, including enhanced security and productivity tools. The AI-powered Intel Celeron processor and Windows Copilot offer intelligent task management and personalized assistance to streamline your workflow.

Headphone/microphone combo

HDMI 1.4b

Media card reader

SuperSpeed USB Type-C®



SuperSpeed USB Type-A

HP Fast Charge
Charge up to 50%
in 45 minutes¹

USB Type-C® and USB-C® are trademarks of USB Implementers Forum.

¹ Recharges your battery up to 50% within 45 minutes when the system is off (using "shut down" command). Recommended for use with the HP adapter provided with the notebook, not recommended with a smaller capacity battery charger. After charging has reached 50% capacity, charging speed will return to normal speed. Charging time may vary +/-10% due to System tolerance.

Image: The HP 15 Slim Laptop displaying the Windows 11 Pro interface, indicating its optimization for professional use with enhanced security and capabilities.

ENHANCED SECURITY

Protect your data with advanced security features including TPM 2.0 Express VPN, and McAfee Security. Enjoy peace of mind with encryption and comprehensive protection.



Image: The HP 15 Slim Laptop with a graphic overlay of a shield, symbolizing its enhanced security features for data protection.

6. Battery Life

The laptop provides up to 9 hours of battery life, allowing for extended use without needing to recharge frequently.

LONG BATTERY LIFE

Stay unplugged longer with 41 Wh Li-ion.
Up to 9 hours of battery life.



Image: The HP 15 Slim Laptop with a visual representation of its long battery life, highlighting up to 9 hours of usage.

LIGHTWEIGHT AND PORTABLE

Only 3.8lb, easy to carry around



Image: The HP 15 Slim Laptop held in a hand, illustrating its lightweight and portable nature, weighing only 3.8 lbs.

POWERFUL INTERNALS

AI-Powered Intel Processor, Boosts Performance with Efficiency



Image: The HP 15 Slim Laptop with multiple application windows open, signifying its powerful internals and efficient performance driven by the AI-powered Intel processor.

MAINTENANCE

1. Cleaning the Laptop

Use the provided microfiber cloth to gently clean the screen and exterior surfaces of your laptop. Avoid using harsh chemicals or abrasive materials. Ensure the laptop is powered off before cleaning.

2. Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Store the laptop in a cool, dry place when not in use for extended periods. For optimal performance, use the original HP power adapter.

3. Software Updates

Regularly check for and install Windows 11 Pro updates to ensure your system has the latest security patches and

performance enhancements. Go to **Settings > Windows Update** to manage updates.

4. Storage Management

Your laptop comes with 1TB of storage (512GB M.2 SSD + 512GB external hard drive). Regularly back up important data to the external drive or cloud storage. Periodically clean up unnecessary files to maintain optimal performance of the SSD.

TROUBLESHOOTING

This section addresses common issues you might encounter with your HP 15 Slim laptop.

1. Laptop Does Not Power On

- Ensure the power adapter is securely connected to both the laptop and a working power outlet.
- Verify that the power outlet is functional by plugging in another device.
- If the battery is completely drained, allow it to charge for at least 30 minutes before attempting to power on.

2. Display Issues

- If the screen is blank, try adjusting the display brightness using the function keys (Fn + Fx keys, where Fx is the brightness control).
- If an external monitor is connected, ensure the correct display output is selected (Fn + Fx key for display switching).

3. Wi-Fi or Bluetooth Connectivity Problems

- Check if Wi-Fi or Bluetooth is enabled in Windows Settings.
- Restart your router or modem.
- Update wireless drivers through Windows Update or HP's support website.

4. Slow Performance

- Close unnecessary applications running in the background.
- Ensure Windows 11 Pro is up to date.
- Check for malware or viruses using a reputable antivirus program.
- Free up disk space on your SSD.

For more complex issues, refer to the HP support website or contact customer service.

SPECIFICATIONS

Brand	HP
Model Name	Slim
Processor	Intel Celeron N4120 (4 Cores, up to 2.6 GHz, 4 MB L2 cache)
Graphics	Intel UHD Graphics (Integrated)

Operating System	Windows 11 Pro
Memory (RAM)	16GB DDR4 SDRAM
Storage	1TB (512GB M.2 Solid State Drive + 512GB External Hard Drive)
Display	15.6" FHD (1920x1080) Anti-glare LED
Wireless Connectivity	Wi-Fi (802.11ac, 802.11ax), Bluetooth 5
Audio	Dual stereo speakers, Dual array microphones
Webcam	HD 720p
Ports	1x USB Type-C 5Gbps, 2x USB Type-A 5Gbps, 1x HDMI 1.4b, 1x Multi-format SD media card reader, 1x Headphone/microphone combo, 1x AC smart pin
Battery Life	Up to 9 hours
Dimensions (L x W x Th)	14.09" x 9.53" x 0.78"
Weight	3.84 lbs
Color	Asteroid Silver

WARRANTY AND SUPPORT

1. Warranty Information

Your HP 15 Slim laptop comes with a **1 Year Limited Warranty**. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty documentation included with your product or visit the official HP support website.

2. Customer Support

For technical assistance, driver downloads, or further information, please visit the official HP support website. You can find contact information for customer service and access a knowledge base for common issues and solutions.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DQR1T588>

More documents and user manuals: <https://manuals.plus/>