

ODK B04011801001

ODK 80x50cm LED Gaming Desk Instruction Manual

Model: B04011801001

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your ODK 80x50cm LED Gaming Desk. Please read this manual thoroughly before assembly and use to ensure proper function and safety. Keep this manual for future reference.



Image 1.1: The ODK 80x50cm LED Gaming Desk in a typical gaming environment, showcasing its integrated LED lighting and accessories.

2. SAFETY INFORMATION

To prevent injury and damage to your desk, please observe the following safety precautions:

- Ensure all components are securely fastened before use.
- Do not exceed the maximum weight capacity of the desk.
- Keep liquids away from electrical components, including the power outlet and LED controller.

- Avoid placing hot items directly on the desk surface without protection.
- Do not allow children to climb on or play with the desk.
- Use only the provided power adapter for the LED lights and power outlet.
- If any part is damaged or missing, contact customer support immediately. Do not attempt to assemble or use the desk with damaged parts.

3. PACKAGE CONTENTS

Please verify that all parts are present before beginning assembly. If any parts are missing or damaged, contact ODK customer support.

Item	Description	Quantity
Desk Top (Split-board)	Carbon fiber textured desktop with integrated LED channel.	1 Set
Z-shaped Legs	Metal frame legs for stability.	2
Power Outlet Unit	Integrated unit with 2 AC outlets and 2 USB ports.	1
LED Light Strip & Controller	Pre-installed LED strip with remote control.	1 Set
Headphone Hook	Attachable hook for headphones.	1
Cup Holder	Attachable holder for beverages.	1
Assembly Hardware	Screws, bolts, and tools required for assembly.	1 Set
Instruction Manual	This document.	1

4. SETUP AND ASSEMBLY

Follow these steps for easy assembly. It is recommended to have two people for certain steps.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all parts against the package contents list.
2. **Assemble Z-shaped Legs:** Attach the horizontal support bars to the Z-shaped leg frames using the provided hardware. Ensure all connections are secure. The double Z-design enhances stability.
3. **Attach Desk Top:** Place the split-board desk top onto the assembled leg frames. Align the pre-drilled holes and secure the desk top to the frame using the appropriate screws. The split-board design allows for monitor arm installation in the center.
4. **Install Power Outlet Unit:** Locate the designated slot on the desk top for the power outlet unit. Insert the unit and secure it according to the instructions. Connect the power cord.
5. **Connect LED Lights:** The LED light strip is pre-installed. Connect the LED controller to the light strip and the power outlet unit.
6. **Attach Accessories:** Install the headphone hook and cup holder to your preferred locations on the desk edges.
7. **Final Check:** Ensure all screws are tightened and the desk is stable before placing any equipment on it.




Image 4.1: Detail of the split-board design, which accommodates monitor arms and integrates the LED lighting.



Image 4.2: The robust Z-shaped leg structure providing enhanced stability for the desk.

5. OPERATING INSTRUCTIONS

5.1 LED Lighting System

The integrated LED lights offer customizable ambiance for your gaming or work setup. Use the included remote control to manage the lighting.

- **Power On/Off:** Press the **ON/OFF** button on the remote to turn the lights on or off.
- **Color Selection:** Use the color buttons to choose from 10 static colors.
- **Mode Selection:** Cycle through 10 dynamic lighting modes using the **MODE** button.
- **Brightness/Speed Adjustment:** Adjust the brightness of static colors or the speed of dynamic modes using the **+/-** buttons.



Image 5.1: The LED controller, showing buttons for various lighting adjustments.

5.2 Integrated Power Outlet

The desk features a built-in power outlet unit with 2 AC outlets and 2 USB ports for convenient charging and powering of your devices.

- **AC Outlets:** Plug in your computer, monitor, or other AC-powered devices (110-240V/6A).
- **USB Ports:** Connect your smartphones, tablets, or other USB-powered devices for charging (5V/2A).
- Ensure the desk's main power cord is securely plugged into a wall outlet.



Image 5.2: The integrated power strip, providing convenient access to power and USB charging.

6. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your ODK Gaming Desk.

- **Cleaning the Surface:** Wipe the carbon fiber surface with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Cleaning the Frame:** Use a dry or slightly damp cloth to clean the metal frame.
- **Electrical Components:** Ensure the power outlet and LED components are kept dry. Disconnect power before cleaning around these areas.
- **Tightening Screws:** Periodically check and tighten all assembly screws to maintain stability.

7. TROUBLESHOOTING

If you encounter any issues with your ODK Gaming Desk, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
LED lights not turning on.	Power cord not plugged in; LED controller not connected; remote battery dead.	Ensure the desk's main power cord is plugged into a live outlet. Check the connection between the LED controller and the light strip/power unit. Replace remote control battery if necessary.
Power outlets not working.	Desk's main power cord unplugged; circuit breaker tripped.	Verify the desk's main power cord is securely plugged into a functional wall outlet. Check your household circuit breaker.
Desk feels wobbly.	Loose assembly screws; uneven floor.	Tighten all assembly screws. Adjust the leveling feet (if present) on the bottom of the legs to compensate for uneven flooring.
Accessories (cup holder/headphone hook) are loose.	Not properly secured.	Ensure the accessories are correctly attached and tightened according to assembly instructions.

If the problem persists after attempting these solutions, please contact ODK customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	ODK
Model Number	B04011801001
Color	Carbon Fiber Black
Product Dimensions (L x W x H)	80 cm x 50 cm x 75 cm (approx. 31.5 x 19.7 x 29.5 inches)
Material	Carbon Fiber (top), Metal (frame)
Special Features	Integrated LED Lights, Double Z-Design, Integrated Power Outlet (2 AC, 2 USB), Headphone Hook, Cup Holder
Item Weight	7.8 Kilograms (approx. 17.2 lbs)
Power Outlet Input	110-240V/6A (AC), 5V/2A (USB)
Power Cord Length	200 cm (approx. 6.5 feet)




Image 8.1: Key dimensions of the ODK 80x50cm LED Gaming Desk.

9. WARRANTY AND SUPPORT

ODK provides a warranty for this product against defects in materials and workmanship under normal use. For specific warranty terms and conditions, please refer to the documentation included with your purchase or visit the official ODK website.

If you have any questions, require assistance with assembly, or need to report a missing/damaged part, please contact ODK customer support. Our team is available to assist you within 24 hours.

Contact Information:

Seller: ODK EU

Amazon Seller Page: [Visit ODK EU on Amazon](#)

For direct support, please use the contact methods provided on the seller's Amazon page or your purchase invoice.

© 2025 ODK. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question