

- Manuals.plus /
- › COMHOMA /
- › COMHOMA Recliner Chair User Manual

COMHOMA H7178-BR-N

COMHOMA Recliner Chair User Manual

Model: H7178-BR-N

1. IMPORTANT SAFETY INFORMATION

WARNING: Includes safety warnings regarding proper use, assembly, and potential hazards associated with the chair's features, such as maximum weight capacity, stability considerations, and safe operation of the reclining, swivel, and massage functions. Always ensure the chair is on a stable, level surface before use. Keep children and pets away from moving parts.

2. PRODUCT OVERVIEW

The COMHOMA Recliner Chair is designed for comfort and relaxation, featuring rocking, swivel, reclining, massage, and heat functions. It includes convenient cup holders and side pockets.



Figure 2.1: Front view of the COMHOMA Recliner Chair, highlighting its massage and heat zones, cup holders, and side pocket.

3. ASSEMBLY INSTRUCTIONS

The COMHOMA Recliner Chair is designed for easy assembly. While it can be assembled by one person, having two people may simplify certain steps, especially when attaching the armrests.

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all components listed in the packing list are present. The back of the chair may be vacuum-sealed; allow it to fluff up before assembly.
2. **Assemble Armrests:** The armrests require the most assembly. Ensure the metal frames within the arm pieces are fully expanded and locked into place.
3. **Connect Backrest and Seat:** Align the backrest with the seat base and slide the connecting brackets into place until they securely click.
4. **Attach Remaining Parts:** Follow the detailed instructions provided in the included manual for attaching any remaining components, such as the base and power cords for massage/heat functions.



Figure 3.1: Illustration of the main components of the recliner chair prior to assembly.

4. OPERATING INSTRUCTIONS

4.1 Reclining Function

To recline the chair, gently pull the handle located on the side of the chair. The backrest will recline, and the footrest will extend. You can adjust to various positions, from an upright sitting position to a fully laid-back position for napping.



Figure 4.1: Visual guide demonstrating the three primary reclining positions of the chair: upright, reclined for TV, and fully flat for rest.

4.2 Massage and Heat Functions

The chair features a built-in massage system with 4 massage points and 5 different modes, along with a lumbar heating function. Use the attached remote control to activate and customize these features. You can also set a timer for the duration of the massage and heat.



Figure 4.2: Overview of the massage and heat functionalities, including massage modes, massage points, lumbar heating, and timer function.

4.3 Swivel Function

The chair is equipped with a 360-degree swivel base, allowing for effortless rotation in any direction. This feature provides flexibility for engaging in conversations or adjusting your viewing angle without moving the entire chair.



Figure 4.3: The chair's 360-degree swivel capability, allowing for full rotation.

4.4 Storage Features

For added convenience, the recliner includes built-in cup holders on each armrest and side pockets. These are ideal for storing beverages, snacks, remote controls, or reading materials, keeping essentials within easy reach.



Figure 4.4: Detailed view of the chair's practical features: padded backrest, wide seat, cup holders, and side pockets.

5. MAINTENANCE AND CARE

To maintain the quality and longevity of your COMHOMA Recliner Chair, follow these simple care instructions:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the material.
- **Spills:** Blot spills immediately with a clean, dry cloth.
- **Regular Inspection:** Periodically check all bolts and connections to ensure they are tight. Re-tighten if necessary.
- **Moving Parts:** Ensure the reclining mechanism and swivel base operate smoothly. Keep the area around moving parts clear of obstructions.

6. TROUBLESHOOTING GUIDE

If you encounter any issues with your recliner chair, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Footrest does not retract/extend smoothly.	Obstruction in mechanism; misaligned parts; fabric interference.	Check for any objects or fabric caught in the mechanism. Ensure all assembly connections are secure. If the black felt lining is interfering, carefully trim the affected area.
Massage/Heat functions not working.	Power connection issue; remote control malfunction.	Ensure the power adapter is securely plugged into both the chair and a working electrical outlet. Check the remote control for any damage or loose connections.
Massage vibration is weak or non-existent.	This chair provides a vibration massage, not a kneading massage.	The massage function is designed for gentle vibration. This is normal operation.
Chair is wobbly or unstable.	Loose connections; uneven surface.	Ensure all assembly bolts are tightened. Place the chair on a flat, level surface.

If the problem persists after attempting these solutions, please contact COMHOMA customer support for further assistance.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	COMHOMA
Model Name	CHAIR (H7178-BR-N)
Color	Brown
Style	Pattern
Product Dimensions	20.07"D x 38.5"W x 37.4"H
Seat Depth	25.59 inches
Item Weight	91.5 pounds
Fill Material	Polyurethane Foam
Special Features	Reclining, Rocking, Swivel, Massage, Heat, Cup Holders, Side Pockets
Assembly Required	Yes
Product Care Instructions	Wipe Clean



Figure 7.1: Detailed dimensions of the COMHOMA Recliner Chair.

8. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please contact COMHOMA customer service. Refer to your purchase documentation or the seller's information for specific contact details.

Customer Support: For assistance, please reach out to the seller "Verona Sky" or visit the official COMHOMA store on Amazon.

© 2025 COMHOMA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DQTZCFPZ>

More documents and user manuals: <https://manuals.plus/>