

[Manuals.plus](#) /

› [Smoby](#) /

› Smoby Life Funny Slide Instruction Manual - Model 7600820405

Smoby 7600820405

Smoby Life Funny Slide Instruction Manual

Model: 7600820405

1. INTRODUCTION AND SAFETY INFORMATION

This manual provides essential information for the safe assembly, operation, and maintenance of your Smoby Life Funny Slide. Please read all instructions carefully before use and retain this manual for future reference.

Product Overview

The Smoby Life Funny Slide is a durable and fun outdoor play equipment designed for children. It features a 2-meter double-wave slide and includes a water connection for added enjoyment during warm weather. This product is made with 84% recycled plastic, reflecting a commitment to sustainable materials.



Image: The Smoby Life Funny Slide, showcasing its design and the '84% Recycled Material' emblem.

Important Safety Warnings

- **ATTENTION!** Intended for indoor or outdoor use.
- **ATTENTION!** Reserved for family use only.
- Minimum age: 24 months.
- Maximum weight capacity: 50 Kilograms.
- Adult supervision is required at all times when children are using the slide.
- Ensure the slide is placed on a soft, level surface, away from obstacles.

2. SETUP AND ASSEMBLY

Assembly of the Smoby Life Funny Slide is required. Please follow the steps below carefully. It is recommended to have two adults for assembly.

Unboxing and Component Check

Carefully remove all components from the packaging. Verify that all parts listed in the included assembly guide are present and undamaged. The main components include the slide chute, ladder sections, and support bars.



Image: The product packaging, illustrating the slide and its key features.

Assembly Steps

1. **Step 1: Assemble the Ladder Frame.** Connect the ladder side panels to the steps, ensuring they click securely into place.
2. **Step 2: Attach the Slide Chute.** Securely fasten the slide chute to the top of the ladder frame using the provided connectors. Ensure all connections are tight and stable.
3. **Step 3: Install Support Bars.** Attach any additional support bars or cross-braces as indicated in the detailed assembly instructions provided in the box.
4. **Step 4: Final Stability Check.** Before use, gently shake the assembled slide to ensure all parts are firmly connected and the structure is stable.

Placement Considerations

Choose a flat, level outdoor area for the slide. Ensure there is sufficient clear space around the slide, especially at the bottom, to allow for safe landing. The product dimensions are 2.17 meters (Length) x 0.87 meters (Width) x 1.18 meters (Height).



Image: Detailed diagram illustrating the dimensions of the assembled slide.

3. OPERATING INSTRUCTIONS

The Smoby Life Funny Slide is designed for simple and enjoyable use by children aged 2 years and older, with a maximum weight of 50 kg.

General Use

- Ensure children climb the ladder one at a time.
- Children should slide down feet first, in a seated position.
- Always supervise children to prevent misuse or accidents.



* Questo giocattolo contiene almeno l'84% di materiale riciclato

Image: A child enjoying the slide.




Image: A child at the top of the slide.



Image: Another child preparing to slide.

Water Connection Feature

For enhanced fun during warm weather, the slide is equipped with a water connection point. This allows you to attach a standard garden hose to create a waterfall effect, keeping the slide surface wet and cool.

- Locate the water connection nozzle on the underside of the slide chute.
- Securely attach a garden hose to this nozzle.
- Turn on the water supply to create a gentle stream down the slide.
- Always ensure the water flow is not too strong to avoid splashing or creating unsafe conditions.



* das Spielzeug besteht zu mindestens 84% aus Recyclingmaterial

Image: The slide in use with its water feature.



Image: Detail of the water sprinkler connection.

4. MAINTENANCE

Proper maintenance ensures the longevity and safety of your Smoby Life Funny Slide.

Cleaning

- Clean the slide regularly with mild soap and water.

- Rinse thoroughly with clean water and allow to air dry.
- Avoid using abrasive cleaners or harsh chemicals, as these can damage the plastic and its UV treatment.

UV Treatment

The slide features an anti-UV treatment to help maintain its colors and structural integrity over time, even with prolonged exposure to sunlight. Regular cleaning helps preserve this treatment.

Storage

During periods of non-use, especially in harsh weather conditions (e.g., extreme cold or heavy rain), it is recommended to store the slide indoors or cover it to protect it from the elements.

5. TROUBLESHOOTING

Here are some common issues and their potential solutions:

Issue	Possible Cause	Solution
Slide feels unstable after assembly.	Connections not fully secured; uneven ground.	Recheck all connection points to ensure they are tightly fastened. Move the slide to a completely flat and level surface.
Water feature not working or weak flow.	Hose not properly connected; water pressure too low; nozzle blockage.	Ensure the garden hose is securely attached. Check your water supply pressure. Inspect the nozzle for any debris and clear if necessary.
Minor plastic imperfections (small protruding pieces).	Manufacturing residue from molding process.	Carefully remove any small, sharp plastic edges using fine-grit sandpaper or a utility knife, ensuring a smooth finish to prevent injury.
Colors fading over time.	Prolonged exposure to intense sunlight.	While the slide has UV treatment, extreme conditions can still cause some fading. Store the slide indoors or cover it when not in use for extended periods.

6. SPECIFICATIONS

Detailed technical specifications for the Smoby Life Funny Slide:

Feature	Detail
Brand	Smoby
Model Number	7600820405
Material	Plastic (84% Recycled)

Feature	Detail
Color	Multicolor
Product Dimensions (L x W x H)	2.17 x 0.87 x 1.18 meters
Item Weight	11.5 Kilograms
Recommended Maximum Weight	50 Kilograms
Manufacturer Minimum Age	24 Months
Manufacturer Maximum Age	60 Months
Assembly Required	Yes
Included Components	Slide
Country of Origin	China

7. WARRANTY AND SPARE PARTS

Smoby provides a commitment to product quality and availability of spare parts.

- **EU Spare Parts Availability:** Spare parts for this product are available for a duration of 2 years from the date of purchase within the EU.
- For specific warranty terms and conditions, please refer to the documentation provided with your purchase or contact the retailer.

8. SUPPORT

If you encounter any issues or have questions not covered in this manual, please contact your retailer or the Smoby customer service department for assistance. Please have your model number (7600820405) and proof of purchase ready when contacting support.