

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [OnePlus](#) /

› [OnePlus Nord N30 5G User Manual](#)

OnePlus Nord N30 5G

OnePlus Nord N30 5G User Manual

Model: Nord N30 5G

[Instructions](#) [Maintenance](#) [Introduction](#) [What's in the Box](#) [Setup](#) [Operating](#)
[Troubleshooting](#) [Specifications](#) [Renewed Product Information](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides essential instructions for the proper setup, operation, and maintenance of your OnePlus Nord N30 5G smartphone. Please read this guide thoroughly before using your device to ensure optimal performance and longevity.



Image 1.1: OnePlus Nord N30 5G smartphone. This image displays the overall design of the device, highlighting its screen and camera module.

2. WHAT'S IN THE BOX

Verify that all items are present in the package:

- OnePlus Nord N30 5G Smartphone
- Power Adapter
- USB Cable

Note: Accessories may vary by region.

3. SETUP

3.1. Inserting the SIM Card

1. Locate the SIM card tray on the side of the device.
2. Insert the SIM ejector tool (not included, use a paperclip if necessary) into the small hole next to the tray to open it.
3. Place your Nano-SIM card(s) into the tray with the gold contacts facing down. The device supports a single SIM card and a microSDXC card for expandable storage.
4. Carefully push the tray back into the slot until it is flush with the phone's body.

3.2. Initial Charging and Power On

Before first use, it is recommended to fully charge the device.

1. Connect the USB cable to the power adapter and then to the phone's USB-C port.
2. Plug the power adapter into a wall outlet. The device supports 50W SUPERVOOC fast charging.
3. Once sufficiently charged, press and hold the Power button (located on the side) until the OnePlus logo appears.

3.3. Initial Device Configuration

Follow the on-screen prompts to complete the initial setup:

- Select your preferred language.
- Connect to a Wi-Fi network.
- Review and accept the terms and conditions.
- Sign in with your Google account or create a new one.
- Set up security features such as fingerprint unlock or face unlock.

4. OPERATING INSTRUCTIONS

4.1. Display and Navigation

The OnePlus Nord N30 5G features a 6.72-inch LCD display with a 120Hz refresh rate for smooth visuals. Navigate the OxygenOS interface using gestures or traditional navigation buttons.

- **Swipe Up:** Access the app drawer.
- **Swipe Down:** Access notifications and quick settings.
- **Tap:** Select items.
- **Pinch:** Zoom in or out.

4.2. Camera Usage

The device is equipped with a triple rear camera system and a front camera.

- **Main Camera:** 108 MP, f/1.7 (wide) for high-resolution photos.
- **Macro Camera:** 2 MP, f/2.4 for close-up shots.
- **Depth Camera:** 2 MP, f/2.4 for portrait mode effects.
- **Front Camera:** 16 MP, f/2.4 for selfies and video calls.

Open the Camera app and select your desired mode (Photo, Video, Portrait, Macro, etc.) from the interface. Tap the shutter button to capture images or start/stop video recording.

4.3. Storage Management

The phone comes with 128GB of internal storage. You can expand this up to 1TB using a microSDXC card inserted into the SIM tray.

- To check storage usage: Go to **Settings > Storage**.
- To move files to microSD: Use the File Manager app.

4.4. Connectivity

The device supports 5G cellular technology, Wi-Fi, and Bluetooth 5.1.

- **5G:** Ensure your SIM card and plan support 5G for faster mobile data speeds.
- **Wi-Fi:** Connect to wireless networks via **Settings > Wi-Fi**.
- **Bluetooth:** Pair with wireless headphones or other devices via **Settings > Bluetooth**.

4.5. Security Features

Secure your device using the side-mounted fingerprint sensor or face unlock.

- To set up fingerprint unlock: Go to **Settings > Security & privacy > Fingerprint unlock**.
- To set up face unlock: Go to **Settings > Security & privacy > Face unlock**.

4.6. Audio

The device features dual stereo speakers for enhanced audio experience. It also includes a 3.5 mm audio jack for wired headphones.

5. MAINTENANCE

5.1. Battery Care

The 5000mAh battery provides extended usage. To prolong battery life:

- Avoid extreme temperatures.
- Use the provided 50W SUPERVOOC charger for optimal charging speed and battery health.
- Avoid completely draining the battery frequently.

5.2. Software Updates

Keep your OxygenOS (based on Android 13) updated to ensure optimal performance, security, and access to new features.

- To check for updates: Go to **Settings > About device > OxygenOS version**.

5.3. Cleaning the Device

Use a soft, lint-free cloth to clean the screen and body of the phone. Avoid using harsh chemicals or abrasive materials.

6. TROUBLESHOOTING

This section addresses common issues you might encounter.

6.1. Device Not Powering On

- Ensure the battery is charged. Connect the device to the charger for at least 15 minutes.
- Press and hold the Power button for 10-15 seconds to force a restart.

6.2. Network Connectivity Issues

- Check if the SIM card is correctly inserted.
- Verify that mobile data is enabled in **Settings > Mobile network**.
- Restart the device.
- Contact your carrier (T-Mobile) to confirm service availability in your area.

6.3. Apps Crashing or Freezing

- Close and reopen the app.
- Clear the app's cache: **Settings > Apps > [App Name] > Storage usage > Clear cache.**
- Ensure the app and OxygenOS are updated to the latest versions.

6.4. Battery Draining Quickly

- Reduce screen brightness.
- Disable unused features like Bluetooth, GPS, or Wi-Fi when not needed.
- Check battery usage in **Settings > Battery** to identify power-hungry apps.
- Ensure background app refresh is limited for non-essential apps.

7. SPECIFICATIONS

| | |
|-------------------------|--|
| Model Name | OnePlus Nord N30 5G |
| Operating System | OxygenOS (based on Android 13) |
| Processor | Qualcomm Snapdragon 695 Octa-core |
| RAM | 8GB |
| Internal Storage | 128GB (Expandable up to 1TB via microSDXC) |
| Display | 6.72 inches LCD, 2400 x 1080 resolution, 120Hz Refresh Rate |
| Rear Camera | 108 MP (wide), 2 MP (macro), 2 MP (depth) |
| Front Camera | 16 MP |
| Battery Capacity | 5000 mAh |
| Charging | 50W SUPERVOOC Fast Charging (approx. 47 minutes for full charge) |
| Connectivity | 5G, Wi-Fi, Bluetooth 5.1, USB-C |
| Audio Jack | 3.5 mm |
| Dimensions | 6 x 4 x 4 inches |
| Weight | 10.8 ounces |
| Special Features | Dual SIM, Side-mounted Fingerprint Sensor, Face Unlock, Dual Stereo Speakers |

8. RENEWED PRODUCT INFORMATION

This OnePlus Nord N30 5G is an Amazon Renewed product. Renewed products are pre-owned and professionally inspected, tested, and cleaned to work like new. They come with generic or original accessories and packaging.

8.1. Amazon Renewed Conditions

Amazon Renewed products are categorized based on their cosmetic condition and battery life. All renewed products are fully functional and have a battery life greater than 80% of a new equivalent.

Amazon Renewed conditions

All Amazon Renewed products are fully functional, and come with generic or original accessories and packaging.

Example body scratches and dents – not actual products



Image 8.1: Amazon Renewed conditions overview. This image illustrates the criteria for Excellent, Good, and Acceptable cosmetic conditions for renewed products.




Image 8.2: Visual examples of renewed product cosmetic conditions. This image provides visual examples of what 'Excellent', 'Good', and 'Acceptable' cosmetic conditions might look like on a phone's back.

What Renewed customers are saying




Image 8.3: Customer feedback on Amazon Renewed. This image presents testimonials from customers regarding their positive experiences with Amazon Renewed products.

9. WARRANTY AND SUPPORT

9.1. Warranty Information

As an Amazon Renewed product, this device is backed by the Amazon Renewed Guarantee. Please refer to the Amazon Renewed program terms and conditions for specific warranty details and coverage. This typically includes a limited warranty for a specified period from the date of purchase, covering defects in materials and workmanship.

9.2. Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact Amazon Customer Service or refer to the official OnePlus support website for additional resources and FAQs.

- **Amazon Customer Service:** Visit amazon.com/contact-us
- **OnePlus Support:** Visit the official OnePlus support website for your region.