

[Manuals.plus](#) /

> [Iceman](#) /

> Iceman Dual-Size Ice Maker Countertop - Portable Ice Machine, Large and Small Ice Machine Maker with Self Cleaning, 9 Cubes in 7 Mins, 22lbs/24hrs, for Home, Kitchen, Office, Party, Ice Scoop Included US

Iceman RJ56-BUL-12

Iceman Dual-Size Ice Maker Countertop Instruction Manual

Model: RJ56-BUL-12 | Brand: Iceman

INTRODUCTION

Thank you for choosing the Iceman Dual-Size Ice Maker. This portable countertop ice machine is designed to provide you with fresh ice quickly and efficiently, offering both large and small ice cube options. With its self-cleaning function and compact design, it is ideal for home, kitchen, office, or party use. Please read this manual thoroughly before operating your new ice maker to ensure safe and optimal performance.

PRODUCT OVERVIEW AND COMPONENTS



The Iceman Dual-Size Ice Maker, shown with a glass of iced beverage and an ice scoop, highlighting its compact design and the bullet-shaped ice it produces.



**Fits perfectly on your counter,
deck, or patio.**

Dimensions of the Iceman Ice Maker: 11 inches high, 11.3 inches deep, and 9 inches wide, illustrating its suitability for various countertop spaces.



Quickly make large or small ice on your countertop.

The Iceman Ice Maker positioned on a countertop, ready to produce ice, with various refreshing beverages in the background.



Choose smaller or larger ice to fit your beverage of choice.

Two glasses showcasing the two available sizes of bullet ice, demonstrating the dual-size ice production capability of the machine.



Bullet-style ice keeps beverages cold longer than nugget or crushed.

A collection of various drinks and an ice bucket filled with bullet-style ice, highlighting the versatility and efficiency of the ice maker for different occasions.



Holds 1 lb of ice so you'll never run out at your barbecue or potluck again.

A close-up view of the ice maker's control panel and the ice basket filled with ice, showing the 'LARGE', 'SMALL', 'CLEAN', 'SELECT', 'START/STOP', 'ICE', 'FULL', and 'REFILL' indicators for easy operation.



Makes 9 bullet-shaped ice cubes every 7-10 minutes.

An ice scoop holding several bullet-shaped ice cubes, illustrating that the machine produces 9 cubes every 7-10 minutes.



One-touch cleaning function ensures the freshest-tasting ice possible.

An internal view of the ice maker's water reservoir with water circulating, demonstrating the one-touch cleaning function for fresh-tasting ice.

SETUP

1. **Unpacking:** Carefully remove the ice maker from its packaging. Retain packaging materials for future storage or transport.
2. **Placement:** Place the ice maker on a flat, stable surface away from direct sunlight and heat sources. Ensure there is adequate ventilation around the unit (at least 4 inches of space on all sides).
3. **Initial Cleaning:** Before first use, clean the interior of the ice maker. Fill the water reservoir with clean water and run the self-cleaning cycle (refer to the Maintenance section for details). Discard the water after the cycle.
4. **Power Connection:** Plug the ice maker into a grounded electrical outlet. Ensure the voltage matches the specifications of the unit (120 Volts).

OPERATING INSTRUCTIONS

1. **Fill Water Reservoir:** Open the lid and fill the water reservoir with potable water up to the 'MAX' fill line. Do not overfill.
2. **Select Ice Size:** Press the 'SELECT' button on the control panel to choose between 'LARGE' or 'SMALL' ice cube sizes. The corresponding indicator light will illuminate.
3. **Start Ice Production:** Press the 'START/STOP' button to begin the ice making cycle. The 'ICE' indicator light will turn on.
4. **Monitor Ice Production:** The ice maker will produce 9 bullet-shaped ice cubes approximately every 7-10 minutes.
5. **Ice Full Indicator:** When the ice basket is full, the 'FULL' indicator light will illuminate, and the ice production will automatically pause. Remove ice from the basket to resume production.
6. **Water Refill Indicator:** If the water level in the reservoir is too low, the 'REFILL' indicator light will illuminate, and the ice production will stop. Add more water to the reservoir to resume.
7. **Stop Production:** To stop ice production at any time, press the 'START/STOP' button again.

MAINTENANCE AND CLEANING

Self-Cleaning Function

The Iceman Ice Maker features a convenient one-touch self-cleaning function:

1. Ensure the ice basket is empty.
2. Fill the water reservoir with clean water up to the 'MAX' line.
3. Press and hold the 'CLEAN' button for a few seconds until the cleaning cycle begins. The 'CLEAN' indicator light will illuminate.
4. The cleaning cycle will run for several minutes, circulating water through the system.
5. Once the cycle is complete, drain the water from the unit by removing the drain plug located at the bottom or side of the unit (refer to diagram in product manual if available).
6. Rinse the interior with fresh water and drain again.

Regular Cleaning

- Wipe the exterior with a soft, damp cloth.
- Clean the ice basket and ice scoop with mild detergent and warm water. Rinse thoroughly and dry before reinserting.
- For optimal performance and hygiene, perform the self-cleaning cycle regularly, especially if the unit has not been used for an extended period.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water in reservoir; 'REFILL' light on.	Add water to the reservoir up to the 'MAX' line.
Ice maker not producing ice.	Ice basket is full; 'FULL' light on.	Remove ice from the basket.
Ice maker not producing ice.	Unit is not powered on or plugged in.	Ensure the unit is plugged into a working outlet and the 'START/STOP' button has been pressed.
Ice cubes are too small or clumpy.	Water temperature is too high.	Use colder water. Ensure the unit is in a cool environment.

Problem	Possible Cause	Solution
Unusual noise during operation.	Normal operational sounds (compressor, water pump).	This is usually normal. If the noise is excessive or new, contact customer support.
Water leakage.	Drain plug not properly sealed.	Ensure the drain plug is securely inserted.

SPECIFICATIONS

Brand	Iceman
Model Number	RJ56-BUL-12
Manufacturer	Chefman
Product Dimensions	28.7 x 22.86 x 27.94 cm (11.3 x 9 x 11 inches)
Item Weight	6.15 kg
Voltage	120 Volts
Wattage	120 watts
Ice Production Capacity	Approx. 9 cubes in 7-10 minutes; 22lbs/24hrs
Ice Storage Capacity	1 lb
Included Components	Ice Maker, Ice Scoop

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Iceman website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2025 Iceman. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question