

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [GreenLife](#) /

> [GreenLife Compact Electric Air Fryer Oven 5.3QT \(Model CC009534-001\) - Instruction Manual](#)

GreenLife CC009534-001

GreenLife Compact Electric Air Fryer Oven 5.3QT (Model CC009534-001) - Instruction Manual

Brand: GreenLife | Model: CC009534-001

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your GreenLife Compact Electric Air Fryer Oven. Please read all instructions carefully before first use and retain for future reference.

Product Overview

The GreenLife Compact Electric Air Fryer Oven, Model CC009534-001, is designed to transform your cooking experience with its advanced features and user-friendly design. Key features include:

- **PFAS-FREE HEALTHY COOKING:** Premium ceramic nonstick coating free of PFAS, PFOA, lead, and cadmium for safer, healthier meals.
- **ADVANCED AIR CRISP TECHNOLOGY:** Features rapid 360° air circulation and precise temperature control for perfectly crispy results with up to 95% less oil.
- **FAMILY-SIZED CAPACITY:** Spacious 5.3QT drawer accommodates large family meals while maintaining a compact countertop footprint.
- **VERSATILE COOKING MODES:** 8 one-touch presets for Air Fry, Fries, Roast, Bake, Fish, Steak, Veggies, and Wings, with adjustable time and temperature control.
- **SNEAK PEEK WINDOW & INTERIOR LIGHT:** Large viewing window and interior light let you monitor cooking progress without opening the drawer and losing heat.
- **PROFESSIONAL-GRADE DESIGN:** Easy-slide drawer with stay-cool handle for safe, effortless food access and temperature maintenance.
- **DISHWASHER SAFE DRAWER & TRAY:** Dishwasher-safe drawer and tray with nonstick coating make post-cooking cleanup quick and simple.

IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using the appliance.
- Do not immerse the main unit, cord, or plug in water or any other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only on a stable, heat-resistant surface. Ensure adequate clearance around all sides for proper ventilation.
- Do not block any ventilation openings.
- Do not touch hot surfaces. Use handles or knobs.
- Do not use attachments not recommended by the appliance manufacturer.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use the appliance for other than intended use.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your air fryer:

- Main Unit
- Control Panel with Digital Display
- Drawer (5.3QT capacity)
- Crisper Tray
- Stay-Cool Handle
- Sneak Peek Window
- Interior Light



Image: Front view of the GreenLife Compact Electric Air Fryer Oven, highlighting the digital display, control panel, and drawer handle.

SETUP AND FIRST USE

1. Unpack all components and remove any packaging materials.
2. Wipe the exterior of the air fryer with a damp cloth.
3. Wash the drawer and crisper tray thoroughly with warm, soapy water. Rinse and dry completely.
4. Place the air fryer on a stable, heat-resistant surface, ensuring adequate clearance around all sides for proper ventilation.
5. Insert the crisper tray into the drawer, then slide the drawer into the main unit.

6. Plug the power cord into a grounded electrical outlet.
7. Before first use, it is recommended to run the air fryer empty for about 10-15 minutes at 350°F (175°C) to eliminate any manufacturing odors. A slight odor may be present during this initial use, which is normal.

OPERATING INSTRUCTIONS

Control Panel and Digital Display

The air fryer features a crystal-clear digital display and touch controls for easy operation.

- **Power On/Off:** Press the power button to turn the unit on or off.
- **Temperature Adjustment:** Use the '+' and '-' buttons to adjust the cooking temperature.
- **Time Adjustment:** Use the '+' and '-' buttons to set the cooking time.
- **8 One-Touch Presets:** Select from pre-programmed settings for Air Fry, Fries, Roast, Bake, Fish, Steak, Veggies, and Wings.
- **Sneak Peek Window & Interior Light:** Use the interior light to monitor cooking progress through the viewing window without opening the drawer.




Image: Close-up of the digital display and touch controls, showing temperature and time settings.

Basic Operation

1. Place food in the crisper tray within the drawer. Do not overfill.
2. Slide the drawer back into the air fryer.
3. Press the power button to turn on the display.
4. Select a preset or manually set the desired temperature and time.
5. Press the start button to begin cooking.
6. The air fryer will automatically shut off when the timer expires.
7. Carefully remove the drawer using the stay-cool handle.
8. Serve food immediately.

COOKING GUIDE

The GreenLife Air Fryer uses rapid 360° air circulation for crispy results with less oil. Cooking times and temperatures may vary based on food type, quantity, and desired crispiness.

- For best results, preheat the air fryer for 3-5 minutes before adding food.
- Shake the drawer halfway through cooking for even browning, especially for smaller items like fries or wings.
- Use a cooking thermometer to ensure food reaches safe internal temperatures.
- Refer to the 8 one-touch presets for common food items as a starting point.

3 SIZES | 3.5QT • 6QT • 8QT

SLOW COOKERS

Simplify the season - from morning prep to holiday parties



Image: Air fryer displaying the 8 one-touch cooking modes: Air Fry, Fries, Roast, Bake, Fish, Steak, Veggies, and Wings.

Official Product Video: GreenLife 4.5QT Compact Digital Air Fryer Overview

Your browser does not support the video tag.

Video: An official GreenLife video demonstrating the features and compact design of the 4.5QT Digital Air Fryer, including its nonstick interior and ease of use. Note: This video features the 4.5QT model, while this manual is for the 5.3QT model, but the core features and operation are similar.

CLEANING AND MAINTENANCE

Proper cleaning ensures the longevity and optimal performance of your air fryer. Always unplug the appliance and allow it to cool completely before cleaning.

1. **Exterior:** Wipe the exterior with a damp cloth. Do not use abrasive cleaners.
2. **Drawer and Crisper Tray:** The drawer and crisper tray are dishwasher safe. Alternatively, wash them with warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry completely before reassembling.
3. **Interior:** Wipe the interior of the appliance with a damp cloth. For stubborn residue, use a mild detergent.
4. Do not immerse the main unit in water or any other liquid.

EASY TO CLEAN & DISHWASHER SAFE DRAWER & TRAY



Image: The air fryer with its drawer and crisper tray removed, emphasizing their dishwasher-safe design for easy cleaning.

TROUBLESHOOTING

If you encounter any issues with your GreenLife Air Fryer, please refer to the following common problems and solutions:

- **Appliance does not turn on:** Ensure the power cord is securely plugged into a grounded outlet. Check if the outlet is functioning.
- **Food is not crispy:** Do not overfill the drawer. Shake the food halfway through cooking. Ensure the temperature and time settings are appropriate for the food type.
- **White smoke from appliance:** This may occur if cooking fatty foods. Ensure the drawer and crisper tray are clean and free of excess oil.
- **Unusual odor during first use:** This is normal for initial use and will dissipate after a few uses. Run the air fryer empty for 10-15 minutes at 350°F (175°C) to help reduce the odor.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	GreenLife
Model Number	CC009534-001
Capacity	5.3 Quarts
Dimensions (DxWxH)	15.16"D x 12"W x 13.98"H
Weight	11 Pounds
Color	Graphite
Material	PFAS Free Ceramic Nonstick, Stay-Cool Handle
Output Wattage	1500 Watts
Control Method	Touch
Special Features	8 One-Touch Modes, Digital Display, Dishwasher Safe, Easy-Slide Drawer, PFAS-Free Nonstick Interior, Stay-Cool Handle, Timer, Sneak Peek Window, Interior Light
Air Frying Technology	Rapid 360° air circulation
UPC	885837049800

WARRANTY AND SUPPORT

For warranty information, product registration, or customer support, please refer to the documentation included with your product or visit the official GreenLife website. Keep your purchase receipt as proof of purchase.

Related Documents - CC009534-001

 <p>The image shows the cover of the instruction manual for the GreenLife Healthy Power 5-in-1 Electric Skillet. It features a photograph of the skillet and the GreenLife logo. The text on the cover includes 'HEALTHY POWER 5-IN-1 INSTRUCTION BOOKLET' and 'CUSTOMER SERVICE 1-877-633-6363'.</p>	<p>GreenLife Healthy Power 5-in-1 Electric Skillet Instruction Manual</p> <p>Comprehensive guide for the GreenLife Healthy Power 5-in-1 Electric Skillet, covering safety precautions, parts, features, operation, cooking tips, and warranty information. Learn how to use and maintain your electric skillet for healthy and delicious meals.</p>
--	---



[GreenLife Air Fry Toaster Oven Instruction Manual and Guide](#)

Comprehensive instruction manual for the GreenLife Air Fry Toaster Oven. Includes safety guidelines, operating instructions for toast, bake, air fry, and broil functions, cooking chart, cleaning tips, troubleshooting, warranty information, and terms of sale.



[GreenLife Go Grains Rice & Grains Cooker Instruction Manual](#)

Official instruction booklet for the GreenLife Go Grains Rice & Grains Cooker. Learn about important safeguards, parts, control panel operation, cleaning, troubleshooting, and warranty information.



[GreenLife 1.5-Quart Rice Cooker: Instruction Manual & User Guide](#)

Comprehensive instruction booklet for the GreenLife 1.5-Quart Rice Cooker. Learn about important safeguards, parts, operation, cleaning, warranty, and terms of sale for your GreenLife appliance.



[GreenPan XL Smoke-Less Grill & Griddle User Guide](#)

Comprehensive user guide for the GreenPan XL Smoke-Less Grill & Griddle, covering important safeguards, parts description, assembly, operation, cooking guide, cleaning, maintenance, troubleshooting, and warranty information.