

Playmobil 71848

Playmobil Castle Kitchen (Model 71848) Instruction Manual

Model: 71848

[Contents](#) [Assembly](#) [Introduction](#) [Safety Information](#) [Package](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Welcome to the world of Playmobil Princess Magic with your new Castle Kitchen playset (Model 71848). This set allows children aged 4 to 10 years to engage in imaginative role-play, creating delightful baking adventures for their princess figures. The kitchen is designed with realistic details to enhance the play experience.

This manual provides essential information for the assembly, operation, and maintenance of your Playmobil Castle Kitchen.

2. SAFETY INFORMATION

Please read and understand all safety warnings before assembly and play.

- **WARNING: CHOKING HAZARD.** Small parts. Not for children under 3 years.
- The playset is recommended for ages 4 to 10 years.
- Ensure all parts are securely assembled before play to prevent detachment and potential hazards.
- Supervise young children during play, especially with small accessories.
- This product is made from child-safe materials.

3. PACKAGE CONTENTS

The Playmobil Castle Kitchen set (Model 71848) includes the following components:

- Two princess figures
- One dog figure

- Kitchen furniture (oven, cabinet, counter)
- Cookbook
- Various baking accessories (e.g., rolling pin, cake stand, treats)
- Instruction manual



Image 1: Overview of the Playmobil Castle Kitchen playset and its main components.

4. ASSEMBLY INSTRUCTIONS

The Playmobil Castle Kitchen requires some assembly. Please follow the detailed step-by-step instructions provided in the included instruction manual (separate booklet) for proper construction.

1. Unpack all components and verify against the package contents list.
2. Refer to the assembly diagrams in the separate instruction booklet.
3. Connect parts firmly until they click into place, if applicable.
4. Ensure all small accessories are placed correctly and securely.



Image 2: Princess figures with removable aprons and a recipe book, demonstrating detailed play elements.

5. OPERATING INSTRUCTIONS (PLAYING WITH THE SET)

The Playmobil Castle Kitchen is designed for imaginative play. Here are some ways to enjoy the set:

- **Baking Adventures:** Use the oven and various accessories to pretend to bake delicious treats like macarons and muffins.
- **Role-Playing:** The two princess figures can take on different roles, following recipes from the included cookbook.
- **Pet Interaction:** The dog figure can interact with the princesses and the treats, adding a playful element to the kitchen scene.
- **Expand Play:** This set can be combined with other Playmobil Princess Magic sets (sold separately) to create a larger, more elaborate play world.



Image 3: The kitchen in action, highlighting the figures and accessories during play.

6. MAINTENANCE AND CARE

To ensure the longevity of your Playmobil Castle Kitchen, follow these care guidelines:

- **Cleaning:** Wipe the plastic parts with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the playset in a clean, dry place away from direct sunlight and extreme temperatures to prevent material degradation.
- **Inspection:** Periodically check for any loose or damaged parts. Replace or repair as necessary to maintain safe play.

7. TROUBLESHOOTING

If you encounter any issues with your Playmobil Castle Kitchen, consider the following:

- **Missing Parts:** Double-check the packaging and assembly area. If parts are genuinely missing, contact Playmobil customer support.
- **Assembly Difficulties:** Re-examine the assembly instructions provided in the separate booklet. Ensure all pieces are oriented correctly and firmly attached.
- **Damaged Parts:** Do not use the playset if any parts are broken or damaged. Contact customer support for replacement parts.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	11.18 x 7.36 x 2.91 inches
Item Weight	10.6 ounces
Item Model Number	71848
Manufacturer Recommended Age	4 - 10 years
Manufacturer	PLAYMOBIL
ASIN	B0DQVPDLMS
Release Date	August 1, 2025

9. WARRANTY AND SUPPORT

Playmobil products are manufactured to high-quality standards. For specific warranty information, please refer to the documentation included with your purchase or visit the official Playmobil website.

If you require assistance, have questions about assembly, or need replacement parts, please contact Playmobil customer support directly. Contact details can typically be found on the product packaging or the official Playmobil website.

For purchases made through Amazon, a 30-day refund/replacement return policy is generally available, as per Amazon's terms.

10. EXPAND YOUR PLAY

The Playmobil Castle Kitchen is part of the larger Playmobil Princess Magic theme. Enhance your play experience by combining this set with other complementary sets (sold separately).



Discover more playsets from **PLAYMOBIL** Princess Magic



Image 4: Discover more playsets from the Playmobil Princess Magic series.

Official Playmobil Princess Magic Video

Your browser does not support the video tag.

Video 1: A short preview video showcasing the Playmobil Princess Magic theme, including the Royal Castle. This video provides a general overview of the play world.



© 2025 Playmobil. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.