

KW02

Generic KW02 Retro Bluetooth Speaker User Manual

Model: KW02

INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation of your Generic KW02 Retro Bluetooth Speaker. Please read this manual thoroughly before using the product and retain it for future reference.



Image: Front view of the Generic KW02 Retro Bluetooth Speaker, featuring a green vinyl record design and a red 'KAWOO' tag on the side.

SAFETY INFORMATION

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Do not disassemble or attempt to repair the device yourself. Contact qualified service personnel.
- Keep the device away from water and other liquids.
- Use only the provided charging cable or a certified equivalent.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Generic KW02 Retro Bluetooth Speaker

- 1 x USB Type-C Charging Cable
- 1 x User Manual (this document)

PRODUCT OVERVIEW AND SETUP

Familiarize yourself with the speaker's components and prepare it for first use.



Image: The Generic KW02 Retro Bluetooth Speaker positioned on a wooden shelf, highlighting its vintage vinyl record player aesthetic.

Charging the Speaker

1. Connect the provided USB Type-C charging cable to the charging port on the speaker.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate during charging and turn off when fully charged.
4. A full charge typically takes approximately 2-3 hours.

OPERATING INSTRUCTIONS

Power On/Off

- To power on, press and hold the power button for a few seconds until the indicator light illuminates.
- To power off, press and hold the power button again for a few seconds until the indicator light turns off.

Bluetooth Pairing



Image: The Generic KW02 Retro Bluetooth Speaker with its central disc glowing with blue RGB light, indicating active operation or Bluetooth mode.

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicator light will flash).
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "KW02" from the list of devices.
4. Once paired, the speaker will emit a confirmation sound, and the indicator light will become solid.

Multiple Playback Functions (Bluetooth, TF Card, AUX)

Multiple Playback Functions

Four playback modes can be enjoyed, it supports Bluetooth connection/TF card/AUX input/White noise




Image: A visual representation of the Generic KW02 Retro Bluetooth Speaker's multiple playback options, including Bluetooth, TF card, AUX input, and white noise.

- **Bluetooth Mode:** After successful pairing, audio from your connected device will play through the speaker.
- **TF Card Playback:** Insert a TF (microSD) card with audio files into the designated slot. The speaker will automatically switch to TF card mode and begin playback.
- **AUX Input:** Connect an audio device using a 3.5mm AUX cable (not included) to the AUX input port. The speaker will switch to AUX mode.
- Use the mode button (if available) to cycle between Bluetooth, TF Card, and AUX input modes.

White Noise Function




Image: The Generic KW02 Retro Bluetooth Speaker generating white noise, with visual cues for various nature sounds like waves, birds, fire, and stream.

The speaker includes pre-loaded white noise sounds to aid relaxation and sleep.

- Press the dedicated white noise button (or cycle through modes) to activate the white noise function.
- Cycle through the available white noise sounds (waves, fire, song of birds, stream) using the appropriate control button.

RGB Lighting Control

RGB Colorful Light

Classic phonograph design speaker with colored night lights
three modes to choose from, with white light/breathing/RGB mode



Image: Three views of the Generic KW02 Retro Bluetooth Speaker, each demonstrating a different RGB lighting mode: blue, purple, and orange, highlighting its ambient light capabilities.

The speaker features colorful ambient lighting with multiple modes.

- Press the light mode button to cycle through different lighting effects: white light, breathing mode, and RGB mode.
- Press the button again to change the lighting effect or turn it off.

Volume Control

Adjust the volume using the dedicated volume controls on the speaker or through your connected device.

Multi-angle Adjustment

Multi-angle Adjustment



Image: The Generic KW02 Retro Bluetooth Speaker shown with its stand allowing for multi-angle adjustment, and also being held by hand, illustrating its portability.

The speaker's stand allows for multi-angle adjustment, enabling optimal sound direction. It can also be hung or handheld for portability.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker

regularly, even if not in active use.

TROUBLESHOOTING

Problem	Possible Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source using the charging cable.
Cannot pair via Bluetooth.	Ensure the speaker is in pairing mode. Make sure Bluetooth is enabled on your device. Move the speaker closer to your device. Forget "KW02" from your device's Bluetooth list and try pairing again.
No sound.	Check the volume level on both the speaker and your connected device. Ensure the correct playback mode (Bluetooth, TF Card, AUX) is selected. Verify that the audio cable is securely connected for AUX mode.
White noise not playing.	Ensure the white noise function is activated and the desired sound is selected.

SPECIFICATIONS

Feature	Detail
Model Name	KW02
Bluetooth Version	VER5.0
Bluetooth Reception Distance	≤10m (33 feet)
Speaker Output	Φ40mm 4Ω 5 Watts
Signal-to-Noise Ratio	≥75dB
Frequency Range	80Hz-20KHz
Battery	3.7V/1500mAh
Input Voltage	DC5V/1A
Charging Port	Type-C
Charge Time	Approx. 2-3 hours
Playing Time	≤6 hours (varies by volume)
Material	ABS (Acrylonitrile Butadiene Styrene)
Product Dimensions	150 x 80 x 150mm (5.9 x 3.15 x 5.9 inches)

[illegible]

Comprehensive stock list of parts for HBC Radiomatic systems from Adams International Trading, featuring a wide range of part numbers for industrial radio remote controls.