

[Manuals.plus](#) /

› [Ohniyou](#) /

› Ohniyou 46" Flush Mount Ceiling Fan with Lights User Manual

Ohniyou GLX099

Ohniyou 46" Flush Mount Ceiling Fan with Lights User Manual

Model: GLX099

[Introduction](#)

[Safety Information](#)

[Package Contents](#)

[Setup & Installation](#)

[Operating Instructions](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Support](#)

1. INTRODUCTION

Thank you for choosing the Ohniyou 46" Flush Mount Ceiling Fan with Lights. This manual provides detailed instructions for the safe installation, operation, and maintenance of your new ceiling fan. Designed for both indoor and outdoor use, this fan features a quiet DC motor, remote and app control, reversible functionality for year-round comfort, and customizable lighting with dimmable and 3-color temperature options.



Figure 1.1: Ohniyou 46-inch Flush Mount Ceiling Fan with included remote control and smartphone app interface.

2. SAFETY INFORMATION

Please read all instructions carefully before beginning installation and retain this manual for future reference.

- Ensure the power is turned off at the circuit breaker before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, and the National Electric Code. If you are unfamiliar with electrical wiring, consult a qualified electrician.
- The mounting structure must be capable of supporting the weight of the fan (approximately 4.54 kg).
- Do not operate the fan with damaged blades or housing.
- Keep hands, hair, and clothing away from moving fan blades.
- This fan is suitable for both indoor and outdoor (covered patio) use. Do not expose to direct water spray.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation. If any parts are missing or damaged, contact Ohniyou customer support.

Item	Quantity
Ceiling Fan Motor Housing with Integrated Light	1
Fan Blades (Dual-Sided: White/Wood Grain)	5
Remote Control	1
Mounting Bracket	1
Hardware Pack (Screws, Wire Nuts, etc.)	1 set
User Manual	1

4. SETUP & INSTALLATION

Follow these steps for proper installation of your Ohniyou ceiling fan. It is recommended to have two people for installation.

4.1 Pre-Installation Checklist

- Turn off power at the main circuit breaker.
- Ensure the electrical box is securely mounted and capable of supporting the fan's weight.
- Gather necessary tools: screwdriver, wire strippers, electrical tape, ladder.

4.2 Mounting the Fan

1. Attach the mounting bracket to the electrical junction box in the ceiling using the provided screws. Ensure it is firmly secured.
2. Carefully lift the fan motor assembly and hang it from the mounting bracket using the provided hook or support system, if applicable, to free your hands for wiring.




Figure 4.1: Fan dimensions and illustration of the quiet DC motor, highlighting 35dB max noise and 80% energy saving.

4.3 Electrical Wiring

1. Connect the fan's electrical wires to the household wiring according to the wiring diagram provided in the separate wiring guide (if applicable) or standard electrical practices (Live to Live, Neutral to Neutral, Ground to Ground). Use the provided wire nuts to secure connections.
2. Ensure all connections are tight and insulated with electrical tape.

4.4 Attaching Fan Blades

1. The fan includes 5 dual-sided blades with one side in white and the other in wood grain. Choose the desired finish for your room's decor.
2. Attach each fan blade to the motor housing using the screws provided. Ensure all screws are tightened securely to prevent wobbling.

4.5 Final Assembly

1. Carefully push the fan assembly up to the mounting bracket and secure it with the canopy screws.
2. Install the light cover by twisting or snapping it into place.

3. Restore power at the circuit breaker.

5. OPERATING INSTRUCTIONS

Your Ohniyou ceiling fan can be controlled via the included remote control or a smartphone application.

5.1 Remote Control Operation

The remote control provides full functionality for your fan and light. Ensure 2x AAA batteries (not included) are installed correctly.




Figure 5.1: Multifunctional Remote Control Layout and Functions.

- **Fan / Light ALL ON/OFF:** Turns both fan and light on/off simultaneously.
- **LIGHT ON/OFF:** Toggles the light on or off independently.
- **Reversible Motor (F/R):** Changes the direction of fan rotation for summer or winter mode.
- **Turn Off The Beep:** Mutes the operational sounds of the fan.
- **6 Speed Button (1-6):** Adjusts fan speed from low (1) to high (6).
 - Speed 1-2: Comfortable wind

- Speed 3-4: Natural wind
- Speed 5-6: Cool wind
- **Pairing & Fan Off:** Used for pairing the remote with the fan or turning the fan off.
- **Natural Light / Yellow Light / White Light:** Cycles through the three color temperatures (3000K, 4500K, 6000K).
- **Luminance +/-:** Adjusts the brightness of the light (dimnable from 100% to 10%).
- **Timer Setting (1H, 4H, 8H):** Sets the fan to turn off automatically after 1, 4, or 8 hours.




Figure 5.2: Customizable Lighting: Dimmable and 3-Color Temperature Options.

5.2 App Control

The Ohniyou ceiling fan can also be controlled via a dedicated smartphone application. Refer to the video provided by the seller for detailed instructions on connecting the APP.

1. Turn on your phone's Bluetooth.
2. Return to the APP interface.
3. Turn off the wall switch, wait 5 seconds, then turn it on again.
4. Click the "Pair" button within the app to connect.

5.3 Reversible DC Motor (Summer/Winter Mode)

The reversible DC motor allows you to change the direction of the fan blades for optimal air circulation throughout the year.

- **Summer Mode (Counter-clockwise):** Pushes air downwards, creating a cooling breeze. Ideal for warmer months.
- **Winter Mode (Clockwise):** Draws air upwards, circulating warm air trapped near the ceiling. Ideal for cooler months to improve heat distribution.



Figure 5.3: Summer and Winter Operation Modes.

5.4 Ultra-Quiet Operation

The fan is equipped with a quiet DC motor, operating at a low noise level of 35dB, ensuring a peaceful environment. If any operational sounds are heard, use the "Turn Off The Beep" button on the remote control.

Comfortable Sleep Quiet Ceiling Fan with Light



Figure 5.4: Quiet Operation for Comfortable Sleep.

5.5 Light Memory Function

The fan's light features a memory function, retaining your last selected color temperature and brightness settings. To activate:

1. Select your desired color temperature and brightness.
2. Keep the light on for more than 10 seconds.
3. Turn off the light using the remote or app.
4. When you turn the light back on, it will resume the previously set preferences.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish. Ensure power is off before cleaning.
- **Blade Cleaning:** Dust the fan blades regularly to maintain efficient airflow.
- **Tightening Screws:** Periodically check all screws on the fan and mounting bracket to ensure they are

tight. Loose screws can cause wobbling or noise.

- **Light Source:** The integrated LED light source is designed for long life and typically does not require replacement.

7. TROUBLESHOOTING

If you experience issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery dead.	Check circuit breaker; Verify all wire connections are secure; Replace remote control batteries.
Fan wobbles	Loose fan blades; Loose mounting bracket; Unbalanced blades.	Ensure all blade screws are tight; Verify mounting bracket is secure; Check for bent blades or use a balancing kit (not included).
Light does not work	Loose wire connection to light; Light switch off; Remote control issue.	Check light wiring connections; Ensure light is turned on via remote/app; Replace remote batteries.
Remote control not working	Dead batteries; Not paired with fan.	Replace batteries; Follow pairing instructions in Section 5.1.
Fan makes clicking noise	Loose screws; Obstruction in fan path.	Tighten all screws on blades and housing; Ensure nothing is hitting the blades. If noise persists, use the "Turn Off The Beep" function on the remote.

8. SPECIFICATIONS

Feature	Detail
Brand	Ohniyou
Model Number	GLX099
Colour	White
Product Dimensions	116.84 x 116.84 x 24 cm (46" diameter)
Item Weight	4.54 kg
Power/Wattage	26 watts
Voltage	230 Volts
Material	Acrylic, Metal, Wood
Number of Speeds	6

Feature	Detail
Noise Level	35 dB (Max)
Special Features	LED Light, Quiet Operation, Remote Controlled, Timer, Reversible, App Control
Light Color Temperature	3000K (Warm), 4500K (Natural), 6000K (Cool)
Dimmable	100%-10%
Recommended Room Size	10 ft * 10 ft - 15 ft * 15 ft
Mounting Type	Ceiling Mount (Flush)
Usage Environment	Indoor/Outdoor (Covered)

9. WARRANTY AND SUPPORT

For warranty information, technical support, or any questions regarding your Ohniyou ceiling fan, please contact the Ohniyou Store directly through your purchase platform or visit the official Ohniyou brand store online. Please have your model number (GLX099) and purchase date ready when contacting support.

Ohniyou Store: [Visit Ohniyou Store on Amazon](#)