

[Manuals.plus](#) /

› [Karl home](#) /

› Karl home Grey 6 Drawer Dresser (Model KHDR5499) Instruction Manual

Karl home KHDR5499

Karl home Grey 6 Drawer Dresser (Model KHDR5499) Instruction Manual

Your guide to assembly, operation, and care.

INTRODUCTION

Thank you for choosing the Karl home Grey 6 Drawer Dresser, Model KHDR5499. This modern bedroom chest features a sleek grey finish with rose gold handles, designed to provide ample storage and complement your living space. This manual provides detailed instructions for assembly, safe operation, maintenance, and troubleshooting to ensure long-lasting use and satisfaction.



Image: The Karl home Grey 6 Drawer Dresser, Model KHDR5499, showcasing its modern design and six drawers.

SAFETY INFORMATION

Please read and understand all safety warnings before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Always assemble and secure the product according to the provided instructions.
- Do not overload the drawers.
- Keep the product away from heat sources and moisture.
- Never move the product when it is fully loaded.
- Always supervise children when they are near the product.
- Utilize the anti-tipping device to secure the dresser to a wall, preventing accidental tipping.



Image: Close-up of the anti-tipping device, a strap designed to secure the dresser to a wall for safety.

PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

The package typically includes:

- Dresser panels (top, bottom, sides, back)
- Drawer panels (front, back, sides, bottom)
- Drawer slides/runners
- Rose gold handles
- Assembly hardware (screws, dowels, cam locks, etc.)
- Anti-tipping device kit
- Instruction manual

ASSEMBLY INSTRUCTIONS

Assembly typically requires 1-2 people and takes approximately 60-90 minutes. Follow the detailed step-by-step manual included in your package. All parts are labeled for easy identification.

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface to prevent scratches. Refer to the parts list in your manual to identify each piece.
2. **Assemble the Main Frame:** Attach the side panels to the bottom panel using the provided hardware (e.g., dowels and cam locks). Ensure all connections are secure.
3. **Install Drawer Slides:** Secure the drawer slides to the inner sides of the dresser frame using the designated screws. Ensure they are level and aligned.
4. **Attach Back Panel:** Fasten the back panel to the assembled frame. This adds stability to the dresser.
5. **Assemble Drawers:** For each drawer, attach the side panels to the front and back panels. Slide the bottom panel into the grooves. Secure the drawer slides to the sides of the assembled drawers.
6. **Attach Handles:** Secure the rose gold handles to the front of each drawer.
7. **Insert Drawers:** Carefully slide each assembled drawer into its corresponding slot in the dresser frame.
8. **Install Anti-Tipping Device:** Secure the anti-tipping device to the top rear of the dresser and to a wall stud using the provided hardware. This is a critical safety step.



Image: An exploded view diagram showing the various components of the dresser and how they fit together during assembly.



Image: A fully assembled 6-drawer dresser, ready for use.

OPERATING INSTRUCTIONS

The Karl home dresser is designed for straightforward use.

- **Opening Drawers:** Gently pull the rose gold handle on the front of each drawer to open. The durable drawer slides ensure smooth operation.
- **Closing Drawers:** Push the drawer firmly until it is fully closed and flush with the dresser frame.
- **Weight Capacity:** Avoid placing excessively heavy items in the drawers or on top of the dresser to prevent damage or tipping. Distribute weight evenly.



Image: A dresser with several drawers partially open, demonstrating the ample storage space for various items.



Image: A close-up view of an open dresser drawer, highlighting its construction and depth.

MAINTENANCE

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** Wipe the dresser surfaces with a dry cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Immediately wipe up any spills with a soft, dry cloth to prevent moisture damage.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- **Drawer Slides:** If drawers become stiff, a small amount of silicone-based lubricant can be applied to the drawer slides.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned drawer slides, loose screws, or debris in the tracks.	Check alignment of slides and tighten screws. Clean tracks of any debris. Apply silicone lubricant if needed.
Dresser feels wobbly.	Loose assembly hardware or uneven floor.	Ensure all assembly screws are tightened. Use furniture levelers or shims under the dresser feet if the floor is uneven. Confirm anti-tipping device is securely installed.
Drawer front detaches.	Loose screws connecting the drawer front to the drawer box.	Reattach the drawer front and tighten all screws securely.

SPECIFICATIONS

Feature	Detail
Brand	Karl home
Model Number	KHDR5499
Color	Grey
Material	Engineered Wood
Product Dimensions (L x D x H)	25.98"L x 13"D x 36.65"H
Number of Drawers	6
Item Weight	67.9 pounds
Mounting Type	Free Standing (with anti-tipping device for wall attachment)
Product Care Instructions	Wipe with Dry Cloth

Product Dimension:



Image: Diagram illustrating the overall dimensions of the dresser and the internal dimensions of the drawers.

OFFICIAL PRODUCT VIDEOS

Video: 5 Drawer White Dresser | Your Stable Storage Solution

Your browser does not support the video tag.

This video demonstrates the stability and storage capabilities of a similar Karl home dresser, highlighting features like durable drawer slides and the anti-tipping device. While it shows a white 5-drawer model, the construction and safety features are representative of the KHDR5499 Grey 6-Drawer Dresser.

Video: Beautiful rustic wood dressers with lots of space!

Your browser does not support the video tag.

This video showcases the spaciousness and aesthetic appeal of Karl home dressers, demonstrating how the drawers can accommodate various items. It provides a visual representation of the storage capacity and overall design quality.

WARRANTY AND SUPPORT

Karl home products are designed for quality and durability. For any questions, concerns, or assistance with your dresser, please contact Karl home customer support.

- **Returns:** This product is eligible for 30-day easy returns. Please refer to your purchase documentation for details.
- **Customer Support:** For direct assistance, please visit the [Karl home Store on Amazon](#) or contact the seller directly through your order history.

© 2026 Karl home. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question