

VCK LE-TF009A

VCK 13-inch Tower Fan User Manual

Model: LE-TF009A | Brand: VCK

	Safety Instructions	Package Contents	Setup	Operating
Instructions	Maintenance	Troubleshooting	Specifications	Warranty & Support

1. IMPORTANT SAFETY INSTRUCTIONS

Please read and save these safety instructions before using this tower fan. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always unplug the fan before cleaning or performing any maintenance.
- Do not operate the fan with a damaged cord or plug.
- Keep children and pets away from the fan during operation due to its bladeless design, which enhances safety.
- Ensure the fan is placed on a stable, level surface to prevent tipping.
- Do not insert fingers or foreign objects into any openings of the fan.
- Do not use the fan in wet or damp locations.
- This fan is for indoor use only.

Remote Control all
functions within a range
of up to 27 feet



Image Description: A VCK tower fan is shown between a baby and a cat, illustrating its safe bladeless design for households with children and pets.

2. PACKAGE CONTENTS

Verify that all items are included in your package:

- VCK 13-inch Tower Fan
- Remote Control
- User Manual (this document)

3. SETUP

The VCK 13-inch Tower Fan comes pre-assembled for immediate use. Simply follow these steps:

1. Unpack the fan and all accessories from the box.
2. Place the fan on a firm, level surface.
3. Plug the power cord into a standard 120V AC electrical outlet.

Your browser does not support the video tag.

Video Description: This video demonstrates the basic setup and initial use of the VCK Tower Fan, including plugging it in and activating its functions.

4. OPERATING INSTRUCTIONS

The VCK Tower Fan can be operated using either the touch control panel on top of the unit or the included remote control.

4.1 Control Panel Overview



Image Description: A close-up view of the VCK Tower Fan's top touch control panel, showing icons for power, speed, mode, oscillation, and timer settings.

- **Power Button** (): Turns the fan On or Off.
- **Speed Button** (): Cycles through 3 fan speeds: Low, Medium, High.
- **Mode Button** (≡): Selects between 3 modes: Normal, Natural, and Sleep.
- **Oscillation Button** (↶↷): Activates or deactivates 90° oscillation.
- **Timer Button** (): Sets the auto-off timer for 1, 2, 4, or 7 hours.

4.2 Remote Control



Image Description: A hand holding the VCK Tower Fan remote control, with the fan visible in the background. The remote allows control of all fan functions from a distance.

The remote control duplicates all functions available on the touch control panel, allowing convenient operation from a distance of up to 27 feet.

4.3 Fan Modes Explained

- **Normal Mode:** Provides a constant airflow at the selected speed.
- **Natural Mode:** Simulates natural breeze by cycling through different fan speeds.
- **Sleep Mode:** Operates at a lower noise level and gradually decreases fan speed over time to provide a comfortable sleeping environment. The display lights dim automatically.



Image Description: A VCK tower fan operating quietly next to a bed where a child is sleeping, highlighting its whisper-quiet sleep mode feature.

5. MAINTENANCE

Regular cleaning ensures optimal performance and longevity of your VCK Tower Fan.

1. **Cleaning the Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
2. **Cleaning the Air Inlet/Outlet:** Use a vacuum cleaner with a brush attachment to gently remove dust from the air inlet and outlet grilles.
3. **Internal Cleaning:** For deeper cleaning, the back plate can be unscrewed to access and dust the internal components. Ensure the fan is unplugged before attempting internal cleaning.

6. TROUBLESHOOTING

If you encounter issues with your VCK Tower Fan, refer to the following common solutions:

Problem	Solution
Fan does not turn on.	Ensure the power cord is securely plugged into a working electrical outlet. Check if the power button is pressed.
Weak airflow.	Increase the fan speed setting. Clean the air inlet and outlet grilles to remove any obstructions.
Fan is noisy.	Ensure the fan is on a stable, level surface. Check for any foreign objects inside the fan. If in Natural mode, the speed will vary, causing sound changes.
Remote control not working.	Ensure there are no obstructions between the remote and the fan. Check and replace the remote control battery if necessary.

7. SPECIFICATIONS

Feature	Detail
Brand	VCK
Model Name	LE-TF009A
Product Dimensions	5"D x 6"W x 13"H
Item Weight	3 Pounds
Electric Fan Design	Floor Fan / Tower Fan
Power Source	Corded Electric
Wattage	30 watts
Speed Settings	3 (Low, Medium, High)
Wind Modes	3 (Normal, Natural, Sleep)
Oscillation	90°
Timer	1-7 Hours
Control Method	Remote, Touch
Special Feature	Oscillating, Portable, Remote Controlled, Bladeless
Indoor/Outdoor Usage	Indoor

Upgraded Powerful Motor

Long-distance cooling and accelerated air circulation

AC 120V/60Hz 30W



Image Description: A VCK 13-inch Tower Fan in black, shown with its remote control, highlighting its compact design and airflow.



Image Description: An image illustrating the compact dimensions of the VCK Tower Fan, showing its height of 12.9 inches and width of 4.4 inches.

8. WARRANTY & SUPPORT

For warranty information or product support, please contact VCK customer service through the retailer where the product was purchased or visit the official VCK website.
Please retain your proof of purchase for any warranty claims.

© 2025 VCK. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DQXSTKDG>

More documents and user manuals: <https://manuals.plus/>