

[Manuals.plus](#) /

> [Wekily](#) /

> Wekily S50 Wireless Earbuds User Manual

Wekily S50

Wekily S50 Wireless Earbuds User Manual

Model: S50
Brand: Wekily

1. INTRODUCTION

Thank you for choosing the Wekily S50 Wireless Earbuds. These earbuds are designed to provide a superior audio experience with powerful bass and clear calls, featuring advanced Bluetooth 5.3 technology, an LED power display, and a comfortable, waterproof design. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

2. PACKAGE CONTENTS

Please check the package contents to ensure all items are present:

- Earbuds (2)
- Charging case (1)
- Mini USB Type-C charging cable (1)
- Ear Caps (6 - S/M/L sizes)
- User Manual (1)



Figure 2.1: Contents of the Wekily S50 Earbuds package, including the earbuds, charging case, USB-C cable, various ear tip sizes, and the user manual.

3. PRODUCT OVERVIEW

The Wekily S50 earbuds feature a sleek design with intuitive controls and a portable charging case. Understanding the components will enhance your user experience.



Figure 3.1: The Wekily S50 Wireless Earbuds and their charging case, highlighting the digital LED power display.

3.1 Earbud Components

- **Touch Control Area:** Located on the outer surface of each earbud for managing playback, calls, and voice assistant.
- **Microphone:** Integrated for calls and voice commands, featuring ENC noise cancellation.
- **Ear Tip:** Soft silicone tips for comfortable fit and sound isolation.
- **Charging Contacts:** Located on the stem, for charging when placed in the case.

3.2 Charging Case Components

- **LED Digital Display:** Shows the battery percentage of the charging case and individual earbud charge levels (L/R).

- **Charging Port:** USB Type-C port for recharging the case.
- **Earbud Charging Slots:** Securely holds and charges the earbuds.

Digital Power Display

Dual digital display to show the power of the charging case and earbuds



Figure 3.2: The digital power display on the charging case, indicating battery levels for both the case and individual earbuds.

4. SETUP

4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated in their respective slots.
2. Connect the provided USB Type-C cable to the charging port on the case and the other end to a USB power adapter (not included) or a computer's USB port.
3. The LED digital display on the case will show the charging progress. A full charge for the case typically takes about 1 hour. Earbuds charge quickly, providing up to 1 hour of playback with just 10 minutes of charging.
4. Once fully charged, the display will show "100" for the case, and the earbud indicators will be full.

48H Long Battery Life

8 Hrs 

48 Hrs 

1Hrs 
Fast Charging



Figure 4.1: Charging the Wekily S50 earbuds and case, illustrating battery life and fast charging capabilities.

4.2 Powering On/Off

- **Power On:** The earbuds automatically power on when removed from the charging case.
- **Power Off:** The earbuds automatically power off and begin charging when placed back into the charging case and the lid is closed.

4.3 Pairing with a Device

The S50 earbuds utilize Bluetooth 5.3 for a stable and efficient connection.

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "S50" from the list of discovered devices.
5. Once connected, your device will confirm the pairing. The earbuds are now ready for use.

After the initial pairing, the earbuds will automatically connect to your device when removed from the case, provided Bluetooth is

enabled on your device.

ENC Noise Cancelling Mic for Clear Calls

Built-in mic noise cancellation
cuts noise by up to 90%




Figure 4.2: One-step pairing process for the Wekily S50 earbuds with a mobile device.

5. OPERATING INSTRUCTIONS

5.1 Wearing the Earbuds

For optimal sound quality and comfort, choose the ear tips that best fit your ears (S, M, L provided). Insert the earbuds gently into your ear canal and rotate them slightly until they feel secure and comfortable.

Ergonomic design

Different size eartips & in-ear design make you more comfortable and fit



Figure 5.1: Proper ergonomic fit and available ear tip sizes for the Wekily S50 earbuds.

5.2 Touch Controls

The S50 earbuds feature smart touch controls on each earbud. The functions are as follows:

Action	Function
Click R/L	Play/Pause music; Answer/End call
Long press 2s L	Previous Song
Long press 2s R	Next Song
Long press 2s R/L	Reject Call
Quick Triple Tap R/L	Activate Voice Assistant (Siri, Google Assistant, etc.)



Figure 5.2: Overview of smart touch controls on the Wekily S50 earbuds.

5.3 Making and Receiving Calls

The earbuds are equipped with an ENC (Environmental Noise Cancellation) microphone to ensure clear voice transmission during calls, reducing ambient noise by up to 90%.

- **Answer Call:** Click either earbud once.
- **End Call:** Click either earbud once during a call.
- **Reject Call:** Long press either earbud for 2 seconds.

One-Step Pairing

Taking out the headphones, the earbuds are automatically switched on and paired.



Open //
Quick Connect



Close //
Automatic disconnection
and charging




Figure 5.3: ENC Noise Cancelling Microphone for clear calls.

5.4 Music Playback

The S50 earbuds deliver Hi-Fi stereo sound quality with 14.2mm dynamic drivers, providing powerful bass and clear mids for an immersive listening experience.

Hi-Fi Stereo Sound Quality

14.2 mm dynamic speakers for more natural sound quality



14.2MM Drivers



ENC Noise Cancelling



HD Call

Figure 5.4: Internal structure highlighting Hi-Fi Stereo Sound Quality components.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Wekily S50 earbuds.

- **Cleaning:** Regularly clean the earbuds, especially the ear tips and charging contacts, with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Water Resistance:** The earbuds feature an IPX7 waterproof rating, making them resistant to splashes, rain, and sweat. They are not designed for swimming or submersion in water. Ensure they are dry before placing them back in the charging case.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.



Producer Name : Shenzhen Guanghong Times Technology Co.LTD
Address : Floor2, Building 3, Zhifeng Industrial Park, No. 68 Shahe Road,
Longgang District, Shenzhen,518000 China
Name : fuying li
Phone : +86-18123845677

Figure 6.1: IPX7 Waterproof rating for the Wekily S50 earbuds.

7. TROUBLESHOOTING

If you encounter any issues with your Wekily S50 earbuds, please refer to the following common problems and solutions:

- **Earbuds not pairing with device:**

- Ensure Bluetooth is enabled on your device.
- Make sure the earbuds are charged and removed from the case.
- Forget "S50" from your device's Bluetooth list and try pairing again.
- Restart your device and the earbuds (by placing them back in the case and taking them out).

- **Only one earbud working:**

- Ensure both earbuds are charged.
- Place both earbuds back into the charging case, close the lid for a few seconds, then open it and take them out simultaneously. This should re-sync them.
- If the issue persists, try resetting the earbuds (refer to manufacturer's website for specific reset instructions if not covered here).

- **No sound or low volume:**

- Check the volume level on both your device and the earbuds.
- Ensure the earbuds are properly connected to your device.
- Clean any debris from the earbud speakers and ear tips.

- **Charging case not charging:**

- Verify the USB-C cable is securely connected to both the case and the power source.
- Try a different USB-C cable or power adapter.
- Ensure the power source is active.

8. SPECIFICATIONS

Key technical specifications for the Wekily S50 Wireless Earbuds:

Feature	Detail
Model Name	S50
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Bluetooth Range	15 Meters
Audio Driver Size	14.2 Millimeters
Battery Life (Earbuds)	6-8 Hours (single charge)
Battery Life (with Charging Case)	Up to 48 Hours
Charging Time (Earbuds)	10 minutes for 1 hour playback
Charging Time (Case)	Approx. 1 Hour
Charging Port	USB Type-C
Water Resistance Level	IPX7 (Waterproof)
Noise Control	Passive Noise Cancellation (ENC Mic for calls)
Control Type	Touch Control

Feature	Detail
Item Weight (single earbud)	4 Grams
Charging Case Weight	30 Grams
Manufacturer	Wekily

9. WARRANTY AND SUPPORT

Wekily products are manufactured with high-quality standards. For any warranty claims or technical support, please refer to the purchase platform or contact the seller directly. Keep your proof of purchase for warranty validation.