

[Manuals.plus](#) /

› [JOYBOS](#) /

› JOYBOS 360° Spin Mop and Bucket Set User Manual

## JOYBOS JBS-XZTB-S1F1-JWT4P

# JOYBOS 360° Spin Mop and Bucket Set User Manual

Model: JBS-XZTB-S1F1-JWT4P

Brand: JOYBOS

[Introduction](#)

[Setup](#)

[Operation](#)

[Maintenance  
Warranty &  
Support](#)

[Troubleshooting](#)

[Specifications](#)

## 1. INTRODUCTION

---

This manual provides instructions for the JOYBOS 360° Spin Mop and Bucket Set, designed for efficient floor cleaning. This system features a unique clean and dirty water separation mechanism, ensuring that only clean water is used for mopping. The set includes a round spin mop and four thick, machine-washable mop pads.



**Figure 1.1:** The JOYBOS 360° Spin Mop and Bucket Set, including the mop, bucket, and four replacement mop pads.

Key features include a 360° swivel mop head for reaching difficult areas, a square mop-head design for corner access, and a convenient water inlet for easy refilling. The microfiber mop pads are suitable for both dry and wet cleaning, effectively removing dirt, dust, and hair from various floor surfaces.

## 2. SETUP

---


Follow these steps to assemble your JOYBOS Spin Mop and Bucket Set:

1. **Unpack Components:** Carefully remove all components from the packaging. Ensure you have the mop handle sections, mop head, bucket, and mop pads.
2. **Assemble Mop Handle:** Connect the stainless steel handle sections by twisting them together until secure. The handle features a knob for length adjustment.



**Figure 2.1:** Close-up of the handle lock mechanism for adjusting mop handle length.

3. **Attach Mop Head:** Align the mop head with the bottom of the assembled handle and press firmly until it clicks into place.
4. **Attach Mop Pad:** Place a microfiber mop pad flat on the floor. Align the mop head directly over the pad and press down firmly. The mop pad will securely attach to the mop head via hook-and-loop fasteners.



**Figure 2.2:** The microfiber mop pad securely attached to the mop head.

5. **Fill Bucket with Water:** Open the water inlet on the bucket (typically an orange cap). Fill the inner compartment with clean water. Do not overfill.



**Figure 2.3:** The convenient water inlet for refilling the bucket.

### 3. OPERATING INSTRUCTIONS

---


The JOYBOS Spin Mop system is designed for efficient and hygienic cleaning:

1. **Wet the Mop Pad:** Insert the mop head into the clean water section of the bucket. Push the mop handle down repeatedly to activate the spinning mechanism, which wets and cleans the mop pad with fresh water.



**Figure 3.1:** Illustration of the clean water (clearwater) and dirty water (sewage area) separation system within the bucket.

2. **Spin Dry the Mop Pad:** Lift the mop head slightly and place it into the spinning basket. Push the mop handle down repeatedly to spin the mop pad dry to your desired dampness. The centrifugal dehydration process removes excess water in approximately 5 seconds.



**Figure 3.2:** The centrifugal dehydration mechanism quickly dries the mop pad.

3. **Mopping:** Mop your floors as usual. The 360° swivel head allows for easy maneuverability around furniture and into corners. The square mop-head design is particularly effective for cleaning deep into corners.
4. **Rinse and Repeat:** After mopping an area, re-insert the mop head into the clean water section of the bucket to rinse, then spin dry before continuing to mop. The system ensures that the mop pad is always cleaned with fresh water.

The mop is suitable for various floor types, including hardwood, marble, and glass, and can effectively clean spills like oil, hair, and general wet dirt without causing damage.



Figure 3.3: The JOYBOS mop is effective on various surfaces and for different types of messes.

#### Video Demonstration (If available)

*Note: No relevant product operation videos from the seller were provided in the product data. Please refer to the written instructions and diagrams for guidance.*

## 4. MAINTENANCE

---

Proper maintenance ensures the longevity and effectiveness of your JOYBOS Spin Mop and Bucket Set:

- **Cleaning Mop Pads:** The microfiber mop pads are machine washable. Remove them from the mop head after use and wash with similar colors. Do not use bleach or fabric softener. Air dry for best results.
- **Cleaning the Bucket:** After each use, empty the dirty water from the outer sewage area. Rinse the bucket thoroughly with clean water. Periodically, you may use a mild detergent to clean the interior of the bucket and the spinning mechanism.
- **Storage:** Store the mop and bucket in a dry place. The mop handle can be adjusted and the mop head can be positioned at a 90-degree angle for compact storage, saving space.



Figure 4.1: The mop handle can be angled for convenient storage in tight spaces.

## 5. TROUBLESHOOTING

If you encounter any issues with your JOYBOS Spin Mop and Bucket Set, refer to the following common problems and solutions:

| Problem                           | Possible Cause                                                              | Solution                                                                                                                                                                     |
|-----------------------------------|-----------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Mop pad not spinning effectively. | Insufficient force applied to the handle; mechanism jammed; too much water. | Ensure the mop head is properly seated in the spinning basket. Apply firm, consistent downward pressure on the handle. Check for any obstructions in the spinning mechanism. |
| Mop pad not attaching securely.   | Hook-and-loop fasteners are dirty or worn; mop pad not aligned correctly.   | Clean any debris from the hook-and-loop fasteners on both the mop head and pad. Ensure the pad is centered before pressing down. Replace worn pads if necessary.             |
| Water not separating properly.    | Bucket overfilled; internal components obstructed.                          | Do not overfill the clean water compartment. Ensure no large debris is blocking the internal water flow channels.                                                            |
| Mop handle feels loose.           | Handle sections not fully tightened.                                        | Twist the handle sections firmly until they are securely connected. Ensure the adjustment knob is tightened.                                                                 |

## 6. SPECIFICATIONS

Detailed specifications for the JOYBOS 360° Spin Mop and Bucket Set:

- **Model Number:** JBS-XZTB-S1F1-JWT4P
- **Brand:** JOYBOS
- **Special Feature:** 360° Spin, Clean and Dirty Water Separation
- **Included Components:** Mop, Bucket, 4 Microfiber Mop Pads
- **Material:** Plastic, Stainless Steel (Handle)
- **Handle Material:** Stainless Steel
- **Handle Type:** Knob (for adjustment)
- **Head Material:** Plastic
- **Color:** White



**Figure 6.1:** Approximate dimensions of the mop and bucket. Mop handle length: 50.0" (127cm), Mop head diameter: 9.1" (23cm), Bucket dimensions: 12.6" (35cm) width, 7.1" (18cm) height.



**Figure 6.2:** Internal structure highlighting key components: Powerful Flushing, Cleaning Brush, Stainless Steel handle, Hidden Handle, and Microfiber Mop Pad.

## 7. WARRANTY AND SUPPORT

For warranty information or product support, please contact JOYBOS customer service. Keep your purchase receipt as proof of purchase.

You can find more information about JOYBOS products and contact details by visiting the official JOYBOS store: [JOYBOS Store on Amazon](#).

© 2025 JOYBOS. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**