Csasan T70

Csasan Smart Watch T70 User Manual

Model: T70

1. Product Overview

The Csasan Smart Watch T70 is a versatile wearable device designed to monitor your health, track fitness activities, and keep you connected. It features a 1.91-inch HD touch screen, Bluetooth calling functionality, and compatibility with both Android and iOS devices.



Image: Csasan Smart Watch T70 in purple, showing the main display with time and activity metrics.

2. What's in the Box

- Csasan Smart Watch T70 (1 unit)
- Magnetic Charging Cable (1 unit)
- User Manual (1 unit)

3. Setup Guide

3.1 Charging the Device

Before first use, fully charge your smart watch. Connect the magnetic charging cable to the charging points on the back of the watch and plug the USB end into a power adapter (not included) or a computer's USB port. A full charge typically takes approximately 2 hours.



Image: The Csasan Smart Watch T70 being charged via its magnetic charging cable, with icons indicating battery life.

3.2 App Installation and Pairing

1. Download the **"Gloryfit"** app from your smartphone's app store (compatible with Android 5.0+ and iOS 9.0+).
2. Ensure Bluetooth is enabled on your smartphone.
3. Open the Gloryfit app and follow the on-screen instructions to create an account and set up your profile.
4. In the app, navigate to the device pairing section and select your Csasan T70 Smart Watch from the list of available devices.
5. Confirm the pairing request on both your watch and smartphone.

3.3 Customizing Watch Faces

The watch features a 1.91-inch HD full touch display. You can customize your watch face through the Gloryfit app. Select from over 100 watch faces or upload a personal photo to personalize your device.




Image: Various digital watch faces shown on the Csasan Smart Watch T70, highlighting customization options within the Gloryfit app.

4. Operating Instructions

4.1 Basic Navigation

- **Touch Screen:** Swipe left, right, up, or down to navigate through menus and features. Tap to select.
- **Side Button:** Press to return to the home screen or wake the display.
- **Raise to Wake:** The screen will automatically light up when you raise your wrist.

4.2 Bluetooth Calling and Notifications

Once paired, the watch allows you to answer and make calls directly from your wrist. It also displays notifications from various apps (e.g., Instagram, YouTube, Messenger, Gmail, Snapchat, Facebook, Twitter, WhatsApp). *Note: The smart watch cannot be used to reply to messages.*

- **Answering Calls:** When a call comes in, tap the green icon on the watch screen.
- **Making Calls:** Access the dialer or contact list through the watch interface to initiate a call.

- **Notifications:** Swipe down from the top of the watch face to view recent notifications.

4.3 Health Monitoring

The Csasan T70 Smart Watch includes built-in sensors for continuous health tracking.

- **Heart Rate Monitor:** The watch continuously monitors your heart rate. View real-time data on the watch or detailed historical data in the Gloryfit app.
- **Sleep Tracker:** Automatically records your sleep patterns, including awake, light, and deep sleep stages. Access sleep data in the Gloryfit app to help adjust your sleep habits.
- **Step Counter:** Tracks your daily steps, distance, and calories burned.



Image: The Csasan Smart Watch T70 showing heart rate and sleep tracking features, alongside the Gloryfit app interface displaying detailed health metrics.

Disclaimer: The health data provided by this device is for reference purposes only and should not be used for medical diagnosis or treatment.

4.4 Sports Modes

The watch offers over 110 sports modes, including running, cycling, and swimming. Select your activity to accurately record data such as duration, distance, calories, and heart rate during your workout.



Image: People participating in different sports, illustrating the watch's 110+ sports modes and real-time activity monitoring.

4.5 Additional Functions

The Csasan T70 Smart Watch includes several other useful features:

- Weather Forecast
- Music Control
- Sedentary Reminder
- Stopwatch
- Alarm Clock
- Timer
- Female Cycle Tracking
- Find Phone

5. Maintenance and Care

- **Cleaning:** Wipe the watch and band regularly with a soft, dry cloth. If necessary, use a slightly damp cloth and dry thoroughly.
- **Water Resistance:** The watch is IP68 waterproof, suitable for daily activities like washing hands or exercising in the rain. *Do not use the watch in hot water, saunas, or for prolonged submersion, as this may affect its waterproof integrity.*
- **Storage:** Store the watch in a cool, dry place when not in use.

6. Troubleshooting

- **Watch not turning on:** Ensure the watch is fully charged. Connect it to the magnetic charger and allow it to charge for at least 30 minutes before attempting to power it on.
- **Cannot pair with phone:**
  - Ensure Bluetooth is enabled on your phone.
  - Make sure the watch is within Bluetooth range of your phone.
  - Restart both the watch and your phone.
  - Check if the Gloryfit app is updated to the latest version.
- **Inaccurate health data:** Ensure the watch is worn snugly on your wrist, not too tight or too loose. Clean the sensor on the back of the watch. Remember that health data is for reference only.
- **Notifications not received:** Check app permissions in your phone settings to ensure the Gloryfit app has access to notifications. Verify that notification settings are enabled within the Gloryfit app.

7. Specifications

Model Number	T70
Brand	Csasan
Screen Size	1.91 inches
Display Type	LCD or OLED
Operating System	Wear OS
Connectivity Technology	Bluetooth
Water Resistance Level	IP68 Waterproof (1.5 meters depth)
Battery Type	Lithium Polymer
Average Battery Life	7 days
Charging Time	Approx. 2 hours
Compatible Devices	Android 5.0+ and iOS 9.0+ Smartphones
Metrics Measured	Heart Rate, Sleep Duration, Steps, Calories, Distance
Material	Silicone (Band)
Item Weight	90 g

8. Warranty and Support

For product support, technical assistance, or warranty inquiries, please contact Csasan customer service. Refer to the packaging or official website for the most current contact information.

Manufacturer Contact Information: +8616261135043

Additional functions and updates can be explored through the**"Gloryfit"** application.

© 2026 Csasan. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question