

COBI 2629

COBI Armed Forces 2629 KTO Rosomak 2in1 PL Instruction Manual

Model: 2629

INTRODUCTION

This instruction manual provides essential information for the assembly, operation, and maintenance of your COBI Armed Forces 2629 KTO Rosomak 2in1 PL building set. Please read these instructions carefully before beginning assembly to ensure a correct and enjoyable building experience. This model allows for customization with either Polish or Ukrainian insignia.

ASSEMBLY INSTRUCTIONS

The COBI Armed Forces 2629 KTO Rosomak 2in1 PL set includes detailed, step-by-step illustrated assembly instructions within the product packaging. Please refer to these printed instructions for the complete building process. The following images highlight key features and assembly aspects of the model.



Figure 1: Product packaging displaying the COBI KTO Rosomak 2in1 PL model and its features.



Figure 2: The fully assembled COBI KTO Rosomak 2in1 PL model.



Figure 3: The 2-in-1 feature allows for the application of either Ukrainian or Polish insignia.

Follow the numbered steps in the included manual to connect all building blocks securely. Ensure all pieces are firmly pressed together to prevent the model from becoming unstable.

OPERATING THE MODEL

Once assembled, your COBI KTO Rosomak model features several interactive elements for display and play.

- **Turret Rotation:** The main turret can be rotated 360 degrees.




Figure 4: The turret can be rotated for dynamic posing.

- **Gun Elevation:** The main gun can be moved up and down.

- **Steering Function:** The front wheels are designed to turn, simulating steering.



Figure 5: The front wheels can be steered left and right.

- **Opening Hatches:** Certain sections, such as the engine compartment, can be opened to reveal interior details.




Figure 6: An opening hatch reveals the detailed engine compartment.

- **Multiple Movable Parts:** The model features various other movable elements, enhancing its realism and playability.



Figure 7: Overview of the model highlighting its various movable components.

MAINTENANCE

To ensure the longevity and appearance of your COBI building set, follow these simple maintenance guidelines:

- **Cleaning:** Dust the model regularly with a soft, dry cloth or a soft brush. For more thorough cleaning, gently wipe with a damp cloth and mild soap, then dry immediately. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the model in a cool, dry place away from direct sunlight to prevent discoloration and material degradation.
- **Handling:** Handle the model with care to avoid accidental disassembly or damage to delicate parts.

TROUBLESHOOTING

If you encounter any issues during or after assembly, consider the following:

- **Missing Parts:** If you find any parts missing from your set, please contact COBI customer support with your product model number and a description of the missing pieces.
- **Loose Connections:** If parts of the model feel loose, re-examine the assembly steps in the manual to ensure all blocks are correctly and firmly connected.
- **Difficulty with Movement:** If movable parts (turret, wheels, hatches) are stiff, ensure no blocks are obstructing their movement and that they are assembled according to the instructions. Do not force movement.

SPECIFICATIONS

Feature	Detail
Brand	COBI

Model Number	2629
Material Type	Plastic
Theme	Military
Educational Objective	Construction Skills
Number of Players	1-3
Item Dimensions (L x W x H)	22.5 cm x 10 cm x 13.5 cm (8.86 x 3.94 x 5.31 inches)
Item Weight	1.55 Kilograms




Figure 8: Dimensions of the assembled KTO Rosomak model.

WARRANTY AND SUPPORT

For information regarding product warranty or to obtain support for missing parts or assembly issues, please refer to the contact information provided on the COBI product packaging or visit the official COBI website. Keep your purchase receipt as proof of purchase.

Official COBI Store: [COBI Store on Amazon](#)