

[Manuals.plus](#) /

› [DERCASS](#) /

› DERCASS Wood Platform Bed with Storage Headboard and Drawers, Full Size, White - Instruction Manual

DERCASS GX002054AA

DERCASS Wood Platform Bed with Storage Headboard and Drawers, Full Size, White - Instruction Manual

Model: GX002054AA

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your DERCASS Wood Platform Bed with Storage Headboard and Drawers. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: Fully assembled DERCASS Wood Platform Bed in white, featuring a storage headboard with shelves and two under-bed drawers.

SAFETY INFORMATION

- Always assemble the bed on a soft, clean surface to prevent damage.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not allow children to climb on the bed frame or headboard during assembly.
- Keep small parts out of reach of children to avoid choking hazards.
- Use only the recommended mattress thickness (6-8 inches) to ensure proper fit and safety.
- Do not exceed the bed's weight capacity of 400 lbs.

PACKAGE CONTENTS

Before assembly, verify that all components are present. Refer to the detailed assembly instruction guide included in your package for a complete list of parts and hardware.

- Platform Bed Frame components
- Storage Headboard components
- Slats
- Two Drawers
- Assembly hardware and tools

SETUP AND ASSEMBLY

Assembly is required for this product. Please follow the step-by-step instructions provided in the separate assembly guide included with your purchase. All necessary tools are provided.

Key Assembly Steps Overview:

1. Unpack all components and verify against the parts list.
2. Assemble the main bed frame structure.
3. Attach the storage headboard sections.
4. Install the wooden slats onto the bed frame.
5. Assemble and insert the two under-bed drawers.



Image: View of the bed frame during assembly, highlighting the slat support system and the headboard structure.



Image: Another view of the bed frame during assembly, focusing on the headboard's shelf design.




Image: Detail of the upholstered headboard and the rotatable storage board mechanism.

OPERATING INSTRUCTIONS

Storage Headboard:

The headboard features integrated shelves and a box for storing various items such as books, decor, or personal belongings. The 29.5" x 8.7" rotatable storage board can be adjusted to hold a phone or tablet for viewing.



Image: The storage headboard with shelves and the rotatable board in use.

Under-Bed Drawers:

Two drawers are located under the bed for additional storage. These can be pulled out smoothly to store bedding, toys, or other bedroom essentials.



Image: An open under-bed drawer, illustrating its storage capacity.

MAINTENANCE

- **Cleaning:** Wipe the bed frame and headboard surfaces with a dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Hardware Check:** Periodically check all bolts, screws, and connections to ensure they remain tight. Re-tighten as needed to maintain stability and prevent squeaking.
- **Slat Care:** Ensure slats are properly seated and not damaged. Replace any broken slats immediately to maintain mattress support.

TROUBLESHOOTING

- **Squeaking Noises:**
Solution: Check all bolts and screws for tightness. Re-tighten any loose connections. Ensure the mattress is properly seated on the slats.
- **Drawers Not Sliding Smoothly:**
Solution: Inspect the drawer runners for any obstructions or damage. Ensure the drawers are assembled correctly and aligned with the tracks.
- **Bed Feels Unstable:**
Solution: Verify that all structural components are correctly assembled and all hardware is fully tightened. Ensure the bed is on a level surface.

SPECIFICATIONS

Feature	Detail
Brand	DERCASS
Model Number	GX002054AA

Image: Dimensional drawing of the bed, indicating all key measurements.

WARRANTY AND SUPPORT

Specific warranty details are not provided in this manual. For any questions regarding your product, assembly, or if you encounter any issues, please contact DERCASS customer support immediately. Refer to your purchase documentation for contact information.

© 2024 DERCASS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question