

[Manuals.plus](#) /

› [ALLIANCE LAUNDRY SYSTEMS](#) /

› ALLIANCE LAUNDRY SYSTEMS Assy Service Door Packaged (35798WP) Instruction Manual

ALLIANCE LAUNDRY SYSTEMS 35798WP

ALLIANCE LAUNDRY SYSTEMS Assy Service Door Packaged (35798WP) Instruction Manual

Model: 35798WP

1. INTRODUCTION

This instruction manual provides essential information for the proper installation, operation, and maintenance of your ALLIANCE LAUNDRY SYSTEMS Assy Service Door Packaged, model 35798WP. This genuine OEM part is designed for use with Huebsch, Speed Queen, and Econo-Wash washer/dryer units. Please read this manual thoroughly before installation to ensure correct usage and to prevent damage.

2. SAFETY INFORMATION

Always prioritize safety during installation and maintenance. Failure to follow these safety guidelines may result in personal injury or damage to the appliance.

- **Disconnect Power:** Before attempting any installation or service, ensure the appliance is completely disconnected from its power source.
- **Wear Protective Gear:** Use appropriate personal protective equipment, such as gloves and eye protection, during installation.
- **Professional Installation:** If you are unsure about any step, consult a qualified technician.
- **Original Parts:** Use only genuine replacement parts specified by the manufacturer.

3. PRODUCT OVERVIEW

The ALLIANCE LAUNDRY SYSTEMS Assy Service Door Packaged (35798WP) is a replacement service door assembly for various laundry appliances. It provides access to internal components for maintenance and service. The door is typically made of durable material and includes necessary mounting points for secure attachment.



Figure 1: ALLIANCE LAUNDRY SYSTEMS Assy Service Door Packaged (35798WP). This image shows the gray rectangular service door with a circular opening on one end, designed for accessing internal components of a laundry appliance.

4. INSTALLATION INSTRUCTIONS

Follow these steps carefully to install the service door assembly. The exact procedure may vary slightly depending on your specific appliance model.

1. **Prepare the Appliance:** Ensure the laundry appliance is turned off and unplugged from the electrical outlet. If applicable, turn off the water supply.
2. **Access the Service Area:** Locate the area where the service door needs to be installed or replaced. This may require removing other panels or components.
3. **Remove Old Door (if applicable):** If replacing an existing door, carefully remove any screws, clips, or fasteners holding the old service door in place. Retain any reusable hardware.
4. **Position the New Door:** Align the new ALLIANCE LAUNDRY SYSTEMS Assy Service Door (35798WP) with the opening on the appliance. Ensure all tabs, hinges, or mounting points are correctly aligned.
5. **Secure the Door:** Fasten the new service door using the appropriate screws, clips, or other hardware. Ensure it is securely attached and does not wobble. Do not overtighten fasteners.
6. **Test Functionality:** Gently open and close the service door to ensure it operates smoothly and latches securely.
7. **Restore Power:** Once the door is securely installed and all other components are reassembled, plug the appliance back into the electrical outlet and restore power.

5. OPERATING INSTRUCTIONS

This service door is designed to provide access for maintenance. It is not intended for frequent user interaction during normal operation of the appliance.

- **Opening:** To open the service door, locate the latch or release mechanism (if present) and gently pull the door open.
- **Closing:** To close, push the door firmly until it latches securely. Ensure it is fully closed before operating the

appliance.

6. MAINTENANCE

Proper maintenance ensures the longevity and functionality of the service door.

- **Cleaning:** Clean the service door periodically with a soft, damp cloth and mild detergent. Avoid abrasive cleaners or solvents.
- **Inspection:** Regularly inspect the door for any signs of damage, cracks, or loose fasteners. Address any issues promptly.
- **Lubrication (if applicable):** If the door has hinges or a latch mechanism that requires lubrication, use a small amount of silicone-based lubricant as needed.

7. TROUBLESHOOTING

If you encounter issues with your service door, refer to the following common problems and solutions:

- **Door Does Not Close Securely:**
 - Check for obstructions around the door frame or latch mechanism.
 - Inspect the latch or hinge for damage or misalignment. Adjust or replace if necessary.
- **Door Appears Loose or Wobbly:**
 - Ensure all mounting screws or fasteners are tightened. Do not overtighten.
 - Inspect the mounting points on both the door and the appliance for damage.
- **Visible Damage (Cracks, Breaks):**
 - If the door itself is cracked or broken, it may need to be replaced to maintain the integrity of the appliance.

8. SPECIFICATIONS

Attribute	Detail
Part Number	35798WP
Manufacturer	Alliance Laundry Systems
Item Weight	1.29 pounds
Package Dimensions	8.8 x 4.85 x 1.5 inches
Item Package Quantity	1
Compatible Brands	Huebsch, Speed Queen, Econo-Wash, Alliance Laundry Systems

9. WARRANTY AND SUPPORT

Information regarding specific warranty terms or direct customer support contacts for the ALLIANCE LAUNDRY SYSTEMS Assy Service Door Packaged (35798WP) was not provided in the product data. For warranty claims or technical assistance, please refer to the documentation supplied with your original appliance or contact Alliance Laundry Systems directly through their official website or customer service channels.

© 2024 ALLIANCE LAUNDRY SYSTEMS. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DQYT7588>

More documents and user manuals: <https://manuals.plus/>