

CoBak CoBak 6-inch E-Reader Case (11th Generation)

CoBak Protective Case User Manual

Model: CoBak 6-inch E-Reader Case (11th Generation)

Brand: CoBak

INTRODUCTION

This manual provides instructions for the proper use and care of your CoBak Protective Case, designed for 6-inch e-readers, specifically the 11th Generation models released in 2022 and 2024. This case offers protection and enhances the functionality of your device with features like automatic sleep/wake.

COMPATIBILITY

This CoBak protective case is compatible with the following 6-inch e-reader models:

- Kindle 6-inch (11th Generation, 2022 Release)
- Kindle 6-inch (11th Generation, 2024 Release)
- Other 6-inch e-readers with similar dimensions and button placements.

Compatibility

All-new
Kindle 6"
(2022 release)




Figure 1: Compatibility with 6-inch Kindle (11th Generation).

KEY FEATURES

- **Automatic Sleep/Wake Function:** The built-in smart sensor automatically wakes your e-reader when the cover is opened and puts it to sleep when closed, conserving battery life.
- **Magnetic Closure:** A secure magnetic design ensures the cover remains closed, providing comprehensive protection for your device.
- **Premium Materials:** Constructed with a waterproof PU leather exterior, an anti-scratch microfiber interior, and fiberglass panels for enhanced strength. The inner shell is made of 100% TPU for high impact resistance.
- **Slim and Lightweight Design:** Provides maximum protection without adding significant bulk, making it ideal for travel.

Auto Wake/Sleep

Built-in Magnet
Snapped closing easily



Reduce battery consumption



Extend standby time



Figure 2: Demonstration of the Auto Sleep/Wake feature.



Figure 3: Material layers and construction of the protective case.

SETUP: INSTALLING YOUR E-READER

1. **Prepare Your Device:** Ensure your 6-inch e-reader is clean and free of dust or debris.
2. **Align the E-Reader:** Gently align your e-reader with the TPU inner shell of the case. Ensure the buttons and ports on your device match the cutouts in the case.
3. **Insert the Device:** Carefully press your e-reader into the TPU shell until it is securely seated. Apply even pressure around the edges to ensure a snug fit.
4. **Verify Fit:** Check that all edges of your e-reader are protected by the case and that buttons and ports are accessible.




Figure 4: E-reader securely fitted within the case.

OPERATING INSTRUCTIONS

- **Opening the Case:** To use your e-reader, simply lift the front cover. The magnetic closure will release, and your device will automatically wake up.
- **Closing the Case:** To put your e-reader to sleep and protect the screen, close the front cover. The magnets will secure it, and the device will enter sleep mode.
- **Reading Position:** The cover can be folded back completely for comfortable one-handed reading.

MAINTENANCE AND CARE

- **Cleaning the Exterior:** Wipe the PU leather exterior with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Cleaning the Interior:** Gently wipe the microfiber interior with a dry, soft cloth to remove dust. Do not use liquids on the interior.
- **Storage:** Store the case in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Avoid Sharp Objects:** Prevent contact with sharp objects to avoid scratching or damaging the case materials.

Waterproof surface



Figure 5: The waterproof surface of the case for easy cleaning.

TROUBLESHOOTING

Issue	Possible Cause	Solution
E-reader does not wake/sleep automatically.	Device not properly seated, or magnetic sensor misalignment.	Ensure the e-reader is fully and correctly inserted into the case. Remove and re-insert if necessary.
Case cover does not stay closed.	Obstruction or magnetic closure issue.	Check for any foreign objects between the cover and the e-reader. Ensure the case is not damaged.
Difficulty inserting/removing e-reader.	Incorrect alignment or excessive force.	Align the device carefully with the case. Apply gentle, even pressure. Do not force the device.

SPECIFICATIONS

- **Product Dimensions:** 6.3 x 4.72 x 0.51 inches (16.0 x 12.0 x 1.3 cm)
- **Item Weight:** 3.53 ounces (100 grams)

- **Material:** Premium PU Leather (exterior), Microfiber (interior), Fiberglass panels, 100% TPU (inner shell)
- **Special Features:** Automatic Sleep/Wake, Magnetic Closure, Slim Fit, Waterproof Surface
- **Compatible Devices:** 6-inch E-readers (Kindle 11th Generation, 2022/2024 models)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official CoBak website or contact CoBak customer service directly. Specific warranty terms may vary by region and retailer.

For further assistance, visit the [CoBak Store on Amazon](#).

© 2025 CoBak. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question