

X10

Generic X10 Gaming Headphones User Manual

Model: X10

1. INTRODUCTION

Thank you for choosing the Generic X10 Gaming Headphones. These headphones are designed to provide an immersive audio experience for gaming, music, and movies across various platforms including PC, consoles, and laptops. Featuring detachable cat ears, dynamic RGB lighting, a high-definition microphone, and surround sound capabilities, the X10 offers both style and performance. Please read this manual carefully to ensure proper setup and operation.

2. PACKAGE CONTENTS

Please check the package for the following items:

- 1 x Generic X10 Gaming Headphones
- 1 x Detachable Microphone
- 2 x Detachable Cat Ears
- 1 x USB Connection Cable (integrated)

3. PRODUCT FEATURES

- **Detachable Cat Ears:** Customizable aesthetic with easy-to-attach and remove cat ears.
- **RGB Lighting:** Dynamic lighting effects for an enhanced visual experience.
- **HD Microphone:** High-definition, noise-canceling microphone for clear communication.
- **Surround Sound:** 50mm drivers deliver immersive audio.
- **Comfortable Over-Ear Design:** Ergonomic design for extended wear comfort.

4. SETUP

4.1 Connecting the Headphones

Connect the integrated USB cable from the headphones directly to an available USB port on your PC, gaming console, or laptop. The headphones are plug-and-play and should be recognized automatically by most operating systems.

4.2 Attaching/Detaching Cat Ears

To attach the cat ears, align the base of each cat ear with the designated slots on the top of the headphone headband. Gently push until they securely click into place. To detach, gently pull them away from the headband.

Detachable cat ear

Flexible use on different occasions,
buckle structure design can be
disassembled arbitrarily
food-grade silica gel material
assures safety.



Adaptive suspension
head beam



Fully wrapped
 earmuffs



Image showing the Generic X10 Gaming Headphones on a stand, with the detachable cat ears placed separately. The image highlights the adaptive suspension head beam and fully wrapped earmuffs.

4.3 Attaching/Detaching Microphone

Locate the microphone port on the left earcup of the headphones. Insert the microphone jack firmly into this port until it is fully seated. To remove the microphone, gently pull it straight out from the port.

Pluggable microphone

Omnidirectional microphone, high-definition, and efficient voice call pre-emptive to bring a better game experience



Detachable 360° adjustment



Clear-call
Noise-rejection



Image displaying the Generic X10 Gaming Headphones with the pluggable microphone attached. The image emphasizes the 360-degree adjustable and noise-canceling features of the microphone.

5. OPERATING INSTRUCTIONS

5.1 Volume Control

Adjust the audio volume using the scroll wheel or buttons located on the inline remote control attached to the headphone cable. Rotate the wheel up to increase volume and down to decrease, or press the respective buttons.

5.2 Microphone Mute

To mute or unmute the microphone, press the dedicated microphone mute button on the inline remote control. An indicator light (if present) may show the microphone's status.

5.3 RGB Lighting Control

The RGB lighting will activate automatically when the headphones are connected via USB. If there is a button on the inline remote, you can press it to cycle through different lighting modes or to turn the RGB lighting on/off.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners, solvents, or harsh

chemicals.

- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid sharp bends or excessive pulling on the cable to prevent damage.

7. TROUBLESHOOTING

7.1 No Sound from Headphones

- Ensure the USB cable is securely connected to your device.
- Check the volume level on the inline remote control and on your computer/console.
- Verify that the Generic X10 Headphones are selected as the default audio output device in your device's sound settings.

7.2 Microphone Not Working

- Ensure the microphone is fully inserted into its port on the earcup.
- Check that the microphone is not muted via the inline remote control.
- Confirm that the Generic X10 Microphone is selected as the default input device in your device's sound settings.
- Test the microphone with another application or device if possible.

7.3 RGB Lighting Not Functioning

- Ensure the USB connection is secure and providing power.
- If applicable, press the RGB control button on the inline remote to activate or cycle through modes.
- Some systems may require specific drivers; check the manufacturer's website for updates.

8. SPECIFICATIONS

Brand	Generic
Model Number	X10
Connectivity Technology	Wired (USB Type-C Connector)
Ear Placement	Over Ear
Audio Driver Type	Dynamic Driver (50mm)
Frequency Range	20Hz - 20,000Hz
Microphone	High-Definition, Noise-Canceling, Pluggable
Material	Plastic, Fabric/Plush
Compatible Devices	Gaming PCs, Gaming Consoles, Laptops, Desktops, Smartphones
Control Method	Remote (Inline)

9. WARRANTY AND SUPPORT

9.1 Warranty Information

This product comes with a **1 Year Manufacturer Warranty**. Please retain your proof of purchase for warranty

claims.

9.2 Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact your retailer or the manufacturer, Onikuma. Refer to your purchase documentation for specific contact details.