Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Happybuy GZT764585

Happybuy Heavy-Duty Stainless Steel Work Table

Model: GZT764585 | **Brand:** Happybuy

Instruction Manual

1. Introduction

Thank you for choosing the Happybuy Heavy-Duty Stainless Steel Work Table. This manual provides essential information for the safe assembly, operation, and maintenance of your new work table. Designed for commercial kitchens, restaurants, and various other applications, this table offers a sturdy and versatile workspace. Please read these instructions thoroughly before assembly and retain them for future reference.



Image 1.1: The Happybuy Stainless Steel Work Table providing additional workspace in a kitchen environment.

2. Safety Instructions

- Always ensure all bolts and fasteners are securely tightened before use.
- Do not exceed the maximum weight capacity of 700 lbs for the entire table (400 lbs for the top shelf, 300 lbs for the bottom shelf). Overloading can cause damage or injury.
- When moving the table, ensure the path is clear and move slowly to prevent tipping. Lock the casters once the table is in its desired position.
- Keep hands and fingers clear of moving parts during assembly and adjustment.
- Clean the stainless steel surfaces regularly to maintain hygiene and prevent corrosion.

3. Package Contents

Verify that all components are present before beginning assembly:

- 1 x Stainless Steel Tabletop
- 1 x Undershelf
- 4 x Legs
- 4 x Swivel Casters (2 with brakes)
- 4 x Triangular Plates (for leg stability)
- 12 x Hexagon Socket Bolts M8*16mm
- 4 x M8 Nuts

4. Setup

4.1. Assembly Steps

1. Carefully unbox all components and lay them out on a clean, flat surface.
2. Attach the four legs to the underside of the tabletop using the provided hexagon socket bolts. Ensure they are finger-tight initially.
3. Slide the undershelf onto the legs. Do not tighten the bolts yet.
4. Attach the four triangular plates to the corners where the legs meet the tabletop for added stability. Secure with bolts.
5. Insert the four swivel casters into the bottom of each leg. Two casters have brakes; position these on the same side for easier access.
6. Once all components are in place, use an appropriate wrench to securely tighten all bolts. Do not overtighten.



Image 4.1: Detail of the swivel casters, including the brake mechanism for stability.

4.2. Adjustable Height Shelf

The bottom shelf can be adjusted to three different height levels to accommodate various items. To adjust:

1. Loosen the bolts securing the undershelf to the legs.
2. Carefully raise or lower the shelf to the desired height, aligning the shelf supports with the pre-drilled holes in the legs.
3. Securely tighten the bolts at the new position. Ensure all four corners are at the same height for stability.




Image 4.2: Illustration of the adjustable bottom shelf, demonstrating height variations.

5. Operating

5.1. Weight Capacity

The work table is designed to support a total weight of up to 700 lbs. The top shelf has a maximum capacity of 400 lbs, and the bottom shelf can hold up to 300 lbs. Distribute weight evenly to maintain stability.



Image 5.1: Visual representation of the weight capacities for the top (220 lbs shown, actual 400 lbs) and bottom (110 lbs shown, actual 300 lbs) shelves.

5.2. Mobility and Stability

The table is equipped with four swivel casters for easy movement. Two of these casters include brakes. To secure the table in place, press down on the brake levers on the two braked casters until they lock. To move the table, release the brakes.

6. Maintenance

6.1. Cleaning

The stainless steel surfaces are easy to clean. Use a mild detergent and a soft cloth. Avoid abrasive cleaners or scouring pads, as these can scratch the surface. Rinse with clean water and dry thoroughly to prevent water spots and maintain the finish.

6.2. Inspection

Periodically inspect all bolts and fasteners to ensure they remain tight. Check the casters for smooth operation and ensure the brakes engage properly. Address any loose components immediately to prevent accidents.

7. Troubleshooting

- **Table is wobbly:** Ensure all bolts, especially those connecting the legs to the tabletop and undershelf, are securely tightened. Verify that the table is on a level surface.
- **Casters not rolling smoothly:** Check for debris caught in the wheels. Ensure the caster brakes are fully disengaged.
- **Casters not locking:** Ensure the brake mechanism is free of obstructions and fully engaged.

8. Specifications

Feature	Specification
Material	SUS201 Stainless Steel
Product Size (L x W x H)	30 x 18 x 34 inch (76 x 46 x 86 cm)
Load Capacity (Total)	700 lbs
Load Capacity (Top Shelf)	400 lbs
Load Capacity (Bottom Shelf)	300 lbs
Product Weight	20 lbs (9.2 kg)
Height Adjustment	3 Levels for bottom shelf
Casters	4 Swivel Casters (2 with brakes)
Leg Diameter	1.9 inch
Model Number	GZT764585

PRODUCT SPECIFICATIONS:

Weight: 24.3 lbs / 11 kg
Product Size: 30 x 18 x 34 inch / 76 x 46 x 86 cm










Image 8.1: Overview of product dimensions and weight.




Image 8.2: Further detailed measurements of the work table components.



Image 8.3: Features of the stainless steel material, integrated design, and 1.9-inch leg diameter.

9. Warranty & Support

For warranty information or technical support, please contact Happybuy customer service. Refer to your purchase documentation for specific contact details or visit the official Happybuy website.

© 2026 Happybuy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DR24V6R9

More documents and user manuals: **https://manuals.plus/**