

[Manuals.plus](#) /

› [Oreilet](#) /

› Oreilet Travel Electric Kettle Model Oreilet90g4pi8twg User Manual

Oreilet Oreilet90g4pi8twg

Oreilet Travel Electric Kettle Model Oreilet90g4pi8twg User Manual

Your guide to safe and efficient use of your portable electric kettle.

1. INTRODUCTION

Thank you for choosing the Oreilet Travel Electric Kettle. This compact and portable device is designed for heating water, milk, tea, and coffee on the go. Featuring a stainless steel interior, USB rechargeable battery, and a built-in rotary stirrer, it offers convenience for travel, business, and daily use. Please read this manual thoroughly before operation to ensure safe and optimal performance.

2. SAFETY INFORMATION

To prevent injury or damage, always follow these basic safety precautions:

- Do not immerse the kettle base, power cord, or plug in water or other liquids.
- Ensure the kettle is placed on a stable, flat, heat-resistant surface away from the edge of the countertop.
- Do not operate the kettle if the power cord or plug is damaged, or if the kettle malfunctions or has been damaged in any way.
- Keep the appliance out of reach of children. Close supervision is necessary when any appliance is used by or near children.
- Do not fill above the maximum fill line or below the minimum fill line to prevent boiling dry or overflow.
- Always ensure the lid is securely closed before operating.
- Use only the charging cable provided with the kettle.
- Avoid contact with hot surfaces. Use handles or knobs.
- Unplug the kettle from the power source when not in use and before cleaning.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Oreilet Travel Electric Kettle
- 1 x USB Charging Cable



Image: The Oreilet Travel Electric Kettle shown with its included USB charging cable.

4. PRODUCT FEATURES

- **Food-Grade Material:** Constructed with food-grade stainless steel for safety and durability.
- **Portable Design:** Compact and lightweight, featuring a USB rechargeable design for convenience during travel.
- **Fast Heating and Stirring:** Equipped with a built-in rotary stirrer to mix beverages like coffee or milk, and capable of heating water up to 55°C quickly.
- **Optimal Temperature:** Heats water to 55°C, suitable for preparing milk powder for children or enjoying warm beverages.
- **High Capacity Battery:** Includes two 3000mAh Li-ion batteries for extended use between charges.



Image: The kettle shown next to a baby bottle, illustrating its use for warming milk to 45°C (as indicated in the image, though product description states 55°C).




Image: The portable kettle displayed in an outdoor environment, highlighting its suitability for travel and on-the-go use.

5. SETUP

1. **Initial Cleaning:** Before first use, wash the interior of the kettle with warm water and a mild detergent. Rinse thoroughly and wipe dry. Do not immerse the exterior of the kettle in water.
2. **Charging:** Connect the provided USB charging cable to the charging port on the kettle and to a suitable USB power adapter (not included). Allow the kettle to fully charge before first use. The battery indicator on the control panel will show charging status.
3. **Placement:** Place the kettle on a flat, stable surface.



Image: A close-up view of the bottom of the kettle, showing the charging port for the USB cable.

6. OPERATING INSTRUCTIONS

1. **Fill the Kettle:** Open the lid and fill the kettle with the desired liquid (water, milk, etc.). Do not exceed the maximum fill line (400ML).
2. **Secure the Lid:** Close the lid tightly to prevent spills during operation.
3. **Power On/Off:** Touch and hold the power button (labeled "warm" with a power icon) for three seconds to turn the kettle on or off.
4. **Heating Function:** Once powered on, the kettle will begin heating the contents to approximately 55°C. The heating process is indicated by the control panel.
5. **Stirring Function:** To activate the rotary stirrer, press the "Battery" button (with a circular arrow icon) briefly. Press again to stop stirring. This is useful for mixing powdered beverages like coffee or milk.
6. **Monitoring Battery:** The "Battery" indicator on the control panel provides information on the remaining battery life.
7. **Serving:** Once the desired temperature is reached or heating is complete, carefully open the lid and pour the contents. Be cautious of hot steam.



Image: A close-up of the kettle's control panel, showing the "Battery" (stirring) and "warm" (power/heating) buttons.

7. MAINTENANCE

Regular cleaning ensures the longevity and hygiene of your kettle.

- **Exterior Cleaning:** Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or immerse the kettle in water.
- **Interior Cleaning:** For general cleaning, rinse the interior with warm water. For stubborn stains or mineral deposits (limescale), fill the kettle with a mixture of water and white vinegar (1:1 ratio) and let it sit for an hour, then rinse thoroughly. Do not boil vinegar.
- **Storage:** When not in use, ensure the kettle is clean and dry. Store it in a cool, dry place away from direct sunlight.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Kettle does not turn on.	Low battery or not charged.	Charge the kettle using the provided USB cable. Ensure the power button is held for 3 seconds.

Problem	Possible Cause	Solution
Kettle is not heating.	Kettle not powered on, or battery is too low.	Ensure the kettle is powered on (hold power button for 3 seconds). Check battery level and recharge if necessary.
Stirrer is not working.	Stirrer not activated, or battery is low.	Press the "Battery" button briefly to activate the stirrer. Recharge the kettle if the battery is low.
Liquid leaks from the lid.	Lid not properly secured or kettle overfilled.	Ensure the lid is closed tightly. Do not fill liquid above the maximum fill line.

9. SPECIFICATIONS

Feature	Detail
Brand	Oreilet
Model Name	Oreilet90g4pi8twg
Material	Stainless Steel (Food Grade)
Capacity	400ML
Heating Temperature	Up to 55°C
Battery Type	Li Battery (Built-In)
Battery Capacity	2 x 3000mAh
Product Dimensions	7.87"L x 4.72"W x 4.72"H
Item Weight	1.21 pounds

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DR27QL4J>

More documents and user manuals: <https://manuals.plus/>