

STUDIOFINIX ST-RSGBTGY-S-SLR

STUDIOFINIX 8-inch Outdoor Rock Speaker Instruction Manual

Model: ST-RSGBTGY-S-SLR

INTRODUCTION

Thank you for choosing the STUDIOFINIX 8-inch Outdoor Rock Speaker. This waterproof, Bluetooth-enabled, solar-powered speaker is designed to provide high-quality audio in various outdoor environments, including patios, decks, pools, and gardens. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your speaker.

PACKAGE CONTENTS

WHAT'S IN THE BOX?



Speaker x1



USB A+C Power Adaptor x1
C-C Charging Cables x1



User Manual x1

Image: Contents of the STUDIOFINIX 8-inch Outdoor Rock Speaker package, including the speaker, power adapter, charging cable, and user manual.

- Main Rock Speaker (1)
- USB A+C Power Adapter (1)
- 1M Fast Charging Cable (1)
- Instruction Manual (1)

KEY FEATURES

Solar & Type-C Rechargeable

The speaker is equipped with a high-performance battery that supports both solar and Type-C charging. Type-C charging takes approximately 4 hours for a full charge. Playback time varies based on volume and sunlight exposure:

up to 10 hours at 80% volume, 8 hours at maximum volume, and even longer at the lowest volume setting.



Image: Close-up view of the rock speaker showing the solar panel on top and the USB-C charging port on the back.

Bluetooth 5.3 & TWS Pairing

Utilizing Bluetooth 5.3, this speaker offers quick pairing and a stable connection up to 49 feet. It features True Wireless Stereo (TWS) mode, allowing you to sync two same-model speakers for an immersive stereo sound experience, ideal for larger outdoor spaces.

Seamless Connectivity within 49 Feet

Keep music smooth via Bluetooth, anytime, anywhere.




Image: A smartphone screen displaying Bluetooth settings, indicating a successful connection to the speaker, with the speaker visible in an outdoor setting.

Tough & Weatherproof (IPX7)

Crafted with sturdy materials and an IPX7 waterproof rating, this speaker is built to withstand various outdoor conditions. It operates stably in rain, shine, or sun, making it a reliable companion for your garden, terrace, or poolside.

IPX7 Design Waterproof

Weatherproof music anywhere, anytime!



Image: The rock speaker placed near a pool, with water droplets visible, illustrating its IPX7 waterproof design.

Versatile Design

The realistic rock design blends seamlessly into outdoor landscapes. Its robust construction and excellent sound quality make it suitable for various outdoor activities and gatherings.



Five-step baking process

for paint, ensuring long-lasting and fade-resistant color



Easy to maintain



Durable



Weather
resistant



Environmental
protection

VARIOUS OCCASIONS



Patio



Courtyard



Poolside



Garden

Image: A collage showing the rock speaker integrated into different outdoor environments, including a patio, courtyard, poolside, and garden.

SETUP GUIDE

1. Initial Charging

Before first use, it is recommended to fully charge the speaker using the provided USB A+C Power Adapter and 1M Fast Charging Cable. A full charge via Type-C takes approximately 4 hours. The speaker will also charge via its solar panel when exposed to direct sunlight.

2. Powering On/Off

Locate the control panel on the back of the speaker. Press and hold the Power button (for 3 seconds to turn the speaker on or off. A sound indicator will confirm the power status.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing blue LED).
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "STUDIOFINIX Rock Speaker" from the list.
4. Once connected, the LED indicator will turn solid blue, and you will hear a confirmation tone.

4. TWS (True Wireless Stereo) Pairing (for two speakers)

To achieve stereo sound with two STUDIOFINIX 8-inch Rock Speakers:

1. Turn on both speakers. Do not connect either speaker to your Bluetooth device yet.
2. On one speaker (this will be your primary speaker), double-press the Bluetooth button . It will enter TWS pairing mode.
3. The two speakers will automatically search for and connect to each other. You will hear a confirmation tone once TWS pairing is successful.
4. Now, connect your Bluetooth device to the primary speaker as described in step 3. Both speakers will play audio in stereo.

Your browser does not support the video tag.

Video: An overview of the STUDIOFINIX 8-inch Solar Outdoor Rock Speaker, demonstrating its design and features, including its placement by a pool and the control panel for charging and Bluetooth pairing.

OPERATING INSTRUCTIONS

Volume Control

Adjust the volume directly from your connected Bluetooth device (smartphone, tablet, etc.).

Playback Control

Control music playback (play, pause, skip tracks) directly from your connected Bluetooth device.

Placement

For optimal solar charging, place the speaker in an area that receives direct sunlight for several hours a day. The realistic rock design allows it to blend naturally into garden beds, by pools, or on patios.



Image: The STUDIOFINIX 8-inch Outdoor Rock Speaker, designed to resemble a gray rock, placed in an outdoor environment.

MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Solar Panel:** Periodically clean the solar panel surface to ensure maximum charging efficiency. Dust and debris can reduce its effectiveness.
- **Storage:** If storing the speaker for an extended period, ensure it is fully charged. Store in a cool, dry place away from extreme temperatures.
- **Battery Care:** To prolong battery life, avoid completely draining the battery frequently. Recharge the speaker regularly, especially if not used for long periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker using the Type-C cable or place it in direct sunlight.

Problem	Possible Cause	Solution
Cannot pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from speaker.	Ensure speaker is in pairing mode (flashing blue LED). Turn on Bluetooth on your device. Move device closer to speaker (within 49 ft).
No sound or low volume.	Volume too low on speaker or device; speaker not connected.	Increase volume on both the speaker (via connected device) and your audio source. Re-establish Bluetooth connection.
TWS pairing fails.	Speakers already connected to a device; incorrect pairing sequence.	Ensure both speakers are disconnected from any Bluetooth devices. Follow TWS pairing steps precisely.

SPECIFICATIONS

Feature	Detail
Model Name	ST-RSGBTGY-S-SLR
Speaker Type	Surround Sound (2.0 Channel Configuration)
Special Features	Portable, Waterproof (IPX7), Solar Powered
Connectivity Technology	Bluetooth 5.3, Wireless
Bluetooth Range	Up to 49 Feet
Speaker Size	8 Inches (Woofer)
Speaker Maximum Output Power	120 Watts
Battery Life	Up to 10 hours (80% volume), 8 hours (max volume)
Charging Time (Type-C)	Approx. 4 hours
Product Dimensions	13.4"D x 11.4"W x 11.6"H
Item Weight	10.67 pounds (4.85 Kilograms)
Color	Gray
Manufacturer	Studiofinix

WARRANTY AND SUPPORT

STUDIOFINIX products come with a limited warranty. For detailed warranty information, technical support, or any inquiries regarding your speaker, please refer to the official STUDIOFINIX website or contact their customer service directly. Contact information can typically be found in the included instruction manual or on the product packaging.