

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bestway](#) /

› [Bestway Multi-Max 5-in-1 Air Couch \(Model 75054\) Instruction Manual](#)

Bestway 75054

Bestway Multi-Max 5-in-1 Air Couch

Model: 75054

INTRODUCTION

This manual provides essential instructions for the safe and effective use, setup, and maintenance of your Bestway Multi-Max 5-in-1 Air Couch. Please read all instructions carefully before inflation and use. This versatile inflatable product can be configured as a couch, double bed, double layered bed, recliner, or lounge.

SAFETY INFORMATION

- **Adult Supervision:** Always ensure children are supervised when near or on the air couch.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 300 kg (661 lbs). Overloading can cause damage and injury.
- **Sharp Objects:** Keep the air couch away from sharp objects, heat sources, and open flames.
- **Inflation:** Do not over-inflate. Inflate until firm but not rigid.
- **Pump Not Included:** A manual or electric air pump is required for inflation and is not included with this product.
- **Repair Patch:** Use the included repair patch for any air leaks.

SETUP AND INFLATION

1. **Unpack:** Carefully remove the air couch from its packaging. Unfold it completely on a clean, flat surface, free from sharp objects.
2. **Locate Valves:** Identify the inflation valves on the air couch. This model typically has multiple chambers for different configurations.
3. **Inflate:** Using a compatible air pump (not included), inflate each chamber until the couch is firm to the touch but still has some give. Do not over-inflate. Close all valves securely after inflation.



Image: The Bestway Multi-Max 5-in-1 Air Couch showing its dimensions (188cm x 152cm x 64cm) in a couch configuration with an extended footrest. This illustrates the overall size when set up.



Image: The Bestway Multi-Max 5-in-1 Air Couch in a couch configuration with an extended footrest, ready for use. This shows the product fully inflated and assembled in one of its versatile modes.

OPERATING (5-IN-1 CONFIGURATIONS)

The Bestway Multi-Max Air Couch offers five distinct configurations. Adjust the inflation of specific chambers and the folding of the sections to achieve the desired mode.

1. Couch Mode

Inflate all sections. Fold the base section to create a backrest and armrests. This provides a comfortable seating arrangement for multiple people.



Image: The Bestway Multi-Max 5-in-1 Air Couch configured as a standard two-seater couch. This mode is ideal for general seating.

2. Double Bed Mode

Fully extend all inflatable sections to create a flat, spacious sleeping surface. Ensure all chambers are adequately inflated for optimal comfort.



Image: The Bestway Multi-Max 5-in-1 Air Couch fully extended into a double bed configuration. This mode provides a large, flat surface suitable for sleeping.

3. Double Layered Bed Mode

Similar to the double bed, but with an additional layer for increased height and comfort. This may involve stacking or folding specific sections to achieve the elevated bed structure.

4. Recliner Mode

Partially fold one section to create an inclined backrest, while keeping the other sections extended for leg support. Adjust inflation for desired firmness.



Image: The Bestway Multi-Max 5-in-1 Air Couch configured as a recliner, offering a comfortable position for lounging or reading.

5. Lounge Mode

Extend the main body and partially fold one end to create a comfortable lounge chair with a slight incline. This is ideal for relaxed seating.



Image: The Bestway Multi-Max 5-in-1 Air Couch in a lounge configuration, providing an extended surface with a backrest for comfortable relaxation.

MAINTENANCE

- **Cleaning:** Clean the air couch with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners. Hand wash only.
- **Drying:** Ensure the air couch is completely dry before deflating and storing to prevent mold and mildew.
- **Storage:** Deflate the air couch completely. Fold it neatly and store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Repair Patch:** If an air leak occurs, locate the hole, clean the area, and apply the included repair patch firmly over the hole. Allow sufficient time for the patch to bond before re-inflating.

TROUBLESHOOTING

- **Slow Air Loss:** Check all inflation valves to ensure they are securely closed. Inspect the surface for small punctures or leaks. Use soapy water to identify leaks by looking for bubbles. Apply the repair patch as instructed.

- **Rapid Air Loss:** A larger puncture may be present. Locate the damage and apply the repair patch. If the damage is extensive, the product may need replacement.
- **Uneven Inflation:** Ensure all chambers are inflated to a similar firmness. If one section appears softer, check its valve and for any leaks.

SPECIFICATIONS

Model Number	75054
Inflated Size (L x W x H)	188 cm x 152 cm x 64 cm (74" x 60" x 25")
Material	Durable PVC (Polyvinyl Chloride) with flocked surface
Weight Capacity	300 kg (661 lbs)
Included Components	1 Air Couch, 1 Repair Patch
Color	Black

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the documentation included with your purchase or visit the official Bestway website. Only use original Bestway spare parts and accessories for repairs or replacements.