Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kestanlora 1

Kestanlora HD 1080P WiFi Hidden Camera Smoke Detector User Manual

Model: 1 | Brand: Kestanlora

1. Introduction

This manual provides detailed instructions for the safe and effective use of your Kestanlora HD 1080P WiFi Hidden Camera Smoke Detector. Please read this manual thoroughly before operating the device and retain it for future reference.



Image: Kestanlora HD 1080P WiFi Hidden Camera Smoke Detector.

2. Important Safety Information

- This device is designed for surveillance purposes only and is not a functional smoke detector. It does not provide fire detection or alarm capabilities.
- Ensure the device is installed in compliance with all local laws and regulations regarding surveillance.
- Do not expose the device to extreme temperatures, humidity, or direct sunlight.
- Keep the device away from water and other liquids.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- Use only the provided charging cable and power adapter to prevent damage.

3. Package Contents

Verify that all items are present in your package:

- Kestanlora HD 1080P WiFi Hidden Camera Smoke Detector
- USB Charging Cable
- Mounting Screws and Anchors
- User Manual (this document)
- (Optional: Micro SD Card Reader, if included with your specific package)

4. Product Overview

The Kestanlora Hidden Camera Smoke Detector is a discreet surveillance device designed to blend into various indoor environments. It features 1080P HD video recording, motion detection, night vision, and remote access via a mobile application.

4.1 Key Features

- **1080P HD Video:** Captures clear, high-definition video footage.
- **WiFi Connectivity:** Enables remote viewing and control via a smartphone app.
- **Motion Detection:** Automatically records when movement is detected, conserving storage and battery.
- **Night Vision:** Equipped with non-illuminated infrared LEDs for clear recording in low-light conditions (not for total darkness).
- **Loop Recording:** Overwrites the oldest files when the memory card is full.
- **Micro SD Card Support:** Supports up to 128GB Micro SD card for local storage (card not included).
- **Discreet Design:** Blends seamlessly into home or office environments.

4.2 Device Components



Image: Side view of the device, showing its compact form factor.



Image: Back view of the device, highlighting ports and controls.



Image: Visual representation of the 120-degree wide-angle lens and night vision feature.



Image: Detailed diagram illustrating product dimensions and various technical features.

5. Setup Guide

5.1 Charging the Device

Before first use, fully charge the device using the provided USB charging cable. Connect the cable to the device's charging port and a standard USB power adapter (not included). The charging indicator light will show the charging status and turn off when fully charged.

5.2 Inserting a Micro SD Card

A Micro SD card (up to 128GB, Class 10 or higher recommended) is required for recording footage and is not included. Locate the SD card slot on the device. Gently insert the Micro SD card with the gold contacts facing down until it clicks into place. To remove, push the card in again until it springs out.

5.3 Mobile App Download and Connection

1. Scan the QR code in the included mini-manual or search for the designated app (e.g., "HomeSecurity" or similar, as per the product's specific app) in your smartphone's app store (App Store for iOS, Google Play Store for Android).
2. Download and install the app.
3. Register an account and log in.
4. Power on the camera.
5. In the app, follow the on-screen instructions to add a new device. This typically involves connecting your phone to the camera's temporary WiFi hotspot, then configuring the camera to connect to your home's 2.4GHz WiFi network.
6. Once connected, you can view live footage and access settings remotely.




Image: Remote access and live streaming via the mobile application.



Image: The device in use, with live footage displayed on a smartphone.

5.4 Mounting the Device

The device is designed for ceiling installation to mimic a standard smoke detector. Use the provided mounting screws and anchors to securely attach the mounting plate to your desired location on the ceiling. Once the plate is secure, twist the camera device onto the plate until it locks into place.



Image: The device discreetly mounted on a ceiling.

6. Operating Instructions

6.1 Power On/Off

Refer to the device's physical buttons or the mobile app for specific power on/off procedures. Typically, a long press on the power button will turn the device on or off. Ensure the device is powered on for recording and remote access.

6.2 Recording Modes

- **Continuous Recording:** The camera records continuously, overwriting the oldest files when the SD card is full. This mode can be configured via the mobile app.
- **Motion Detection Recording:** The camera starts recording automatically when motion is detected within its field of view. This feature helps conserve storage space and battery life. Alerts can be sent to your smartphone when motion is detected.



Image: Looping record functionality, supporting up to 128GB Micro SD card.

6.3 Night Vision

The device is equipped with non-illuminated infrared LEDs for night vision. This feature allows the camera to capture clear video in low-light conditions. Night vision typically activates automatically in dark environments or can be manually controlled through the app.



Image: Multi-scene application of the hidden camera, including night vision monitoring.



Image: Night vision functionality in a living room setting.

6.4 Accessing Footage

- **Via Mobile App:** Live stream and review recorded footage directly through the connected mobile application.
- **Via SD Card:** Remove the Micro SD card from the device and insert it into a computer using an SD card reader (if

applicable) to view recorded files.

7. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the device. Do not use liquid cleaners or aerosols.
- **Battery Care:** For optimal battery life, avoid fully discharging the device frequently. Charge it regularly.
- **Firmware Updates:** Check the mobile app periodically for any available firmware updates to ensure optimal performance and new features.

8. Troubleshooting

Issue	Possible Solution
Device not powering on.	Ensure the device is fully charged. Connect to power and try again.
Cannot connect to WiFi.	◦ Verify your WiFi network is 2.4GHz. ◦ Ensure the WiFi password is correct. ◦ Move the device closer to the WiFi router. ◦ Reset the device and attempt connection again.
No recording on SD card.	◦ Ensure an SD card is properly inserted. ◦ Check if the SD card is formatted correctly (FAT32). ◦ Verify recording settings in the app (continuous/motion detection). ◦ The SD card might be full; enable loop recording or replace it.
Poor video quality.	◦ Ensure the camera lens is clean. ◦ Check network stability for live streaming. ◦ Adjust video resolution settings in the app if available.

9. Specifications

Feature	Detail
Model Number	1
Video Resolution	1080P HD
Connectivity	WiFi (2.4GHz)
Storage	Micro SD Card (up to 128GB, not included)
Motion Detection	Yes
Night Vision	Yes (non-illuminated IR LEDs)
Product Dimensions	4.5 x 4.5 x 1.2 inches

Feature	Detail
Item Weight	6.7 ounces
Manufacturer	Kestanlora

10. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Kestanlora website. Keep your purchase receipt as proof of purchase.

© 2024 Kestanlora. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DR2SWL1K

More documents and user manuals: **https://manuals.plus/**