

SICOTAS SC017A1XLTY0743

SICOTAS Rattan Sideboard Buffet Cabinet User Manual

Model: SC017A1XLTY0743

1. INTRODUCTION

Thank you for choosing the SICOTAS Rattan Sideboard Buffet Cabinet. This cabinet combines classic rattan accents with a wood grain finish, offering a blend of boho and farmhouse aesthetics. Designed for versatile use, it provides ample storage with three doors and two drawers, suitable for various rooms such as the kitchen, living room, dining room, or entryway. This manual provides essential information for safe assembly, proper use, and maintenance of your new furniture.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Always follow the assembly instructions carefully.
- Use appropriate tools and safety gear when assembling the cabinet to prevent injuries.
- Ensure all fasteners are securely tightened before using the cabinet.
- Do not overload shelves or drawers. Distribute weight evenly to maintain stability.
- Keep small parts away from children during assembly to prevent choking hazards.
- If included, attach the anti-tip hardware to a wall stud to prevent accidental tipping, especially in households with children.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer service.

- Cabinet Panels (Top, Bottom, Sides, Back)

- 3 Doors with Rattan Accents
- 2 Drawers with Rattan Accents
- Adjustable Shelves (Quantity: 6)
- Hardware Pack (Screws, dowels, cam locks, handles, drawer slides, hinges, adjustable foot pads, small fasteners)
- Assembly Instructions Manual

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. It is recommended to have two people for assembly. Please follow the included detailed assembly instructions step-by-step. An average assembly time is approximately 1-2 hours.

4.1 Important Assembly Tips

- Lay out all parts on a soft, clean surface to prevent scratches.
- Identify all hardware and components using the provided parts list.
- Do not overtighten screws, as this can damage the engineered wood.
- **Special Tip:** Remember to attach the small fasteners to the back and tighten the screws at a 45-degree angle. This will make the cabinet more stable and sturdy.

4.2 Product Dimensions Overview

Refer to the image below for an overview of the cabinet's dimensions.

Larger 3-Door Cabinet



Image: Detailed dimensions of the SICOTAS Rattan Sideboard Buffet Cabinet, showing height (33.9"), width (43.5"), and depth (14.0"), along with drawer dimensions.

4.3 Internal Structure and Storage

The cabinet features two large storage drawers and three doors concealing adjustable shelves, allowing for flexible organization of items of various heights.

Two Large Storage Drawers Design



Image: View of the two large storage drawers of the SICOTAS Rattan Sideboard Buffet Cabinet, pulled open to show interior space.

Ample Storage for Easy Organization



Image: Interior view of the SICOTAS Rattan Sideboard Buffet Cabinet with doors open, highlighting the adjustable shelves for versatile storage.

5. OPERATING AND USAGE

Your SICOTAS Rattan Sideboard Buffet Cabinet is designed for versatile use and ample storage. Here are some guidelines for optimal operation:

- **Storage:** Utilize the two drawers for smaller items and the three cabinet compartments with adjustable shelves for larger items like vases, candle holders, or dinnerware.
- **Adjustable Shelves:** The interior shelves can be adjusted to different heights to accommodate items of various sizes. Simply remove the shelf and reposition the shelf pins to your desired level.
- **Versatile Placement:** This accent cabinet functions effectively as a TV console, coffee bar, buffet table, or entryway cabinet, adapting to various home decor styles and functional needs.
- **Door and Drawer Operation:** Open and close doors and drawers gently to ensure longevity of hinges and slides.



Image: The SICOTAS Rattan Sideboard Buffet Cabinet displayed in a dining room setting, showcasing its aesthetic and functional integration.

6. MAINTENANCE

Proper care will extend the life and appearance of your SICOTAS Rattan Sideboard Buffet Cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Rattan Care:** Gently dust the rattan surfaces with a soft brush or vacuum with a brush attachment. Avoid excessive moisture.
- **Spills:** Clean spills immediately with a dry cloth to prevent staining or water damage.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood and rattan.
- **Humidity:** Maintain a stable humidity level in the room to prevent warping or cracking of the wood.

7. TROUBLESHOOTING

If you encounter any issues with your cabinet, refer to the following common troubleshooting tips:

- **Wobbly Cabinet:** Ensure all screws and fasteners are tightened. Check if the floor is uneven; use the adjustable foot pads (if included) or shims to level the cabinet.
- **Drawers Not Sliding Smoothly:** Check that the drawer slides are correctly installed and aligned. Ensure no objects are obstructing the slides. Lubricate with a silicone-based spray if necessary.
- **Doors Not Closing Properly:** Adjust the hinges if the doors are misaligned. Ensure no items inside the cabinet are blocking the doors from closing fully.
- **Missing Parts:** If you discover missing parts during assembly, do not proceed. Contact SICOTAS customer service immediately for assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	SICOTAS
Model Number	SC017A1XLTY0743
Colour	Reclaimed Caramel Oak
Material	Engineered Wood, Rattan
Product Dimensions (D x W x H)	35.6D x 110.5W x 86.1H centimetres (14D x 43.5W x 33.9H inches)
Item Weight	33.79 kg (74.5 lbs)
Number of Doors	3
Number of Drawers	2
Number of Shelves	6 (Adjustable)
Mounting Type	Floor Mount
Style	Farmhouse, Boho
Recommended Uses	Dining Room, Entryway, General Storage, Kitchen, Living Room

9. WARRANTY AND SUPPORT

SICOTAS is committed to providing high-quality products and excellent customer service.

- **After-sales Service:** Our dedicated customer service team is available 7 days a week to assist with any issues or questions you may have. Please feel free to contact us.
- **Returns:** This product is eligible for return or refund within 30 days of receipt, subject to Amazon's return policy.
- **Manufacturer Contact:** CA-SICOTAS, 1428 Lowen Dr, Gloucester, Ontario K1V 1H3 CA.

For further assistance, please visit the [SICOTAS Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question