NUTIKAS DOS-W3-01

NUTIKAS Desk Shelves Desktop Organizer Shelf User Manual

Model: DOS-W3-01

Introduction

Thank you for choosing the NUTIKAS Desk Shelves Desktop Organizer Shelf. This manual provides detailed instructions for the assembly, operation, and maintenance of your new desktop organizer. Please read these instructions carefully before assembly and use to ensure proper function and longevity of the product.

Safety Information

Important Safety Warnings:

- Ensure all components are securely fastened during assembly.
- Do not overtighten screws, as this may damage the panel surface.
- The maximum weight capacity for this shelf is 5 pounds. Do not exceed this limit to prevent collapse or damage.
- Use the anti-fall locking bolts to maintain stability when adjusting the shelf's width or angle.
- Place the organizer on a stable, flat surface to prevent tipping.
- Be aware of exposed screws on the bottom of the unit, which may scratch delicate surfaces. Consider placing protective pads underneath.

Package Contents

Before beginning assembly, verify that all parts are present and undamaged. The package should include:

- Wood boards (various sizes for shelves and supports)
- Screws and fasteners
- Anti-fall locking bolts
- Assembly tool (screwdriver, if included)

If any parts are missing or damaged, please contact customer support.

Setup and Assembly

Assembly is required for this desktop organizer. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the included diagram (if available) to identify each wood board and hardware piece.
3. **Assemble Base Units:** Begin by connecting the main shelf sections according to the provided instructions. Ensure screws are tightened firmly but avoid overtightening to prevent damage to the wood panels.
4. **Attach Vertical Supports:** Secure the vertical support panels to create the multi-level structure.
5. **Install Anti-Fall Locking Bolts:** Insert the locking bolts into the designated slots. These bolts are crucial for maintaining the shelf's stability when adjusting its width or angle.




Figure 1: Anti-Fall Slot Design. This image illustrates the anti-fall slot design and the function of the locking bolts to ensure stability when adjusting the shelf's length.

For a visual guide, an installation video is available. Scan the QR code provided in the product packaging with your phone's camera to access the video demonstration. Remember not to overtighten screws, which could crack the panel surface.

Operating Instructions

The NUTIKAS Desk Shelves Desktop Organizer is designed for versatile use and can be adjusted to fit various spaces and organizational needs.

Adjusting Size and Configuration

The organizer features an adjustable design, allowing you to modify its width and angle. To adjust:

1. **Unlock:** Gently pull out the anti-fall locking bolts.
2. **Adjust:** Slide the two main sections of the shelf to achieve your desired width (ranging from 16.2 to 27.8 inches) or angle. You can arrange it in a straight line or an L-shape for corner use.
3. **Lock:** Re-insert the anti-fall locking bolts into the nearest available slots to secure the new configuration. Ensure the bolts are fully engaged for stability.



Figure 2: Adjustable Dimensions. This diagram shows the adjustable width and fixed height of the organizer, allowing customization to fit your desk space.



Figure 3: Optimizing Space Usage. This image demonstrates how the adjustable shelf can be configured to optimize desk space, including an L-shape for corner use.

Organizing Your Items

The various compartments and shelves are designed to hold a range of office supplies and decorative items. Utilize the different sections for:

- Books and notebooks
- Pens, pencils, and other stationery
- Small plants or decorative trinkets
- Cosmetics or personal care items




Figure 4: Spacious for a Variety of Items. This image highlights the organizer's capacity to hold diverse items, from books to small decorative elements.




Figure 5: Desk Organization Example. This image shows the organizer in a dorm room setting, illustrating how it can transform a desk into a more organized and attractive space.

Maintenance

To ensure the longevity and appearance of your NUTIKAS Desk Shelves Desktop Organizer, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the lacquered finish.
- **Dusting:** Regularly dust the shelves with a dry, soft cloth to prevent buildup.
- **Inspection:** Periodically check all screws and locking bolts to ensure they remain tight and secure. Retighten if necessary, but do not overtighten.
- **Weight Distribution:** Distribute items evenly across the shelves and avoid placing heavy objects on a single point to prevent stress on the structure.

Troubleshooting

If you encounter any issues with your desktop organizer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Shelf feels unstable or wobbly.	Locking bolts are not fully engaged or screws are loose. Uneven surface.	Ensure all anti-fall locking bolts are securely inserted. Check and tighten all assembly screws. Place the organizer on a flat, level surface.
Scratches on desk surface.	Exposed screws on the bottom of the unit.	Apply felt pads or other protective material to the bottom edges of the organizer to prevent direct contact with your desk.
Panel surface cracked during assembly.	Screws were overtightened.	Avoid overtightening screws during assembly. If damage has occurred, contact customer support for replacement parts.
Difficulty adjusting width/angle.	Locking bolts are stuck or not fully disengaged.	Ensure locking bolts are completely pulled out before attempting to slide the sections. Apply gentle, even pressure when adjusting.

Specifications

Feature	Detail
Brand	NUTIKAS
Model Name	DOS-W3-01
Material	Wood
Color	White
Product Dimensions (D x W x H)	6.7"D x 16.2"~27.8"W x 13.8"H (Adjustable Width)
Item Weight	4.5 pounds
Number of Shelves	3
Weight Capacity	Maximum 5 pounds
Mounting Type	Tabletop Mount
Special Feature	Adjustable
Finish Type	Lacquered

Warranty and Support

For warranty information or technical support, please contact NUTIKAS customer service through the retailer where the product was purchased or visit the official NUTIKAS website. Please have your model number (DOS-W3-01) and purchase date available when contacting support.

© 2026 NUTIKAS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Where can I find the instructions for the NUTIKAS DOS-W3-01 Desk Shelves Desktop Organizer?

You can find the digital version of the instructions for your NUTIKAS DOS-W3-01 Desk Shelves Desktop Organizer right here. Below is a summary of the key assembly and operation steps:Assembly: Lay out the wood...

Read full answer