

Evermagin EV-NIG-WAL-02A

Evermagin Fluted Nightstand Instruction Manual

Model: EV-NIG-WAL-02A

INTRODUCTION

Thank you for choosing the Evermagin Fluted Nightstand. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

This nightstand features a fluted panel design, a convenient drawer, and an open storage shelf, offering both aesthetic appeal and practical storage solutions for your bedroom or living area.

SAFETY INFORMATION

Please read and adhere to the following safety guidelines:

- Use appropriate tools for assembly.
- Read and follow all assembly instructions carefully.
- Keep away from children and pets during assembly and ensure the product is stable once assembled.
- Do not use if any parts are missing or damaged. Contact customer support for replacement parts.
- Always ensure stability and proper installation to prevent tipping or collapse. Secure the nightstand to a wall if necessary, using appropriate anti-tip hardware (not included unless specified).
- Do not exceed the maximum weight recommendation of 40 pounds on the top surface.

SETUP AND ASSEMBLY

Assembly of the Evermagin Fluted Nightstand is designed to be straightforward. All parts are labeled alphabetically to assist with identification. We recommend two people for assembly to ensure stability and ease of handling.

Recommended Tools:

- Drill (for faster assembly, though manual tools may be included)
- Screwdriver (Phillips head)

Assembly Steps:

1. Unpack all components and verify against the parts list in the included assembly guide.
2. Identify each part using the alphabetical labels.
3. Follow the step-by-step diagrams and instructions provided in the separate assembly guide.
4. Ensure all screws and fasteners are tightened securely, but do not overtighten.
5. Once assembled, gently test the stability of the nightstand before placing items on it.



Image: Dimensions of the Evermagin Fluted Nightstand, illustrating height, width, and depth, along with internal shelf and drawer measurements.



Image: The nightstand with its drawer open, showcasing the internal storage capacity.

OPERATING INSTRUCTIONS

The Evermagin Fluted Nightstand is designed for convenient storage and display.

Using the Drawer:

- Gently pull the gold handle to open the drawer.
- Push the drawer firmly but smoothly to close it completely. Avoid forcing the drawer.
- The drawer is suitable for storing personal items, books, or small electronics.

Using the Open Shelf:

- The open shelf provides easy access storage for items like books, decorative pieces, or a small lamp.
- Ensure items placed on the shelf do not obstruct the drawer's operation.



Image: Top-down view of the nightstand with the drawer open, illustrating its storage capabilities for various items.

MAINTENANCE

Proper care will help maintain the appearance and longevity of your nightstand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the finish. The water-resistant surface can be cleaned with a mild soap solution if necessary, followed by drying immediately.
- **Dusting:** Regularly dust with a dry, soft cloth to prevent buildup.
- **Spills:** Clean spills immediately to prevent staining or damage to the engineered wood.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure, which can cause fading or discoloration over time.
- **Heat and Moisture:** Keep the nightstand away from direct heat sources and excessive moisture. Use coasters under drinks to protect the surface.

TROUBLESHOOTING

If you encounter any issues with your Evermagin Fluted Nightstand, refer to the following common solutions:

Drawer Sticking or Not Closing Smoothly:

- **Check Alignment:** Ensure the drawer slides are properly aligned and free of obstructions.
- **Tighten Screws:** Verify that all screws securing the drawer slides and drawer box are tight. Loose screws can cause misalignment.
- **Lubrication:** Apply a small amount of silicone spray or wax to the drawer slides for smoother operation.

Nightstand Wobbles or is Unstable:

- **Check All Fasteners:** Ensure all assembly screws are securely tightened.
- **Level Surface:** Place the nightstand on a flat, level surface. If the floor is uneven, use furniture pads or shims under the legs to stabilize it.
- **Anti-Tip Kit:** For added safety, especially in homes with children or pets, consider securing the nightstand to the wall using an anti-tip kit (sold separately if not included).

Missing or Damaged Parts:

- If you find any parts missing or damaged upon opening the package, do not proceed with assembly.
- Contact Evermagin customer support immediately for assistance and replacement parts.

SPECIFICATIONS

Feature	Detail
Brand	Evermagin
Model Name	EV-NIG-WAL-02A
Product Dimensions (D x W x H)	15"D x 22.8"W x 23.6"H
Item Weight	37 pounds
Maximum Weight Recommendation	40 pounds
Frame Material	Engineered Wood
Color	Walnut
Number of Drawers	1
Special Features	Storage
Recommended Number of People for Assembly	2
UPC	766683672384



Image: The Evermagin Fluted Nightstand, showcasing its design and features.

WARRANTY INFORMATION

Evermagin products are manufactured to high-quality standards. For specific warranty details regarding your Fluted Nightstand, please refer to the warranty card included with your purchase or visit the official Evermagin website. Typically, warranties cover manufacturing defects under normal use. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Evermagin customer support. You can usually find contact information (phone number, email, or website) on the packaging, in the included assembly guide, or by visiting the official Evermagin brand store online. For online inquiries, please visit the [Evermagin Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question