

WattFlo WFG85AL65

WattFlo Electric Pressure Washer Instruction Manual

Model: WFG85AL65

Brand: WattFlo

INTRODUCTION

Thank you for choosing the WattFlo Electric Pressure Washer. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new pressure washer. Designed for powerful and efficient cleaning, this unit is ideal for a wide range of tasks around your home and property, including cleaning cars, driveways, sidewalks, fences, decks, and patios.

With its 1800-watt motor, it delivers up to 4200 PSI of water pressure and a maximum flow rate of 2.5 GPM, ensuring stable performance and high cleaning efficiency while conserving water and energy.

SAFETY INFORMATION

Always read and understand all safety warnings and instructions before operating the pressure washer. Failure to follow these instructions may result in electric shock, fire, and/or serious injury.

- Always wear appropriate personal protective equipment, including eye protection (safety glasses or goggles) and hearing protection.
- Never point the spray gun at people, pets, or electrical devices. The high-pressure spray can cause severe injury.
- Ensure the electrical outlet is properly grounded and suitable for outdoor use. Do not use extension cords unless absolutely necessary, and ensure they are rated for outdoor use and the correct amperage.
- Before each use, inspect the power cord, hose, and spray gun for any damage. Do not operate the unit if any components are damaged.
- Always disconnect the power supply before performing any maintenance or cleaning on the unit.
- Keep children and pets away from the pressure washer during operation.
- Do not operate the pressure washer in an explosive atmosphere, such as in the presence of flammable liquids, gases, or dust.

This pressure washer is equipped with a thermal protector to prevent overheating of the motor. If the unit shuts off

unexpectedly, allow it to cool down before restarting.

PACKAGE CONTENTS

Upon unpacking, please verify that all the following components are included and in good condition:

- WattFlo Electric Pressure Washer Unit
- High-Pressure Spray Gun
- 23-foot High-Pressure Hose
- 16.5-foot Power Cord
- 4 Quick-Connect Nozzles (0°, 15°, 25°, 40°)
- 500ml Foam Cannon
- Owner's Manual
- Water Inlet Fitting (for 3/4" standard US garden hose)



Image: The WattFlo Electric Pressure Washer unit shown with its main accessories, including the spray gun, high-pressure hose, foam

cannon, and four quick-connect nozzles.

SETUP INSTRUCTIONS

Setting up your WattFlo pressure washer is straightforward and typically takes less than 10 minutes. Follow these steps:

1. **Assemble the Handle:** Attach the handle to the main unit. Ensure it clicks securely into place or is fastened with provided screws.
2. **Connect the High-Pressure Hose:** Connect one end of the 23-foot high-pressure hose to the outlet on the pressure washer unit and the other end to the spray gun. Ensure connections are tight to prevent leaks.
3. **Connect Water Supply:** Your pressure washer offers three water intake options:
 - **Direct Faucet Connection:** Use the included 3/4" standard US garden hose fitting to connect your garden hose to the water inlet on the pressure washer.
 - **Self-Priming from Bucket or Pool:** For self-priming, ensure the unit is below the water level of the source (bucket or pool) and follow the specific instructions in the owner's manual for priming the pump.



Image: Diagram illustrating the water inlet fitting for standard garden hoses and the three water intake options: faucet, bucket self-priming, and pool self-priming.

4. **Select and Attach Nozzle:** Choose the appropriate quick-connect nozzle for your cleaning task and insert it into the end of the spray gun until it clicks securely.

1/4" Quick Connect

Compatible with following accessories




Image: Close-up of the 1/4-inch quick-connect interface, showing compatibility with various cleaning accessories like turbo nozzles, surface cleaners, undercarriage tools, and extension wands.

5. **Connect Power:** Plug the 16.5-foot power cord into a suitable 120V/60Hz grounded electrical outlet.

OPERATING INSTRUCTIONS

Once assembled and connected, your WattFlo pressure washer is ready for use. The unit features an Automatic Total Stop System, meaning the water pump is only turned on when you pull and hold the trigger, making it quieter and more energy-efficient than gas-powered models.

1. **Turn On Water Supply:** Fully open the water faucet to ensure a steady supply to the pressure washer.
2. **Power On the Unit:** Turn the power knob on the unit to the "ON" position.
3. **Start Cleaning:** Aim the spray gun at the surface to be cleaned and pull the trigger. The motor will start, and water will begin to spray. Release the trigger to stop the flow.

Nozzle Selection Guide

The WattFlo pressure washer includes 4 quick-connect nozzles, each designed for specific cleaning tasks:

0° Nozzle (Red): Provides a concentrated, powerful jet for tough, stubborn stains and hard-to-reach areas. Use with

extreme caution on durable surfaces only.




Image: The red 0° nozzle producing a powerful, concentrated jet, ideal for removing tough stains from surfaces like metal or cracks in pavement.

15° Nozzle (Yellow): Delivers a focused, high-pressure spray for intense cleaning of hard surfaces like concrete, brick, and asphalt.



Image: The yellow 15° nozzle providing a focused spray, suitable for cleaning surfaces such as asphalt, brick, and concrete.

25° Nozzle (Green): Offers a wider, general-purpose spray for cleaning decks, fences, patios, and other outdoor surfaces.



Image: The green 25° nozzle creating a wider spray pattern, ideal for general cleaning of decks, fences, and patios.

40° Nozzle (White): Provides a gentle, wide spray for delicate surfaces like vehicles, windows, and outdoor furniture.



Image: The white 40° nozzle delivering a gentle, wide spray, suitable for cleaning vehicles, windows, and outdoor furniture.

4 Quick Connect Nozzles



Image: A close-up view of the four quick-connect nozzles (red 0°, yellow 15°, green 25°, white 40°) with their respective spray patterns.

Using the Foam Cannon

The included 500ml foam cannon is perfect for applying cleaning solutions, especially for car washing, significantly improving efficiency. It connects easily to the spray gun.

1. Fill the foam cannon bottle with your desired pressure washer-safe cleaning solution.
2. Attach the foam cannon to the spray gun.
3. Spray the foam onto the surface. The foam cannon ensures safe operation by preventing any risk of damage to the machine from internal detergent use.

Foam Cannon

Dense foam for a spotless clean



Adjustable Spray Angle



500ML

500ML Detergent Bottle

Image: A foam cannon being used to apply dense foam to a car, demonstrating its effectiveness for vehicle cleaning.

General Cleaning Applications

The WattFlo pressure washer is versatile for various cleaning tasks:

- **Cars & Vehicles:** Use the 40° nozzle and foam cannon for a thorough, safe wash.
- **Driveways & Sidewalks:** The 15° or 25° nozzles are effective for removing dirt and grime from concrete and pavers.
- **Decks & Patios:** The 25° nozzle is suitable for general cleaning of wooden or composite decks and stone patios.
- **Fences:** Use the 25° or 40° nozzle depending on the fence material and dirt level.
- **Household Surfaces:** Can be used for cleaning house siding, outdoor furniture, and even gutters with the appropriate nozzle.

Electric Pressure Washer



Image: A man using the pressure washer to clean a large glass door, demonstrating its use for household and patio cleaning.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your WattFlo pressure washer.

- **Cleaning:** After each use, flush the system with clean water to remove any detergent residue or debris. Wipe down the exterior of the unit with a damp cloth.
- **Nozzle Care:** Clean any clogged nozzles using the included nozzle cleaning tool or a thin wire.
- **Storage:** Store the pressure washer in a dry, frost-free environment. The unit features a convenient design with plenty of storage space:
 - Gun holder on the left for easy access.
 - Power cord hook on the right to keep the cable neat.
 - Hook for the high-pressure hose.
 - Holder for the detergent bottle on the back.
 - Nozzle storage on both the body and spray gun.



Image: Illustration highlighting the various storage features of the pressure washer, including holders for the spray gun, power cord, high-pressure hose, detergent bottle, and quick-connect nozzles.

- **Winterization:** If storing in freezing temperatures, ensure all water is drained from the pump and hoses to prevent damage. Consider using a pump protector.

TROUBLESHOOTING

If you encounter issues with your pressure washer, refer to the following common troubleshooting tips. For more detailed solutions, consult the full owner's manual.

Problem	Possible Cause	Solution
Unit does not start	No power supply; Thermal overload activated	Check power connection and outlet; Allow unit to cool down for 30 minutes.
Low pressure	Insufficient water supply; Clogged nozzle; Air in pump	Ensure water faucet is fully open; Clean nozzle; Bleed air from pump by running water through it without the motor on.
Water leaks	Loose connections; Damaged O-rings	Tighten all hose and gun connections; Replace worn or damaged O-rings.

SPECIFICATIONS

- **Brand:** WattFlo
- **Model Number:** WFG85AL65
- **Power Source:** Corded Electric
- **Motor:** 1800 Watt
- **Maximum Pressure:** 4200 PSI
- **Maximum Flow Rate:** 2.5 GPM
- **Hose Length:** 23 Feet
- **Power Cord Length:** 16.5 Feet
- **Foam Cannon Volume:** 500 Milliliters
- **Item Weight:** 18 Pounds
- **Product Dimensions:** 9.92"L x 10.16"W x 32.28"H
- **Color:** Green

1800W Powerful Motor



High Efficiency

Strong Power

Less Noise

Image: An illustration showcasing the 1800W powerful motor, highlighting its high efficiency, strong power, and less noise.

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your product or visit the official WattFlo website. If you require technical assistance or have questions regarding your pressure washer, please contact WattFlo customer support through the channels provided on their official website or product packaging.