

[Manuals.plus](#) /

› [BOUNTECH](#) /

› BOUNTECH Inflatable Music Castle Bounce House with 480W Blower User Manual

BOUNTECH NP11961, S-4

BOUNTECH Inflatable Music Castle Bounce House with 480W Blower User Manual

Model: NP11961, S-4

1. INTRODUCTION AND OVERVIEW

This manual provides essential instructions for the safe setup, operation, and maintenance of your BOUNTECH Inflatable Music Castle Bounce House. This product is designed for children aged 3-12 years, offering multiple play activities including jumping, sliding, a ball pit, and a basketball hoop. It is suitable for both indoor and outdoor use.

Let Kids' Imagination Run Wild in the Inflatable Castle



Image 1.1: The BOUNTECH Inflatable Music Castle Bounce House set up for play both indoors and outdoors.



Image 1.2: Children enjoying the various features of the bounce house, including the slide, jumping area, and ball pit, in an outdoor setting.

2. SAFETY INFORMATION

Adherence to all safety guidelines is crucial to prevent injury. Always supervise children during use.

2.1 General Safety Guidelines

- Recommended age for users: 3 to 12 years.
- Individual weight limit: 100 lbs (45 kg).
- Maximum weight limit for the inflatable part: 200 lbs (90 kg).
- Maximum number of users: 3 children simultaneously.
- Ensure the jumping area is surrounded by a breathable mesh wall for visibility and safety.
- Verify that slides have heightened guardrails and an extended, cushioned landing platform.
- Keep the blower running continuously while the bounce house is in use.
- Do not allow children to wear shoes, glasses, or sharp objects while playing.

- Keep away from fire and other heat sources.




Image 2.1: Visual representation of recommended age (3-12 years), individual weight limit (100 lbs), and total weight limit (200 lbs) for the inflatable structure.

2.2 Material and Construction Safety

- Constructed from premium, wear-resistant 420D Oxford fabric.
- High-stress areas, such as the jumping surface, are reinforced with ultra-tough PVC lamination.
- All critical seams are double-stitched and electronically welded for durability and air retention.

We Care All the Details



Premium 420D Oxford Cloth



Waterproof



Abrasion Resistant



Tear Resistant



Colorfast



**Mesh
Protective Wall**



Double Stitching



**Accessible
Climbing Door**

Image 2.2: Close-up details highlighting the premium 420D Oxford cloth, mesh protective wall, double stitching, and accessible climbing door, all contributing to product safety and durability.

3. SETUP INSTRUCTIONS

The BOUNTECH Inflatable Music Castle Bounce House is designed for quick and easy setup, typically within 3 minutes.

3.1 Unfolding and Placement

1. Choose a flat, clear area for placement, free from sharp objects or debris.
2. Unfold the bounce house completely on the chosen surface.

3.2 Blower Connection and Inflation

3. Locate the air outlet on the bounce house and fasten it securely to the included 480W air blower.
4. Ensure all other air outlets are closed.
5. Plug in the 480W air blower and turn it on. The bounce house will inflate rapidly.

3.3 Anchoring

6. Once fully inflated, use the provided ground stakes to anchor the bounce house firmly to the ground. Use additional blower stakes for the blower if necessary.



Image 3.1: Illustrated steps for setting up the bounce house, including unfolding, connecting the blower, and anchoring with ground stakes.

3.4 Included Components

The complete package includes:

- 1 x Inflatable Bounce House
- 1 x Carrying Bag
- 4 x Ground Stakes
- 1 x Repair Kit
- 1 x 480W Air Blower


Complete Accessories



1 x Inflatable Bounce House



1 x Carrying Bag



4 x Ground Stakes



1 x Repair Kit



1 x 480W Air Blower

Image 3.2: A display of all components included in the package: the inflatable bounce house, carrying bag, ground stakes, repair kit, and 480W air blower.

4. OPERATING INSTRUCTIONS

Once fully inflated and secured, the bounce house is ready for use. Ensure continuous supervision of children.

4.1 Play Activities

- **Jumping Area:** Children can safely jump and bounce within the enclosed area.
- **Slide:** The integrated slide allows for thrilling descents. Ensure children slide feet-first.
- **Ball Pit:** A vibrant ball pit provides an additional area for discovery and play.
- **Basketball Hoop:** An attached basketball hoop allows for interactive play and skill development.

4.2 Indoor and Outdoor Use

The bounce house is versatile for both indoor and outdoor environments. For indoor use, ensure adequate space and a soft surface underneath. For outdoor use, always anchor the unit securely.

Your browser does not support the video tag.

Video 4.1: An official product video demonstrating children playing safely in the BOUNTECH Inflatable Music Castle Bounce House, showcasing its various features and suitability for both indoor and outdoor environments.

5. MAINTENANCE

Proper maintenance ensures the longevity and safety of your bounce house.

5.1 Cleaning

- After each use, especially outdoors, wipe down the surfaces with a damp cloth and mild soap.
- Ensure the bounce house is completely dry before deflating and storing to prevent mold and mildew.

5.2 Storage

- Deflate the bounce house completely.
- Roll it neatly and place it into the included heavy-duty carry bag.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.

5.3 Repairs

- Use the provided repair kit for small punctures or tears. Follow the instructions included with the repair kit.
- For larger damage, contact customer support for assistance.

6. TROUBLESHOOTING

If you encounter issues with your bounce house, refer to these common solutions.

6.1 Insufficient Inflation

- **Check Blower:** Ensure the 480W blower is securely attached and powered on.
- **Check Air Outlets:** Verify that all air outlets on the bounce house are properly closed, except for the one connected to the blower.
- **Inspect for Leaks:** Examine the bounce house for any visible tears or punctures. Use the repair kit for minor damage.

6.2 Stability Issues

- **Ground Stakes:** Ensure all ground stakes are firmly inserted into the ground.
- **Level Surface:** Confirm the bounce house is placed on a flat and level surface.

7. SPECIFICATIONS

Feature	Detail
Brand	BOUNTECH
Model Number	NP11961, S-4
Dimensions (L x W x H)	116.5" x 73.5" x 73.5" (295.9 cm x 186.7 cm x 186.7 cm)
Item Weight	23 Pounds (10.4 kg)

Feature	Detail
Material Type	420D Oxford, PVC
Recommended Age	36 - 120 Months (3 - 10 Years)
Individual Weight Limit	100 lbs (45 kg)
Total Weight Limit (Inflatable Part)	200 lbs (90 kg)
Number of Players	Up to 3
Color	Multicolor
Theme	Music Indoor Play
Included Components	Inflatable Bouncer Set with Blower, Stakes, and Repair Kit (4 Piece)

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact BOUNTECH customer service directly. Keep your purchase receipt for any warranty claims.