

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [advwin](#) /

› [Advwin 22-inch Ride-On Luggage with Seat for Kids & Adults Instruction Manual](#)

advwin US890201

Advwin 22-inch Ride-On Luggage with Seat Instruction Manual

Model: US890201

INTRODUCTION

Thank you for choosing the Advwin 22-inch Ride-On Luggage. This manual provides essential information for the safe and efficient use, setup, and maintenance of your new luggage. Please read these instructions carefully before use and retain them for future reference.

PRODUCT FEATURES

- Size Recommendation:** The 22-inch size is generally suited for checked baggage. For carry-on, the 20-inch size is recommended to comply with most airline restrictions. Always verify specific airline requirements.
- Spacious and Versatile:** Offers a 64L capacity with dimensions of 21.8 x 16.7 x 12 inches and a weight of 11.7 lbs.
- Front-Open Design:** Allows quick, one-hand access to items without fully opening the main compartment. Features a durable all-aluminum 3-stage telescoping handle and a built-in TSA lock.
- Heavy-Duty & Comfy Seat:** Integrated seat supports up to 200 lbs, suitable for both children and adults. Includes a foldable seat back and a safety seatbelt. A bag hook is also provided for convenience.
- Shock Absorption:** Equipped with four 360° spinner wheels with an integrated braking system and shock-absorbing design for smooth, stable movement.
- Smart Storage:** Interior features breathable mesh pockets, wet-dry compartments, and secure zippered sections. Includes a built-in USB charging port for on-the-go device charging.

SETUP

1. Unpacking

Carefully remove the luggage from its packaging. Inspect for any damage. The luggage may come with a protective cover; remove it before first use.

2. Handle Extension

To extend the telescoping handle, press the button located on the top of the handle and pull upwards. Release the button to lock the handle at your desired height. Ensure it clicks securely into place.

3. Seat Deployment

To deploy the seat, lift the seat back from its folded position until it locks upright. Ensure it is stable before use. To fold, press the release mechanism (if present) and gently push the seat back down until it is flush with the luggage top.

4. Setting the TSA Combination Lock

Your luggage is equipped with a TSA-approved combination lock. The initial factory setting is usually 0-0-0.

1. Set the dials to the initial combination (0-0-0).
2. Locate the reset button (a small, recessed button, often requiring a pen tip to press). Press and hold this button.
3. While holding the reset button, set your desired 3-digit combination by turning the dials.
4. Release the reset button. Your new combination is now set. Remember your combination.




Image: Detailed steps for setting the TSA combination lock, showing the initial setting, reset button, and dial adjustment.

OPERATING INSTRUCTIONS

1. Using the Ride-On Seat

Ensure the luggage is on a flat, stable surface and the wheel brakes are engaged before anyone sits on it. For children, always use the provided seatbelt for safety. The seat is designed for temporary resting during travel, not for continuous riding or rough terrain.



360°Wheels with Brakes & Shock Absorption



All-Aluminum 3-Stage Handle



USB Charging Port



Built in TSA Lock

Image: A teddy bear is shown secured in the luggage seat with a seatbelt, highlighting the foldable seat back and the bag hook feature.

2. Maneuvering the Luggage

The 360° spinner wheels allow for effortless gliding in any direction. To engage the brakes, press down on the lever located on each wheel. This will prevent the luggage from rolling, especially when using the seat. Disengage the brakes by lifting the levers before moving.



Foldable Built-in Seat Back



Bag Hook on Seat Back



Seat Belt for Stability and Safety



Image: A detailed view of the luggage wheels, showcasing their 360-degree rotation capability, shock absorption, and the brake mechanism for stability.

3. Accessing the Front Compartment

To open the front compartment, unlock the TSA lock and gently pull the front panel outwards. This provides quick access to frequently needed items without exposing the main contents of your luggage.

Front-Open Design for Easy Access



Front Opening

- ✓ Quick Access: One-hand grab, no fuss.
- ✓ Stay Organized: No mess, no spills.
- ✓ Light & Easy: Top lid lifts effortlessly.



Clamshell Opening

- ✗ Cumbersome: Takes time and effort.
- ✗ Shifts Easily: Items move around.
- ✗ Prone to Spills: Things might fall out.

Image: The luggage is displayed with its front panel open, revealing various mesh and zippered pockets for organized storage and easy access to items.

4. Using the USB Charging Port

Locate the built-in USB port on the side of the luggage. Connect your power bank (not included) to the internal cable and your device to the external port. This allows you to charge your devices conveniently while traveling.

5. Internal Organization

Utilize the breathable mesh pockets, wet-dry compartments, and zippered sections to keep your belongings organized and separated. This helps maximize space and prevent items from shifting during transit.

64L Large Capacity with Smart Organization



Image: The interior of the luggage is shown, highlighting its 64L capacity with various organizational features like breathable mesh pockets, wet-dry separation, and zippered compartments.

6. Video Demonstration

Watch this official product video for a visual guide on the features and operation of your Advwin Ride-On Luggage.

Your browser does not support the video tag.

Video: An official demonstration of the Advwin carry-on luggage with seat, showcasing its features including the hardshell, spinner wheels, brakes, foldable seat, and internal organization. (Duration: 0:45)

MAINTENANCE

- Cleaning:** Wipe the exterior with a soft, damp cloth and mild soap. For the interior, use a damp cloth to clean mesh and fabric surfaces. Do not use harsh chemicals or abrasive cleaners.
- Wheel Care:** Periodically check the wheels for debris or hair. Clean as needed to ensure smooth rolling. Avoid exposing wheels to excessive dirt or sand.
- Lock Maintenance:** Ensure the TSA lock dials move freely. If they become stiff, a small amount of lubricant can be applied.

- **Storage:** Store the luggage in a dry, cool place away from direct sunlight when not in use.

TROUBLESHOOTING

- **Wheels not rolling smoothly:** Check for debris caught in the wheels. Clean thoroughly. Ensure brakes are fully disengaged.
- **Handle sticking:** Ensure no items are obstructing the handle mechanism inside the luggage. Apply a silicone-based lubricant if necessary.
- **TSA Lock not opening:** Double-check your combination. If forgotten, contact customer support for assistance (note: TSA agents can open with a master key, but you will need your combination for personal access).
- **USB port not charging:** Ensure your power bank is fully charged and correctly connected to the internal cable. Verify your device is properly connected to the external port.

SPECIFICATIONS

Feature	Detail
Model Number	US890201
Product Dimensions	16.7 x 12 x 21.8 inches
Item Weight	11.7 pounds
Capacity	64 Liters
Material	Hardside (ABS + PC)
Wheels	Four 360° Spinner Wheels with Brakes
Handle	All-Aluminum 3-Stage Telescoping Handle
Lock Type	Built-in TSA Combination Lock
Additional Features	Foldable Seat, Safety Seatbelt, Bag Hook, USB Charging Port

22"

Volume **64L**

Weight **11.7LBS**



Airline-Approved

Carry on Size for Most Airline Compartments (Please Confirm with Your Airline)

Image: A visual representation of the luggage dimensions, indicating a height of 21.8 inches, width of 16.7 inches, and depth of 12 inches, along with its 64L volume and 11.7 lbs weight.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or visit the official Advwin website. Keep your purchase receipt as proof of purchase.