

18-16921

Instruction Manual

GENERIC BBURAGO FERRARI DAYTONA SP3 CARBON SERIES DIECAST MODEL CAR 1:18 SCALE (MODEL 18-16921)

[Introduction](#)

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. Introduction

This manual provides essential information for the proper handling, display, and care of your Generic Bburago Ferrari Daytona SP3 Carbon Series 1:18 Scale Diecast Model Car, model number 18-16921. This limited edition replica celebrates Bburago's 50th anniversary and features meticulous detailing of the iconic Ferrari Daytona SP3.

Please read this manual thoroughly to ensure the longevity and pristine condition of your collectible model.

2. Setup and Display

Upon receiving your diecast model, carefully remove it from its packaging. The model is typically secured within a protective box and may be attached to a display base.



Figure 2.1: The Ferrari Daytona SP3 diecast model car shown in its original packaging, highlighting the 50th Anniversary Carbon Series branding. The packaging protects the model during transit and provides initial presentation.

1. **Unboxing:** Gently open the outer carton. Remove any protective foam or plastic inserts.
2. **Model Removal:** Carefully lift the model from its inner tray or base. Some models may be secured with small screws or twist ties; untwist or unscrew these carefully if present. Avoid forcing the model.
3. **Base Attachment:** The model comes with a display base. Ensure the model is securely placed on the base. The base provides stability and enhances the display.
4. **Placement:** Choose a stable, flat surface for display, away from direct sunlight, extreme temperatures, and high humidity. Direct sunlight can cause paint fading over time.



Figure 2.2: The Ferrari Daytona SP3 diecast model car securely placed on its black display base. This view showcases the matte carbon fiber-style finish and the vehicle's overall design.

3. Operating and Interaction

This diecast model is primarily for display. While it features some interactive elements, handle them with care to prevent damage.

- **Opening Doors:** The model features opening doors. Gently use a fingernail or a soft, thin tool to pry open the doors from the seam. Avoid excessive force.
- **Interior View:** Once the doors are open, you can observe the detailed interior. Close the doors gently until they click into place.
- **Wheel Movement:** The wheels are designed to roll. However, this model is not intended for vigorous play. Rolling it on rough surfaces or applying excessive pressure can damage the axles or wheels.
- **Steering:** Some diecast models may have functional steering. If present, gently turn the front wheels to adjust their angle. Do not force the steering mechanism.

Note: This is a collectible item, not a toy. Rough handling can lead to breakage of delicate parts.

4. Maintenance and Care

Proper maintenance ensures your diecast model retains its aesthetic value and condition.

- **Cleaning:** Dust is the primary concern for display models. Use a soft, dry microfiber cloth or a soft brush (like a makeup brush) to gently remove dust from the surface. For intricate areas, use compressed air from a safe distance.
- **Stubborn Marks:** For fingerprints or light smudges, lightly dampen a microfiber cloth with water (distilled water is preferred to avoid mineral deposits) and gently wipe the affected area. Avoid harsh chemicals, abrasive cleaners, or solvents, as these can damage the paint finish.
- **Storage:** If storing the model for an extended period, place it back in its original packaging or a sealed display case to protect it from dust and environmental factors.
- **Handling:** Always handle the model by its main body, avoiding delicate parts like mirrors, spoilers, or antennas.

5. Troubleshooting

Here are solutions to common issues you might encounter with your diecast model.

Issue	Possible Cause	Solution
Dust accumulation	Exposure to open air, lack of regular cleaning.	Gently wipe with a soft microfiber cloth or use compressed air. Consider a display case.
Loose or detached small parts (e.g., mirror)	Accidental impact, rough handling, manufacturing defect.	If a clean break, a small amount of model-specific clear adhesive can be used. Apply sparingly with a toothpick.
Doors not closing flush	Misalignment, debris in hinge.	Gently adjust the door. Check for any obstructions in the hinge mechanism. Do not force.
Paint fading or discoloration	Prolonged exposure to direct sunlight or harsh chemicals.	Relocate the model away from direct sunlight. Avoid chemical cleaners. This damage is often irreversible.

6. Specifications

- **Model:** Ferrari Daytona SP3
- **Model Number:** 18-16921

- **Brand:** Generic (Compatible with Bburago)
- **Scale:** 1:18
- **Collection Name:** Carbon Series, 50th Anniversary Limited Edition
- **Material:** Metal (Die-cast)
- **Color:** Carbon (Matte finish)
- **Product Dimensions:** Approximately 10 x 5 x 3 inches (25.4 x 12.7 x 7.6 cm)
- **Item Weight:** Approximately 2 pounds (0.91 kg)
- **Features:** Opening doors, detailed interior, display base.
- **Recommended Use:** Collectible display item.
- **Care Instructions:** Wipe Clean.

7. Warranty and Support

As a collectible diecast model, specific warranties may vary depending on the retailer and region of purchase. Please refer to your purchase receipt or the retailer's policy for details regarding returns or defects.

For product support or inquiries regarding manufacturing defects, please contact the retailer from whom the product was purchased. Keep your proof of purchase for any warranty claims.

This product is intended for display and collecting purposes and is not designed for rigorous play. Damage resulting from improper handling or use is typically not covered under warranty.