

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [HPRT](#) /

› [HPRT CP2100 Photo Paper & Ink Ribbon User Manual](#)

HPRT XT-C5386

HPRT CP2100 Photo Paper & Ink Ribbon User Manual

Model: XT-C5386

PRODUCT OVERVIEW

This manual provides instructions for the HPRT All-in-One Photo Paper and Ink Ribbon Cassette, designed for use with the HPRT CP2100 Mini Photo Printer. This product combines photo paper and an ink ribbon into a single, easy-to-install cartridge, ensuring high-quality, durable photo prints.

Key features include:

- **All-in-One Cartridge:** Integrated photo paper and ink ribbon for simple installation.
- **Excellent Photo Quality:** Utilizes dye-sublimation technology for accurate color reproduction and vivid prints.
- **Fade-Resistant Prints:** Photos are protected by a film layer, making them resistant to dust, water, fingerprints, and scratches, ensuring longevity.
- **Compact Size:** Each photo paper measures 53 x 86 mm, ideal for pocket-sized prints.
- **Compatibility:** Specifically designed for the HPRT CP2100 Photo Printer.







Figure 1: HPRT All-in-One Photo Paper and Ink Ribbon Cassette packaging.

SPECIFICATIONS

Brand	HPRT
Model Number	XT-C5386
Printing Method	Dye-sublimation thermal printing
Paper Surface	Glossy
Sheet Dimensions	53 x 86 mm
Sheets per Pack	10 sheets/pack, 2 packs (Total 20 sheets)
Compatibility	HPRT CP2100 Photo Printer
Item Weight	110 grams

53*86mm Photo Size



Contains two ribbons, one ribbon contains 10 sheets of photo paper, a total of 20 sheets of photo paper

Figure 2: Dimensions of the photo paper (53x86mm) and the two integrated cartridges included in the pack.



Figure 3: A closer look at the two HPRT all-in-one photo paper and ink ribbon cartridges.

SETUP AND INSTALLATION

The HPRT All-in-One Photo Paper and Ink Ribbon Cassette is designed for easy installation into your HPRT CP2100 Mini Photo Printer.

- 1. Prepare the Printer:** Ensure your HPRT CP2100 printer is powered off and the paper tray cover is open.
- 2. Insert the Cartridge:** Gently slide the all-in-one photo paper and ink ribbon cassette into the designated slot on the side of the HPRT CP2100 printer. Ensure it clicks firmly into place. The arrows on the cartridge and printer should align.
- 3. Close the Cover:** Close the paper tray cover securely.
- 4. Power On:** You can now power on your HPRT CP2100 printer and proceed with printing.

easy use

Only compatible with CP2100



Figure 4: Step-by-step illustration of inserting the all-in-one cartridge into the HPRT CP2100 printer. The arrows indicate the correct insertion direction.

OPERATING INSTRUCTIONS

Once the photo paper and ink ribbon cassette is installed, you can begin printing with your HPRT CP2100 printer.

- Connect to Printer:** Ensure your smartphone or device is connected to the HPRT CP2100 printer via Bluetooth 5.0. Refer to your CP2100 printer's manual for detailed connection instructions.
- Select Photo:** Open the HPRT companion application on your device and select the photo you wish to print.
- Print:** Initiate the print command from the application. The printer will automatically process the image and print it using the dye-sublimation technology.
- Retrieve Print:** Once printing is complete, carefully retrieve your photo from the printer's output slot. The photo will have a protective film layer applied during the printing process.

True-to-Life Color Printing dye Sublimation Printer




Figure 5: The HPRT CP2100 printer in operation, demonstrating its ability to produce true-to-life color prints using the dye-sublimation process.

Capture every precious moment

Long-lasting color, as gorgeous as ever




Figure 6: Examples of photos printed with the HPRT CP2100 printer and the all-in-one photo paper, showcasing the ability to capture precious moments with long-lasting color.

MAINTENANCE AND CARE

To ensure the longevity and quality of your prints and the photo paper/ink ribbon cassette, follow these care guidelines:

- Storage:** Store unused cassettes in a cool, dry place away from direct sunlight and extreme temperatures.
- Handling:** Avoid touching the printing surface of the photo paper or the ink ribbon directly to prevent smudges or damage.
- Protective Film:** The printed photos are automatically covered with a protective film. Do not attempt to remove this film as it provides resistance against water, dust, fingerprints, and fading.
- Disposal:** Dispose of empty cartridges according to local regulations for electronic waste or plastic recycling.

High quality photo paper



Waterproof



Anti-fingerprint



Anti-oxidation



Dustproof



Plastic-free seal

Figure 7: Illustration of the multi-layered HPRT photo paper, highlighting its waterproof, anti-fingerprint, anti-oxidation, dustproof, and plastic-free seal properties.

TROUBLESHOOTING

This section addresses common issues you might encounter with the HPRT photo paper and ink ribbon cassette.

- **Poor Print Quality:**

- Ensure the cassette is fully inserted into the printer.
- Check if the cassette is empty and needs replacement.
- Verify that the photo file quality is high resolution.

- **Cassette Not Recognized:**

- Remove and re-insert the cassette, ensuring it clicks into place.
- Confirm that you are using an authentic HPRT XT-C5386 cassette.

- **Paper Jam:**

- Power off the printer immediately.
- Carefully open the printer cover and gently remove any jammed paper or cassette. Do not force it.
- Ensure the paper is loaded correctly and not bent or damaged.

If issues persist, please refer to your HPRT CP2100 printer's user manual or contact HPRT customer support.

WARRANTY AND SUPPORT



Specific warranty information for the HPRT All-in-One Photo Paper and Ink Ribbon Cassette (Model XT-C5386) is typically provided with the HPRT CP2100 Mini Photo Printer or on the official HPRT website.

For technical support, product inquiries, or warranty claims, please visit the official HPRT website or contact their customer service department. Keep your purchase receipt as proof of purchase.

© 2024 HPRT. All rights reserved.

This manual is for informational purposes only. HPRT reserves the right to make changes to product specifications without prior notice.

Related Documents - XT-C5386

	<p><u>HPRT CP4100 Photo Printer User Guide</u></p> <p>User guide for the HPRT CP4100 Photo Printer, covering product introduction, setup, operation, and technical specifications.</p>
	<p><u>HPRT MT53 Quick Start Guide: Printing Photos from Your Phone</u></p> <p>A concise guide to setting up and using the HPRT MT53 photo printer, including paper loading, device connection via Bluetooth, and printing instructions through the mobile app.</p>
	<p><u>HPRT CP4100 Photo Printer Quick Start Guide and Setup</u></p> <p>Learn how to set up and use the HPRT CP4100 Photo Printer. This guide covers connecting power, loading paper and ribbon cassettes, printer operation, LED indicators, and mobile printing via Wi-Fi.</p>
	<p><u>HPRT MT610 Mobile Printer User Manual and Guide</u></p> <p>Comprehensive guide for the HPRT MT610 mobile printer, covering installation, operation, wireless printing from mobile devices and PCs, battery charging, LED indicator definitions, and product specifications.</p>

<p>Mobile Printer MT800 User Manual</p>  <p>Ver 1.0</p> <p>Manufacturer: Shenzhen Huirui Electronic Technology Co., Ltd. Add: No.10, Beiguanqian, Teng'an District, Shenzhen, China 518220 E-mail: support@hprt.com Web: www.hprt.com</p>	<p><u>HPRT MT800 Mobile Printer User Manual</u></p> <p>Comprehensive user manual for the HPRT MT800 A4 mobile printer, covering installation, operation, troubleshooting, and specifications. Learn how to set up and use your mobile printer effectively.</p>
 <p>MT810</p>	<p><u>HPRT MT810 Mobile Printer: Quick Start Guide and User Manual</u></p> <p>Comprehensive guide for the HPRT MT810 mobile printer, covering product introduction, loading paper, power on, printing from Windows PC and mobile devices, battery charging, LED indicators, and product specifications.</p>