

GASLAND BR60SS

GASLAND BR60SS 60cm Integrated Range Hood User Manual

Model: BR60SS

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your GASLAND BR60SS 60cm Integrated Range Hood. Please read this manual thoroughly before installation and use, and keep it for future reference.

2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury. This appliance is intended for domestic use only.

- Ensure the power supply matches the rating label on the appliance.
- Installation must be performed by a qualified technician in accordance with local regulations.
- Do not operate the appliance if the power cord or plug is damaged.
- Regularly clean the filters to prevent grease buildup, which can be a fire hazard.
- Maintain adequate ventilation in the room when the range hood is used simultaneously with gas or other fuel-burning appliances.
- Do not flambé under the range hood.

3. SETUP AND INSTALLATION

The GASLAND BR60SS range hood offers flexible installation options: either mounted on the wall above the cooking surface or integrated under a suspended cabinet.

3.1 Unboxing and Components

Carefully unpack the range hood and check all components against the packing list. Ensure no parts are missing or damaged.

567 m³/h Saugleistung

Maximale Luftleistung 567 m³/h, 4 Stufen inkl. Boost-Modus.



Image: The GASLAND BR60SS range hood and its included components after unboxing.

3.2 Mounting Options

The hood can be installed in two configurations: extraction mode (ducted) or recirculation mode (ductless, with active carbon filter).





Image: Comparison of recirculation mode (Umluftbetrieb) with charcoal filter and extraction mode (Abluftbetrieb) with exhaust duct.

3.3 Dimensions and Placement

Refer to the dimension diagram for precise measurements and ensure adequate clearance above your cooking surface. The hood is 60 cm wide.



Längeneinheit: Millimeter

Image: Detailed dimension diagram of the range hood in millimeters for installation planning.

3.4 Installation Video

For a visual guide on the installation process, please refer to the official product video:

Video: Official product video demonstrating the features and potentially the installation of GASLAND range hoods.

4. OPERATING INSTRUCTIONS

The GASLAND BR60SS features a user-friendly touch control panel for easy operation.



Image: Close-up view of the integrated touch control panel and LED lighting on the range hood.

4.1 Power and Speed Settings

The hood offers 3 speed levels and a Boost function for powerful extraction up to 566 m³/h. Use the touch controls to select the desired speed.

Mehrlagiger Filter

4x Aluminium + 1x Edelstahl –
bessere Fettabcheidung für eine saubere Küche.



Image: Visual representation of the four suction power levels, including the Boost mode, for effective fume removal.

4.2 Memory Function

The memory function automatically restores the previously set speed and light levels when the sliding plate is extended.

4.3 LED Lighting

The integrated LED lighting illuminates your cooking area, enhancing visibility. Control the lighting via the touch panel.

5. MAINTENANCE AND CLEANING

Regular maintenance ensures optimal performance and longevity of your range hood.

5.1 Grease Filter Cleaning

The aluminum grease filters should be cleaned regularly (approximately every 2-4 weeks, depending on usage) to maintain efficiency. They can be washed by hand with warm soapy water or in a dishwasher.

5.2 Active Carbon Filter Replacement (Recirculation Mode)

If operating in recirculation mode, the active carbon filter (CF176) needs to be replaced periodically (typically every 3-6 months, depending on usage). Refer to the filter replacement instructions provided with the filter or contact customer support for guidance.

5.3 Exterior Cleaning

Clean the exterior of the range hood with a soft cloth and a mild, non-abrasive detergent. Avoid using harsh chemicals or abrasive cleaning tools that could damage the stainless steel finish.

6. TROUBLESHOOTING

If you encounter any issues with your range hood, please consult the following common troubleshooting steps before contacting customer service.

- **No power:** Check if the appliance is properly plugged in and if the circuit breaker has tripped.
- **Low suction power:** Ensure the grease filters are clean and not clogged. If in recirculation mode, check if the active carbon filter needs replacement. Verify that the exhaust duct (if applicable) is not obstructed.
- **Excessive noise:** Check for loose parts or improper installation. Ensure the fan blades are clean and free from obstructions.
- **Lights not working:** Check if the LED lights are properly connected. If individual bulbs are replaceable, check for burnt-out bulbs.

If the problem persists after performing these checks, please contact GASLAND customer support.

7. SPECIFICATIONS

Feature	Specification
Brand	GASLAND
Model	BR60SS
Dimensions (P x L x H)	42P x 60l x 28H cm
Color	Stainless Steel
Airflow Capacity	566 m³/h (Boost)
Noise Level	59 Decibels
Control Type	Touch Control
Number of Speeds	4 (including Boost)
Lighting Type	LED
Power (Watts)	73 Watts
Voltage	220 Volts (AC)
Filter Type	Active Carbon (CF176 included)
Ventilation Type	Recirculation / Extraction

Energieeffizient

Sparen Sie Energie und sorgen Sie für zusätzliche Beleuchtung Ihres Herdes.



Image: The energy efficiency rating of A++ for the GASLAND BR60SS range hood.

8. WARRANTY AND SUPPORT

Your GASLAND BR60SS range hood comes with a standard manufacturer's warranty. Please refer to the warranty card included in the packaging for specific terms and conditions.

For technical support, spare parts, or warranty claims, please contact GASLAND customer service through their official website or the contact information provided in your product documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question