



Manuals.plus /

› Alpina /

› Alpina Table Charcoal Grill User Manual

## Alpina 8711252502458

# Alpina Table Charcoal Grill User Manual

Model: 8711252502458

## INTRODUCTION

---

Thank you for purchasing the Alpina Table Charcoal Grill. This compact and portable grill is designed for convenient outdoor cooking in various settings, including gardens, balconies, and picnics. Its stainless steel construction ensures durability and ease of cleaning. Please read this manual carefully before assembly and use to ensure safe and optimal performance.

## SAFETY INSTRUCTIONS

---

Always prioritize safety when operating any charcoal grill. Failure to follow these instructions may result in fire, injury, or property damage.

- **Outdoor Use Only:** This grill is designed for outdoor use in a well-ventilated area. Do not use indoors or in enclosed spaces.
- **Stable Surface:** Always place the grill on a stable, level, non-combustible surface away from flammable materials.
- **Keep Away from Children and Pets:** Ensure children and pets are kept at a safe distance from the hot grill.
- **Use Appropriate Fuel:** Only use charcoal as fuel. Do not use gasoline, kerosene, or alcohol for lighting or relighting.
- **Fire Safety:** Keep a fire extinguisher or a bucket of sand/water nearby in case of emergencies.
- **Hot Surfaces:** Grill surfaces become extremely hot during use. Use heat-resistant gloves and tools.
- **Ash Disposal:** Allow ashes to cool completely before disposing of them. Never dispose of hot ashes in combustible containers.

## PRODUCT COMPONENTS

---



Figure 1: Fully assembled Alpina Table Charcoal Grill. This image shows the compact black grill body, the stainless steel grill grate, and the integrated handles on the sides. The sturdy wire legs are visible at the base, and a small air vent hole is present on the side of the grill body.

The Alpina Table Charcoal Grill typically includes the following components:

- Grill Body (Black, Metal)
- Stainless Steel Grill Grate (Diameter approx. 32 cm)
- Charcoal Grate (often integrated or separate, for holding charcoal)
- Integrated Handles
- Sturdy Wire Legs

Please inspect all components upon unpacking to ensure nothing is missing or damaged.

## SETUP

---

The Alpina Table Charcoal Grill is designed for minimal assembly. Follow these steps for initial setup:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Position Legs:** Ensure the sturdy wire legs are fully extended and locked into position, providing a stable base for the grill.
3. **Insert Charcoal Grate:** Place the charcoal grate (if separate) at the bottom of the grill body. This grate supports the

charcoal and allows for airflow.

4. **Place Grill Grate:** Position the stainless steel grill grate on top of the grill body, ensuring it sits securely.
5. **Location:** Choose a safe, level, non-combustible outdoor location, away from any flammable structures, overhanging trees, or dry vegetation.

## OPERATING INSTRUCTIONS

---

Follow these steps for safe and effective grilling:

1. **Add Charcoal:** Place a single layer of charcoal briquettes or lump charcoal onto the charcoal grate. Do not overfill.
2. **Light Charcoal:** Use a charcoal chimney starter or solid firelighters to ignite the charcoal. Never use lighter fluid or other flammable liquids. Allow charcoal to ash over (turn grey) before cooking. This typically takes 15-20 minutes.
3. **Preheat Grill Grate:** Once the charcoal is ready, place the stainless steel grill grate over the hot coals. Allow it to preheat for a few minutes to reach optimal cooking temperature and to burn off any residue.
4. **Clean Grate:** Use a grill brush to clean the preheated grate before placing food on it.
5. **Place Food:** Carefully place food on the grill grate using long-handled tongs or spatulas.
6. **Cooking:** Monitor cooking progress. Adjust food placement for even cooking. The small air vent hole on the side helps with airflow; ensure it is not blocked.
7. **Extinguishing:** Once cooking is complete, allow the charcoal to burn out naturally. Do not use water to extinguish hot charcoal, as this can create steam and damage the grill.

## MAINTENANCE AND CLEANING

---

Regular cleaning and maintenance will extend the life of your grill and ensure safe operation.

- **After Each Use:**
  - Allow the grill to cool completely.
  - Scrape off any food residue from the grill grate using a grill brush.
  - Remove cooled ashes from the grill body.
- **Deep Cleaning:**
  - The stainless steel grill grate can be washed with warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry completely to prevent rust.
  - Wipe the grill body with a damp cloth. For stubborn stains, use a mild detergent. Avoid abrasive cleaners or scouring pads that could damage the finish.
- **Storage:** Store the grill in a dry, covered area when not in use to protect it from the elements and prolong its lifespan.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Charcoal not lighting or staying lit	Insufficient airflow; damp charcoal; improper lighting method.	Ensure air vent is clear; use dry charcoal; use a charcoal chimney starter.
Food sticking to grill grate	Grill grate not preheated; insufficient oil on grate or food.	Preheat grate thoroughly; lightly oil grate or food before placing on grill.
Grill unstable	Legs not fully extended/locked; uneven surface.	Ensure legs are securely locked; move grill to a flat, stable surface.

## SPECIFICATIONS

---

- **Brand:** Alpina
- **Model Number:** 8711252502458
- **Product Dimensions:** 12.6"D x 12.6"W x 12.6"H (approx. 32 cm diameter, 26 cm height)
- **Fuel Type:** Charcoal
- **Material:** Metal (Grill Body), Stainless Steel (Grill Grate, Handle Material, Frame Material)
- **Color:** Black
- **Item Weight:** 4.18 pounds (approx. 1.9 Kilograms)
- **Special Features:** Portable, Rust Resistant, Corrosion Resistant
- **Assembly Required:** No
- **Included Components:** 1 x table charcoal grill

## WARRANTY AND SUPPORT

---

This Alpina Table Charcoal Grill comes with a **2-Year Warranty** from the date of purchase.

For warranty claims, technical support, or inquiries regarding your product, please contact Alpina customer service. Keep your proof of purchase for warranty validation.

*Note: Warranty does not cover damage caused by misuse, neglect, unauthorized modifications, or normal wear and tear.*

