

Robo Alive 71153

Robo Alive Fossil Find Amber Adventure T-REX Instruction Manual

Brand: Robo Alive | **Model:** 71153

1. PRODUCT OVERVIEW

Embark on an exciting journey with the Robo Alive Fossil Find Amber Adventure. This interactive toy allows you to delve into layers of rock and sand to unearth hidden dinosaur fossils and enchanting amber eggs. Assemble the discovered fossils to bring your dinosaur to life with stunning light-up features. This kit provides the thrill of discovery and the fun of collecting and building unique dinosaurs.

- **Excavation Fun:** Smash the egg and dig through dirt, slime, and amber to uncover dinosaur bones.
- **Fossil Discovery:** Find fossilized remains of prehistoric dinosaurs and amber treasures.
- **Interactive Assembly:** Connect the fossil pieces to build your dinosaur skeleton.
- **Light-Up Features:** Assembled dinosaur skeletons feature light-up eyes.



The fully assembled T-REX dinosaur skeleton with its light-up eyes.

2. WHAT'S INCLUDED

Your Robo Alive Fossil Find Amber Adventure kit contains the following components:

- Large Dinosaur Egg (containing excavation materials and dinosaur parts)
- Excavation Tool (hammer/pickaxe)
- Dino Slime
- Fossil Foam / Sand
- Amber Eggs with Baby Dinosaurs
- Dinosaur Fossil Pieces (for T-REX)
- Instruction Manual



An overview of the kit's contents, showing the large egg, excavation tools, slime, foam, and dinosaur parts.

3. SETUP AND ASSEMBLY

3.1 Unboxing the Egg

1. Carefully remove the outer packaging from the large dinosaur egg.
2. Use the provided excavation tool (hammer) to gently crack open the outer shell of the egg.
3. Once opened, you will find various materials and components inside.

3.2 Excavating Fossils and Surprises

1. Spread a protective layer (e.g., newspaper or plastic sheet) on your play surface to contain any mess.
2. Begin digging through the fossil foam and sand using the excavation tool to uncover dinosaur bone pieces.

3. Locate the Dino Slime and carefully remove any hidden bone pieces from within it.
4. Open the small amber eggs to reveal the baby dinosaur surprises.

3.3 Assembling the T-REX Dinosaur

1. Identify all the T-REX fossil pieces (head, body, legs, tail).
2. Connect the body sections first, ensuring they snap securely into place.
3. Attach the legs to the main body.
4. Connect the head to the neck section.
5. Finally, attach the tail to the rear of the body. Ensure all connections are firm for stability.

COLLECT THEM ALL!



A detailed view of the T-REX skeleton, highlighting the points where pieces connect during assembly.

3.4 Battery Installation

The assembled dinosaur requires batteries for its light-up features.

1. Locate the battery compartment, typically on the underside of the dinosaur's body.
2. Using a small screwdriver (not included), open the battery compartment cover.
3. Insert 3 x LR44 batteries, ensuring correct polarity (+/-).
4. Securely close the battery compartment cover.

4. OPERATING INSTRUCTIONS

To activate the light-up eyes and roaring sound of your assembled dinosaur:

- Gently press down on the dinosaur's tail. This action will trigger the light-up eyes and sound effects.
- Release the tail to stop the effects.

5. MAINTENANCE

5.1 Cleaning

- Wipe the dinosaur skeleton and tools with a dry or slightly damp cloth. Do not immerse electronic parts in water.
- For the slime and foam, ensure they are stored in their original resealable bags or airtight containers to prevent drying out.

5.2 Storage

- Store the dinosaur and its components in a cool, dry place away from direct sunlight.
- Keep batteries out of reach of small children and remove them if the toy will not be used for an extended period.

6. TROUBLESHOOTING

- **Dinosaur parts do not stay together:** Ensure all pieces are aligned correctly and firmly snapped into their designated slots. Some parts may require a gentle but firm push.
- **Lights or sounds are not working:**
 - a. Check if the batteries are installed correctly with the proper polarity.
 - b. Replace old batteries with new LR44 batteries.
 - c. Ensure the tail mechanism is fully pressed to activate the features.
- **Slime or foam is dry:** If the slime or foam has dried out, it may not be reusable. Ensure proper storage in airtight containers after each use.

7. SPECIFICATIONS

Feature	Detail
Brand Name	Robo Alive
Toy Figure Type	Action Figure

Character	T-REX
Model Name	Dino Fossil Find Amber Adventure
Unit Count	1.0 Count
Model Number	71153
Manufacturer	ZURU
Included Components	T-REX
Material Type	Plastic
Batteries Required	Yes
Number of Batteries	3 LR44 batteries (included)
Educational Objective	Learn about paleontology, dinosaurs, and fossil hunting; foster curiosity and understanding of prehistoric life; develop fine motor skills through assembly.

8. SAFETY INFORMATION

WARNING: Choking hazard - Small pieces. Not suitable for children under 3 years due to small parts that could be swallowed.

9. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Robo Alive Fossil Find Amber Adventure T-REX, please contact ZURU customer service. Please retain your proof of purchase for warranty claims.

© 2026 Robo Alive. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question