



[Manuals.plus](#) /

> [Outsunny](#) /

> Outsunny 10' x 10' Outdoor Patio Gazebo Instruction Manual (Model 84C-051V00CW)

Outsunny 84C-051V00CW

Outsunny 10' x 10' Outdoor Patio Gazebo Instruction Manual

Model: 84C-051V00CW

1. INTRODUCTION

Thank you for choosing the Outsunny 10' x 10' Outdoor Patio Gazebo. This manual provides essential information for the safe assembly, operation, and maintenance of your gazebo. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



The Outsunny 10' x 10' Outdoor Patio Gazebo provides a shaded outdoor living space.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Always secure the gazebo to the ground using the provided stakes to prevent it from tipping over in windy conditions.
- Do not leave the gazebo up during adverse weather conditions such as heavy rain, strong winds, or thunderstorms. Dismantle or secure the canopy and frame appropriately.
- Always follow the assembly instructions for safe setup and dismantling.
- Keep children and pets away from the assembly area.
- Ensure all connections are tight and secure before use.
- Do not hang heavy objects from the gazebo frame.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning assembly. If any parts are missing or damaged, contact customer support.



Your gazebo will arrive in one package. Ensure all parts are accounted for.

The package includes:

- Reinforced Aluminum and Steel Frame components
- Two-tier Canopy Top (Water-resistant polyester with PA coating)
- Mesh Netting Sidewalls (with zippers)
- Polyester Curtains
- Ground Stakes for stability
- Assembly Hardware (bolts, nuts, washers, etc.)
- Instruction Manual

4. SETUP AND ASSEMBLY

Assembly typically requires two adults. Choose a level surface for installation. Refer to the detailed diagrams in the included manual for specific part identification and step-by-step instructions.

4.1 Frame Assembly

Connect the aluminum and steel frame components according to the numbered steps in your manual. Ensure all bolts are securely tightened. The powder-coated, rust-resistant frame is designed for durability.



The sturdy frame provides the foundation for your gazebo.

4.2 Canopy Installation

Carefully spread the two-tier canopy top over the assembled frame. The double canopy design increases breathability and provides proper ventilation. Ensure the canopy is taut and secured to the frame. The water-resistant top includes 8 built-in grommet holes for essential drainage, preventing water accumulation.


VENTED SOFT TOP



Double canopy increases breathability



Leaking holes prevent water accumulation



PA coating polyester provides effective sun protection



The vented soft top features a double canopy for breathability, grommet holes for drainage, and PA coating for sun protection.

4.3 Curtains and Mesh Sidewalls Attachment

Attach the polyester curtains and mesh sidewalls to the frame using the integrated hanging loop design. The outer curtains are made of coated polyester for sun protection, while the inner mesh fabric features 4 built-in zippers for protection against outside elements.



Double-Sided Zipper
easy to access



Hook & Loop Strap
tie to the curtains easily



Feets with Holes
to insert reinforcement accessories



Hanging Loop Design
easy for connection

Key features include double-sided zippers for easy access, hook & loop straps to tie curtains, feet with holes for ground stakes, and a hanging loop design for easy curtain connection.

4.4 Securing the Gazebo

Use the provided ground stakes to firmly anchor the gazebo's feet to the ground. This is crucial for stability, especially in windy conditions.

5. OPERATING INSTRUCTIONS

Your Outsunny gazebo offers versatile usage options:

- **Practical Curtains:** Fully close the polyester curtains for privacy and enhanced sun protection. Use the hook & loop straps to secure them when open.
- **Mesh Sidewalls:** Close the mesh sidewalls using the zippers to protect against insects while maintaining airflow.
- **Open-air Feel:** Tie back both the curtains and mesh sidewalls to enjoy an unobstructed open-air environment.

3 USAGE STATES



Practical Curtains



Mesh Sidewalls



Open-air Feel



The gazebo offers three usage states: practical curtains for privacy, mesh sidewalls for insect protection, and an open-air feel.

6. MAINTENANCE

Regular maintenance will extend the life of your gazebo.

- **Cleaning:** Clean the canopy and curtains with mild soap and water. Rinse thoroughly and allow to air dry completely before storage. Do not use harsh chemicals or abrasive cleaners.
- **Frame Care:** Inspect the aluminum and steel frame periodically for any signs of rust or damage. Clean with a damp cloth.
- **Fasteners:** Check all bolts and connections regularly to ensure they remain tight.
- **Seasonal Storage:** During off-season or severe weather forecasts, it is recommended to dismantle the canopy and store it in a dry, protected area to prevent damage and prolong its lifespan.

7. TROUBLESHOOTING

Here are solutions to common issues:

- **Water Accumulation on Canopy:** Ensure the canopy is installed tautly. The built-in grommet holes are designed for drainage; ensure they are not blocked by debris. If water still pools, check for proper frame alignment.
- **Gazebo Instability:** Verify that all ground stakes are fully inserted and secured. In very windy conditions, additional anchoring methods (e.g., sandbags, weights) may be necessary, or the gazebo should be dismantled.
- **Difficulty with Zippers:** Ensure the fabric is aligned correctly before zipping. Apply a silicone-based lubricant if zippers become stiff.

8. SPECIFICATIONS

Feature	Detail
Model Number	84C-051V00CW
Overall Dimensions (L x W x H)	296 cm x 296 cm x 265 cm (116.5" L x 116.5" W x 104.3" H)
Eave Height	196 cm (77.2")
Frame Material	Alloy Steel, Aluminum
Canopy Material	Polyester with PA coating
Sidewall Material	Polyester (curtains), Mesh (netting)
Color	Cream White and Black
Item Weight	28.12 kg
Assembly Required	Yes
Water Resistance Level	Water Resistant
UV Protection	Yes
Occupancy	5 Person

9. WARRANTY AND SUPPORT

This Outsunny gazebo comes with a **90 Day Warranty Against Manufacturer Defects**. Please retain your proof of purchase for warranty claims.

For customer support, missing parts, or warranty inquiries, please contact Aosom Canada:

Phone: 1-416-792-6088

Place of Business: Markham, Ontario, CA

For more information, you may also visit the [Outsunny Store on Amazon.ca](#).

