

KADAMS K5273-02

KADAMS Visual Pomodoro Timer Cube

Model: K5273-02

User Instruction Manual

INTRODUCTION

Thank you for choosing the KADAMS Visual Pomodoro Timer Cube. This innovative device is designed to enhance your productivity and time management through intuitive visual and audible cues. It features preset countdowns, customizable timing, a count-up function, and a silent mode, making it suitable for various environments like work, study, cooking, and exercise. Please read this manual carefully to ensure proper use and to maximize the benefits of your new timer.

PRODUCT FEATURES

- **4 Preset Countdown Options:** Easily select 5, 10, 25, or 50 minutes by simply flipping the cube.
- **Visual LED Ring Display:** A clear LED ring gradually fills or empties, providing an intuitive visual representation of time progression.
- **Fully Customizable Countdown:** Set any desired time for one of the timer's sides using the control buttons.
- **Silent Mode:** Operate the timer without sound, ideal for quiet environments.
- **Stopwatch Mode:** Track elapsed time up to 99 minutes and 59 seconds.
- **USB-C Charging:** Convenient and modern charging interface.

SETUP

1. **Unboxing:** Carefully remove the KADAMS Visual Pomodoro Timer Cube from its packaging.
2. **Initial Charge:** Before first use, fully charge the timer using the provided USB-C cable. Connect the cable to the Type-C port on the back of the timer and to a suitable USB power source. The display will show a charging indicator.
3. **Power On/Off:** Locate the ON/OFF switch on the back of the timer. Slide it to the 'ON' position to power on the device. Slide to 'OFF' to power off and conserve battery when not in use.



Image: Back of the KADAMS timer with ON/OFF switch and Type-C charging port clearly visible.




Image: The timer's display showing a battery icon, indicating it is charging.

OPERATING INSTRUCTIONS

Preset Countdown Timer

The KADAMS Visual Pomodoro Timer Cube comes with four preset countdown times: 5, 10, 25, and 50 minutes. Each time is marked on a different side of the cube.

1. **Select Time:** Simply flip the cube so that the desired preset time (e.g., '25 MIN') is facing upwards. The timer will automatically start counting down.
2. **Visual Progress:** The LED ring on the display will gradually decrease as time elapses, providing a visual indication of the remaining time.
3. **Alarm:** Once the countdown reaches zero, an audible alarm will sound (if not in silent mode) and the display will flash.
4. **Stop/Reset:** To stop the alarm and reset the timer, simply flip the cube to any other side or place it face down.

4 PRESET COUNTDOWN




Image: The KADAMS timer cube illustrating its four preset countdown options (5, 10, 25, 50 minutes) and how to pause or reset it.

Image: A hand demonstrating the 'Flip to Start' feature of the KADAMS timer cube, highlighting its ease of use without buttons.

Customizable Countdown Timer

You can set a custom countdown time for one of the unmarked sides of the cube.

1. **Enter Customization Mode:** Place the timer on an unmarked side. Press and hold the 'SET' button on the back of the timer until the display flashes.
2. **Set Minutes/Seconds:** Use the 'M' (minutes) and 'S' (seconds) buttons to adjust the desired time.
3. **Confirm Setting:** Press the 'SET' button again to confirm and save your custom time.
4. **Start Custom Countdown:** Once set, simply place the timer with the customized side facing up to start the countdown.



Image: Diagram showing the control buttons on the back of the timer, including 'SET', 'S' (seconds), 'M' (minutes), and 'UP' for customization.

Count-Up (Stopwatch) Mode

The timer can also function as a stopwatch to track elapsed time.

1. **Activate Count-Up:** Place the timer on an unmarked side. Long press the 'UP' button on the back of the timer. The display will show '00 00' and start counting upwards.
2. **Pause/Resume:** To pause the count-up, briefly flip the timer face down. Flip it back up to resume.
3. **Reset:** To reset the stopwatch, long press the 'UP' button again while in count-up mode.

Countdown & Count-Up Timer



Image: The KADAMS timer displaying both countdown (left) and count-up (right) functions, highlighting its versatility.

Silent Mode

To use the timer without audible alarms or beeps:

1. **Activate Silent Mode:** While the timer is on, long press the 'UP' button (if not already in count-up mode). A speaker icon with a cross will appear on the display, indicating silent mode is active.
2. **Deactivate Silent Mode:** Long press the 'UP' button again to re-enable sound. The speaker icon will disappear.



Image: A visual representation of how to activate the mute function on the KADAMS timer, indicated by a crossed-out speaker icon on the display.

Pause and Reset Functions

- **Pause:** To pause an active countdown or count-up, simply place the timer face down. The display will show the paused time.
- **Resume:** Flip the timer back to its active side to resume the timer from where it left off.
- **Reset:** To reset a timer to its initial state (for preset times) or to zero (for custom/count-up), flip the timer to a different side or place it face down and then back to the desired side.



Image: A visual guide demonstrating how to pause the timer by turning it face down, showing the time frozen on the display.



Image: A visual guide demonstrating how to reset the timer by flipping it to a different side, returning it to its initial

time setting.

Product Video Overview

Your browser does not support the video tag.

Video: An official product video from Kadams Products demonstrating the KADAMS Pomodoro Timer Cube's features and ease of use, including flipping to set times, customization, and silent mode.

MAINTENANCE

- **Cleaning:** Wipe the timer with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the timer in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery:** The timer has a built-in rechargeable battery. Charge it regularly to maintain battery health. Avoid fully discharging the battery for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Timer not turning on	Battery is low or depleted.	Charge the timer using the USB-C cable. Ensure the ON/OFF switch is in the 'ON' position.
No sound from alarm/beeps	Silent mode is activated.	Long press the 'UP' button on the back of the timer to deactivate silent mode.
Display is dim or unresponsive	Low battery or device malfunction.	Charge the timer. If the issue persists, try turning the device off and on again. If still unresponsive, contact customer support.
Custom time not saving	'SET' button not pressed to confirm.	Ensure you press the 'SET' button after adjusting minutes and seconds to save the custom time.

SPECIFICATIONS

- **Model:** K5273-02
- **Color:** White

- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Product Dimensions:** 2"D x 2"W x 1.5"H (approximately 5.08 cm D x 5.08 cm W x 3.81 cm H)
- **Item Weight:** 0.17 Pounds (approximately 77 grams)
- **Preset Timers:** 5, 10, 25, 50 minutes
- **Custom Timer Range:** Up to 99 minutes 59 seconds
- **Charging Interface:** USB Type-C




Image: The KADAMS timer cube with its dimensions (2.0in x 2.0in x 1.6in) clearly indicated.

WARRANTY AND SUPPORT

KADAMS products are designed for quality and reliability. For warranty information, technical support, or any questions regarding your Visual Pomodoro Timer Cube, please refer to the contact information provided with your purchase or visit the official KADAMS website. Keep your proof of purchase for warranty claims.