

## CUTEBEE CWGC202

# CUTEBEE The Astrology Bookshop Book Nook Kit Instruction Manual

Model: CWGC202

## INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your CUTEBEE The Astrology Bookshop Book Nook Kit. Please read all instructions carefully before beginning assembly to ensure a smooth and enjoyable experience.

## SAFETY INFORMATION

No specific safety warnings are applicable beyond general crafting precautions. Always handle small parts with care and keep them out of reach of young children. Adult supervision is recommended for users under 14 years of age.

## WHAT'S IN THE BOX

Your CUTEBEE The Astrology Bookshop Book Nook Kit includes:

- Wooden pieces
- Paper accessories
- Lighting components

**Note:** Silicone liquid glue and two AAA batteries are required for assembly and operation, but are not included in the kit. Please prepare these items separately.




Image: Kit components laid out, including wooden sheets and accessory packs.

## ASSEMBLY PROCESS

The assembly of The Astrology Bookshop Book Nook Kit involves combining various wooden and paper components to create a detailed miniature scene. Follow the numbered steps in the provided instruction booklet carefully.

1. Carefully detach each piece from its wooden sheet. Refer to the instruction manual for part identification (e.g., C14, C16).
2. Assemble the base structure of the book nook, ensuring all interlocking pieces fit securely.
3. Attach decorative elements such as the miniature books, potions, and furniture using silicone liquid glue. Allow adequate drying time for each glued component.
4. Integrate the lighting components as instructed. This typically involves threading wires and securing small LED lights within the structure.
5. Complete the exterior details, including the front facade, side walls, and any additional decorative pieces.



Image: A close-up of hands assembling small, intricate wooden pieces of the kit.



Image: A hand carefully placing a small, detailed piece into the miniature structure.

The assembly process is designed to be engaging and can take approximately 3-5 hours. It encourages logical thinking and patience.

## Assembly Video Guide

Your browser does not support the video tag.

Video: A time-lapse demonstration of the assembly process for a CUTEBEE book nook kit, highlighting various steps from unboxing to completion.

## OPERATING INSTRUCTIONS

Once assembled, your Astrology Bookshop Book Nook features integrated lighting to enhance its display. To operate the lighting:

- Ensure two AAA batteries are correctly installed in the designated battery compartment.
- Locate the touch switch, typically integrated into the design (e.g., on the front facade or base).
- Gently touch the switch to turn the internal lights on or off.




Image: The assembled book nook, highlighting the touch switch for the internal lighting.

## PRODUCT DETAILS AND FEATURES

The Astrology Bookshop Book Nook is designed with intricate details to create a mystical and relaxing environment. Key features include:

- Soft lighting and mystical decor, including tarot cards, crystal balls, and ancient books.
- A unique front lawn design that adds depth and character.
- A dust cover to protect the delicate miniature scene.
- Detailed interior elements such as shelves, a counter, and various astrological items.



Image: A collage of close-up views showing the intricate details of the book nook's interior.

# Unique Front Lawn Design



Image: The book nook displaying its unique front lawn design and the total number of pieces.

## Product Overview Video

Your browser does not support the video tag.

Video: A detailed overview of the assembled CUTEBEE The Astrology Bookshop Book Nook, showcasing its features and intricate design.

## MAINTENANCE

To maintain the quality and appearance of your book nook:

- Keep the assembled kit in a dry environment, away from direct sunlight and excessive humidity, to prevent warping or fading of materials.
- Use a soft, dry cloth or a small brush to gently remove dust from the surfaces and intricate details.
- Avoid using liquid cleaners or abrasive materials, as these can damage the painted surfaces and delicate components.
- Replace AAA batteries as needed for the lighting function.

# TROUBLESHOOTING

| Issue                                        | Possible Solution                                                                                                                                                                                                             |
|----------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Missing or damaged accessories upon delivery | Contact CUTEBEE customer support immediately for assistance. The kit is carefully checked before delivery.                                                                                                                    |
| Difficulty fitting pieces during assembly    | Ensure you are using the correct pieces for the current step as indicated in the manual. Apply gentle pressure; do not force pieces. If a piece is slightly tight, a small amount of sanding may be necessary (not included). |
| Lights not working                           | Check that two fresh AAA batteries are correctly installed. Verify all wiring connections are secure according to the instruction manual. Ensure the touch switch is functioning correctly.                                   |

# SPECIFICATIONS

- **Product Dimensions:** 6.3 x 6.1 x 7.09 inches
- **Item Weight:** 1.65 pounds
- **Item Model Number:** CWGC202
- **Manufacturer Recommended Age:** 14 years and up
- **Manufacturer:** CUTEBEE

# SUPPORT

For any questions or assistance during assembly or use, please contact CUTEBEE customer support. Refer to the contact information provided with your product packaging or visit the official CUTEBEE website.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question