

ECONTROLLY CRMC-A920JBEZ

ECONTROLLY CRMC-A920JBEZ Replacement AC Remote Control User Manual

FOR SHARP AIR CONDITIONERS

1. Introduction

This manual provides instructions for the ECONTROLLY CRMC-A920JBEZ replacement remote control, designed for use with various Sharp Air Conditioner models. This remote control is pre-programmed and operates via infrared signals, requiring no additional setup or programming.

Please read this manual thoroughly before using the remote control to ensure proper operation and to familiarize yourself with its features.

2. Product Overview

The ECONTROLLY CRMC-A920JBEZ is a direct replacement for your original Sharp Air Conditioner remote. It features a clear display and intuitive buttons for controlling your air conditioning unit's functions.






Figure 1: Front view of the ECONTROLLY CRMC-A920JBEZ remote control. This image shows the main display screen and primary function buttons including COOL, DRY, HEAT, STOP, and temperature adjustment buttons.






Figure 2: Back view of the remote control, illustrating the battery compartment. This section is where AAA alkaline batteries are inserted to power the device.



Figure 3: Image displaying the dimensions of the remote control. The remote measures approximately 20.5 cm (8.07 inches) in length and 5.7 cm (2.24 inches) in width.

3. Setup: Battery Installation

1. Locate the battery compartment on the back of the remote control (refer to Figure 2).
2. Slide open the battery compartment cover.
3. Insert two (2) AAA ALKALINE batteries, ensuring the positive (+) and negative (-) terminals match the markings inside the compartment.
4. Close the battery compartment cover securely.

Important: Use only AAA ALKALINE batteries. Do not use rechargeable batteries, as they may not provide sufficient power for optimal performance. Batteries are not included with the remote control.

4. Operating Instructions

This remote control is pre-programmed and ready to use with compatible Sharp Air Conditioner models. Point the remote control directly at the air conditioner unit's infrared receiver.

Basic Functions:

- **POWER/STOP:** Press the **STOP** button to turn the air conditioner unit ON or OFF.
- **MODE Selection:**
 - Press **COOL** for cooling mode.
 - Press **DRY** for dehumidification mode.
 - Press **HEAT** for heating mode.
- **Temperature Adjustment:** Use the **TEMP ▲** (Up) and **TEMP ▼** (Down) buttons to adjust the desired temperature. *Note: This remote control displays temperature in Celsius only.*
- **FAN Speed:** Press the **FAN** button to cycle through available fan speeds (e.g., Low, Medium, High, Auto).

Advanced Functions (if applicable):

- **MY AREA:** This button may activate a specific airflow setting or direct airflow to a particular zone. Refer to your air conditioner's main manual for details on this function.
- **Ion:** Activates or deactivates the ionizer function, if supported by your air conditioner, to improve air quality.
- **Timer (1-2-3-5h):** This button likely sets a timer for the unit to turn off after a specified duration (1, 2, 3, or 5 hours). Press repeatedly to cycle through options.

5. Compatible Air Conditioner Models

This ECONTROLLY CRMC-A920JBEZ remote control is compatible with the following Sharp Air Conditioner models:

- AY-XPC18LR
- AY-XPC07PU
- AY-XP24PU
- AY-XP24LR
- AY-XPC15PU
- AY-XPC12PHR

- CRMC-A868JBEZ (also compatible with this remote model)
- AY-XPC18PU
- AY-XPC12PU
- AY-XPC09PU
- AY-XPC9PHR
- AY-XPM7PHR
- CRMC-A920JBEZ (original remote model this replaces)

6. Specifications

Feature	Detail
Model	CRMC-A920JBEZ (Replacement)
Brand	ECONTROLLY
Compatibility	Sharp Air Conditioners (specific models listed above)
Special Feature	Pre-Programmed, Infrared
Power Source	2 x AAA Alkaline Batteries (not included)
Display	Celsius only
Color	White
Product Dimensions	3.94 x 1.57 x 0.59 inches (10 x 4 x 1.5 cm)
Item Weight	1.76 ounces (50 grams)

7. Troubleshooting

- **Remote not responding:**
 - Ensure fresh AAA alkaline batteries are correctly installed with proper polarity.
 - Check for any obstructions between the remote control and the air conditioner's infrared receiver.
 - Confirm you are within the effective range of the air conditioner unit.
- **Display is dim or blank:**
 - Replace batteries with new AAA alkaline batteries.
- **Air conditioner not performing desired function:**
 - Verify the remote control is compatible with your specific Sharp Air Conditioner model (refer to Section 5).
 - Ensure the air conditioner unit is powered on and functioning correctly.
 - Some advanced functions (e.g., MY AREA, Ion) may require specific settings or features on your air conditioner unit. Consult your air conditioner's original manual.

8. Maintenance

- Keep the remote control clean by wiping it with a soft, dry cloth.

- Avoid exposing the remote control to direct sunlight, high temperatures, or moisture.
- If the remote control will not be used for an extended period, remove the batteries to prevent leakage.

9. Warranty and Support

For warranty information or technical support, please contact the ECONTROLLY customer service department through your original point of purchase. Please have your product model number (CRMC-A920JBEZ) and purchase details ready.
