



Manuals.plus /

- › APD APETDOLA /
- › APD APETDOLA FS10pro-5 Wireless Stainless Steel Pet Water Fountain User Manual

APD APETDOLA FS10pro-5

APD APETDOLA FS10pro-5 Wireless Stainless Steel Pet Water Fountain

User Manual

INTRODUCTION

Thank you for choosing the APD APETDOLA FS10pro-5 Wireless Stainless Steel Pet Water Fountain. This automatic pet water dispenser is designed to provide fresh, clean water for your cats and small to medium-sized dogs, promoting better hydration and health. Its wireless design offers flexible placement, and the durable stainless steel construction ensures hygiene and longevity. Please read this manual thoroughly before use to ensure proper setup and operation.



Image: The APD APETDOLA FS10pro-5 Wireless Stainless Steel Pet Water Fountain, showcasing its sleek design and included filters.

KEY FEATURES

- **Wireless Operation:** Powered by a built-in 4000mAh rechargeable battery, offering up to 60 days of use on a single charge, allowing flexible placement without cord constraints.
- **Large Capacity:** 152oz (4.5L) water tank ensures up to 2 weeks of hydration for your pets, with a visible window for easy monitoring.
- **Premium Material:** Constructed from SUS 304 stainless steel, providing a hygienic, rust-resistant, and easy-to-clean surface. Dishwasher-safe components.
- **Triple Water Modes:** Features Sensing mode (water flows for 15s when pet approaches within 31.5 inches/80cm), Intermittent mode (water for 15s every 10 minutes), and Constant mode (continuous flow).
- **Multi-layer Filtration:** Advanced filtration system removes heavy metals, dirt, and other harmful substances, ensuring fresh and clean drinking water.
- **Ultra-Quiet Operation:** Unique gentle flow structure reduces noise to a whisper-quiet 25dB.

WHAT'S IN THE BOX

Your APD APETDOLA FS10pro-5 Pet Water Fountain package includes the following components:

- Stainless Steel Water Tray x 1
- Stainless Steel Water Tank x 1
- Master Control Module (with pump) x 1
- Type-C Charging Cable x 1
- Adapter x 1
- Cleaning Brush x 1
- Filter Tray x 1
- Filter Cotton (Pre-filter Sponges) x 20
- Filters x 5
- User Manual x 1

Packing Accessories



Image: All components included in the product packaging, laid out for clear identification.

Your browser does not support the video tag.

Video: An overview of the APD APETDOLA pet fountain and feeder product line, showcasing various models and features.

SETUP INSTRUCTIONS

Follow these steps to assemble and prepare your pet water fountain for use:

- 1. Pre-wash Components:** Before first use, thoroughly wash all parts of the fountain (stainless steel tank, water tray, filter tray, and pump) with water. The stainless steel components are dishwasher-safe.
- 2. Install Filter:** Place one filter into the filter tray. Ensure the filter cotton (pre-filter sponge) is also correctly positioned. It is recommended to soak the filter in water for 5 minutes before installation to remove any loose carbon dust.
- 3. Assemble Base:** Place the filter tray with the filter inside the stainless steel water tank.
- 4. Position Pump:** Insert the Master Control Module (pump) into the designated opening on the water tray. Ensure it is securely seated.
- 5. Place Water Tray:** Carefully place the stainless steel water tray onto the water tank, aligning it properly.
- 6. Fill with Water:** Fill the water tank with fresh water up to the 'MAX' line indicated on the side. Avoid overfilling.
- 7. Power On:** Connect the Type-C charging cable to the Master Control Module and the adapter, then plug it into a power outlet to charge the internal battery or operate in continuous mode.




Image: Visual guide demonstrating the three main steps for installing the APD APETDOLA Cordless Pet Fountain.

OPERATING INSTRUCTIONS

The APD APETDOLA FS10pro-5 offers three distinct working modes to suit your pet's preferences and your convenience. Use the power/mode switch button on the Master Control Module to cycle through the modes.

Water Flow Modes:

- **Sensing Mode (Recommended):** When a pet approaches within 31.5 inches (80cm) of the fountain, it will automatically dispense water for 15 seconds. This conserves battery life and encourages pets to drink.
- **Intermittent Mode:** The fountain dispenses water for 15 seconds at intervals of 10 minutes. This mode is ideal for moderate use and battery saving.
- **Constant Mode:** Water flows continuously. This mode is suitable when the fountain is plugged in or for

pets who prefer a constant water stream.

Battery Life and Charging:

The built-in 4000mAh rechargeable battery provides up to 60 days of operation on a full charge, depending on the selected mode and usage frequency. The fountain ensures your pet stays hydrated even during power outages. Use the provided Type-C cable and adapter for charging.



Image: Illustration detailing the three work modes: Sensor mode, Timed mode, and Continuous mode.

Wireless Put it Anywhere

Battery-Operated help your pets can drink
wherever they feel comfortable.



Image: Pets enjoying the wireless water fountain in different indoor settings, highlighting its portability.

3 Work Modes

With sensor mode, entices instinct to drink more water.



Sensor mode

Water Runs Auto When Cat Approaches.



120°

4-6ft



Timed Mode (unplugged)

Save energy by running water every 15 minutes.



Continuous mode (plug in)

For pets 24/7 hydration.

Image: An exploded view of the fountain's power module, illustrating the 4000mAh battery and Type-C charging port.

MAINTENANCE

Regular maintenance is crucial for the longevity and hygiene of your pet water fountain. Follow these guidelines:

Cleaning:

- **Weekly Cleaning:** Clean the entire fountain, including the stainless steel tank, water tray, filter tray, and pump, at least once a week.
- **Stainless Steel Parts:** The stainless steel tank and water tray are dishwasher-safe for convenient and thorough cleaning.

- **Pump Cleaning:** Use the provided cleaning brush to clean the pump thoroughly, ensuring no debris obstructs its operation.

Filter Replacement:

- **Filter Replacement Frequency:** It is recommended to change the main filter every two weeks and the filter cotton (pre-filter sponge) once a week to maintain optimal water quality.
- **Official Filters:** For replacement filters, search for model B0C36JSP76.



Image: The stainless steel components of the fountain shown inside a dishwasher, emphasizing ease of cleaning.

Fresh in Every Drop

6-layer filtration system keep drinking water fresher, healthier, better taste for your fur babies.




Image: A detailed diagram illustrating the 6-layer filtration system, highlighting each filtration stage for fresh and healthy water.

TROUBLESHOOTING

If you encounter any issues with your pet water fountain, refer to the following common problems and solutions:

- **Fountain Not Dispensing Water:**
 - Check the water level. Ensure it is above the 'MIN' line.
 - Verify the Master Control Module (pump) is correctly installed and fully charged or plugged in.
 - Clean the pump and filter for any obstructions.

- Ensure the selected mode is active (Sensing, Intermittent, or Constant).
- **Water Flow is Weak:**
 - Clean the pump and water outlet thoroughly.
 - Replace the filter if it is clogged.
 - Check the water level.
- **Excessive Noise:**
 - Ensure the water level is sufficient. Low water can cause pump noise.
 - Clean the pump for any debris that might be causing vibrations.
 - Ensure all components are assembled correctly and securely.
- **Indicator Lights:**
 - **Red Light:** Indicates low battery. Recharge the fountain.
 - **Flashing Light:** Reminds you to replace the filter (typically once a month). Long press the on/off key to turn it off after replacement.



Image: A close-up of the user-friendly indicator lights on the control module, showing reminders for low battery and filter replacement.

SPECIFICATIONS

Feature	Detail
Brand	APD APETDOLA
Model Name	FS10pro-5
ASIN	B0DRCLM9M5
Material	SUS 304 Stainless Steel
Capacity	4.5 Liters (152oz)
Power Source	Battery Powered (4000mAh Lithium Ion, included)
Battery Life	Up to 60 days on a full charge
Item Dimensions (LxWxH)	10.63 x 9.06 x 5.91 inches
Item Weight	3.43 pounds
Included Components	5pcs Filter, Cleaning Brush, Type-C Cable, Adapter
Target Audience	House-cats, Small to Medium-sized Dogs

WARRANTY & SUPPORT

The APD APETDOLA FS10pro-5 Wireless Stainless Steel Pet Water Fountain comes with a **1-year warranty** from the date of purchase. For any product inquiries, technical support, or warranty claims, please contact APD APETDOLA customer service through the retailer where the product was purchased.

Please retain your proof of purchase for warranty validation.