



Manuals.plus /

› Yuejiqi /

› Yuejiqi G3530 Folding Treadmill User Manual

Yuejiqi G3530

Yuejiqi G3530 Folding Treadmill User Manual

Brand: Yuejiqi

Model: G3530

INTRODUCTION

Thank you for choosing the Yuejiqi G3530 Folding Treadmill. This compact and versatile running machine is designed for home use, offering a convenient way to achieve your fitness goals. With its powerful motor, adjustable incline, and user-friendly features, it provides a comfortable and effective workout experience. Please read this manual thoroughly before operation to ensure safe and proper use.



Image: The Yuejiqi G3530 Folding Treadmill shown in both its operational state with a user walking, and its compact folded state for storage.

PRODUCT FEATURES

- **Powerful 3.0 HP Motor:** Equipped with a low-noise 3.0 HP motor, supporting speeds from 0.5 MPH to 6.0 MPH, suitable for walking, jogging, and light running.

3.0HP

Powerful Low-Noise Motor



3.0 HP
Powerful Motor



0.5-6.0 MPH
Speed Range



240 LBS
Weight Capacity



≤55 DB
Low Noise




Image: An exploded view illustrating the internal components of the 3.0 HP low-noise motor, highlighting its power and quiet operation.

- **Manual Incline Levels:** Features 3 levels of manual incline, allowing you to adjust the intensity of your workout from 0% to 6%.

Three-Level Manual Incline To 6%



Image: A user on the treadmill, with visual overlays demonstrating the three distinct manual incline levels (0%, 3%, and 6%) available for varied workout intensity.

- **Advanced Shock Absorption:** The 39.4" x 15" running belt is made of 5-layer non-slip textured material, combined with 4 silicone and 6 built-in shock absorbers, providing maximum protection for joints and ankles.

Ease the Strain on Your Knees



6 Built-in
Shock Absorbers



5-Layer Anti-slip
Running Belt



Image: A visual representation of the treadmill's running belt layers and the integrated shock absorption system, designed to reduce impact on knees and joints.

- **LED Display Console:** The clear LED screen displays essential workout data including time, speed, distance, and calories. It features 12 preset programs and intuitive controls for speed and mode selection.

LED Display Console



Image: A detailed view of the treadmill's LED display console, showing the screen, control buttons for speed and programs, integrated speakers, device holder, and cup holders.

- **Compact & Portable Design:** Designed for small spaces, this treadmill can be easily folded and moved using its built-in wheels.

Compact Design Easy To Move and Store



Image: A visual guide demonstrating how the treadmill folds for compact storage and is easily moved using its integrated wheels, ideal for small living spaces.

- **Multifunctional Console:** Includes a built-in speaker for music, convenient cup holders, and tablet/phone holders to enhance your workout experience.
- **Safety Key:** An essential safety feature that immediately stops the treadmill when pulled, preventing injury.

The Yuejiqi G3530 treadmill comes mostly pre-assembled, requiring only a few simple steps to get it ready for use.

Included Components:

- User Manual (x1)
- Safety Key (x1)
- Plum Knob (x1)
- Screw M8*25 (x2)
- Lubricating Oil (x1)
- Inner Hexagon Spanner 5mm (x1)
- Inner Hexagon Spanner 6mm (x1)



Image: A visual representation of all parts and tools included in the package for assembling the treadmill.

Assembly Steps:

1. Carefully remove the treadmill and all components from the packaging.
2. Unfold the treadmill to its upright position. Ensure the main frame is securely locked into place.
3. Attach any remaining components as per the detailed instructions in the included User Manual. This typically involves securing the console and handlebars.
4. Plug the power cord into a grounded electrical outlet.
5. Attach the safety key to the designated slot on the console and clip the other end to your clothing before starting any workout.

For detailed visual instructions, please refer to the comprehensive User Manual provided with your product.

OPERATING INSTRUCTIONS

Getting Started:

1. Ensure the treadmill is properly set up and the safety key is in place.
2. Step onto the treadmill belt.
3. Press the "Start" button on the LED console to begin your workout. The belt will start moving at a low speed.

Console Functions:

- **LED Display:** Shows Time, Speed, Distance, and Calories burned.
- **Speed Adjustment:** Use the "+" and "-" buttons to increase or decrease the speed. Quick speed buttons (e.g., 2/4/6 MPH) are also available.
- **Program (P) Button:** Cycle through 12 preset workout programs (PROG).
- **Mode (M) Button:** Select different display modes or set target goals.
- **Safety Key:** Pulling the safety key from the console will immediately stop the treadmill for emergency situations.

Adjusting Incline:

The G3530 features 3 levels of manual incline. To adjust the incline, you will need to stop the treadmill and manually adjust the support pins located at the rear of the treadmill. Refer to the user manual for precise instructions on how to safely change the incline level.

Using Multimedia Features:

- **Speaker:** Connect your device to the treadmill's audio input (if available) or use the built-in speaker for music.
- **Device Holders:** Place your tablet or phone in the designated holders on the console for entertainment or tracking.

Your browser does not support the video tag.

Video: An official product video demonstrating the features and operation of the YUEJIQI Treadmill with Incline, including its console functions and manual incline adjustment.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your treadmill.

Lubrication Schedule:

Proper lubrication of the running belt is crucial. Use the provided lubricating oil according to the following schedule:

Usage Frequency	Maintenance Frequency
<3 Hours/Week	Every 2 Months
4-7 Hours/Week	Every 1 Month
>8 Hours/Week	Every 2 Weeks

Multi-Functional Console

Time 🕒 Speed 🏃 program 🏠

Distance 📍 Calorie 🔥 Speaker 🎵



Image: A visual guide on how to apply lubricating oil to the treadmill belt, accompanied by a table detailing the recommended lubrication schedule based on usage frequency.

General Cleaning:

- Wipe down the console and frame with a damp cloth after each use.
- Periodically vacuum under the treadmill to prevent dust buildup.

TROUBLESHOOTING

If you encounter any issues with your treadmill, please refer to the detailed troubleshooting section in the complete User Manual. Common issues and their solutions are typically covered there.

For persistent problems or technical assistance, please contact Yuejiqi customer support.

SPECIFICATIONS

Feature	Detail
Motor	3.0 HP Low-Noise
Speed Range	0.5 - 6.0 MPH
Weight Capacity	240 LBS
Running Belt Dimensions	39.4" (Length) x 15" (Width)
Incline Levels	3 Manual Levels (0-6%)
Product Dimensions (Unfolded)	51.2"D x 23"W x 44.3"H
Folded Dimensions (Approx.)	23"D x 8.5"W x 48.6"H (based on image)
Item Weight	46.3 Pounds
Display Type	LED
Number of Programs	12 Preset PROG

WARRANTY & SUPPORT

The Yuejiqi G3530 Folding Treadmill comes with a **1-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or any questions regarding your product, please contact Yuejiqi customer service through the retailer's platform or the official brand website. Please have your purchase receipt and product model number (G3530) ready when contacting support.